

Check the axle ventilation for condition and tight fit.

- Check the connection point of the ventilation line for tightness, tighten if necessary.
- Vent line to the central vent behind Check the cab for cracks, breaks and kinks.

Check the oil level on the rear axle

same as for front axle group 33.

Oil change on the rear axle

same as for front axle group 33.

Compensation lock maintenance

same as for front axle group 33.

Checking tightness on the rear axle

same as for front axle group 33.

