AR68.30-P-4300GR Remove/install headliner 22.2.12

MODEL 463.222 /243 /244 /245 /246 /247 /249 /270 /271 /322 /323 /332 /333 /336 /340 /341

MODEL 463.248 except CODE (979) Special protection version


MODEL 463.237 /346 up to model year 2013 /model refinement package 2012

MODEL 463.236

except CODE (979) Special protection version up to model year 2013

/facelift 2012





P68.30-2426-08

- 1 Left sun visor
- 2 Right sun visor
- 3 Bolts
- 4 Bracket

- 5 Bearing
- 6 Cover
- 7 Inside rearview mirror
- 8 Left A-pillar paneling

- 9 Right A-pillar paneling
- B25 Handsfree system microphone
 - Overhead control panel control unit


24 Seat belt guide

A26/5 Interior protection transmitter and receiver



N70


P68.30-3007-11







P68.30-2574-09

- Grab handle 10
- 11 Covers










P68.30-2428-08

- 12 Inside rearview mirror bracket
- 13 Bolts
- 14 Electrical connector

- 15 Chrome-plated molding
- 16 Bolts
- 19 Sheet metal clip

B38 Rain sensor




P68.30-2429-09

- 17 Bolts
- 18 Guide rails

Illustrated on model 463.248

- 19 Plate clamps
- 21 Headliner

20 Bolts



P68.30-2430-02

| XX | Remove/install | | |
|----|--|---|---------------------|
| 1 | Remove paneling from tilting/sliding roof | i Only with code (D27) Electric tilting/sliding | AR77.20-P-0500G |
| | | roof | |
| 2 | Fully open tilting/sliding roof | i Only with code (D27) Electric tilting/sliding |] |
| | | roof | |
| 3 | Remove right front seat | Model 463.236/237/243/245/246/248/249/ | AR91.10-P-3300GR |
| | | 270/271/323/333/341/346 | |
| | | Model 463.222/244/247/322/332/336/340 | AR91.10-P-1000GM |
| | | wheelbase 2400 mm | |
| 4 | Remove rear seat and rear seat backrest | Except model 463.248 with code (SM1) Left | AR91.12-P-1700G |
| | | rear electrically adjustable individual seat with | |
| | | armrest with code (SM2) Right rear | |
| | | electrically adjustable individual seat with | |
| | | armrest | |
| | | i Only right rear seat. | |
| 5 | Activate service mode in Telematic Alarm Identification on Demand (emergency call system) (TELE AID) | i Only on model 463.243/244/245/250/309/ | AR82.95-P-0005-03GR |
| | | 322/323/332/333 with code (ET2) TELE AID | |
| | | car telephone emergency call system, | |
| | | 463.247/248/254/270 up to 1.4.07 | |
| | | with code (ET2) TELE AID car telephone | |
| | | emergency call system | |

| i | Notes regarding the TELE AID emergency call system | Model 463.243/244/245/250/309/322/323/ 332/333, Model 463.247/248/254/270 up to 1.4.07 | AH82.95-P-0001-01GA |
|-----------|--|--|--------------------------------------|
| ⚠ Danger! | Risk of explosion caused by escaping oxyhydrogen gas. Risk of injury caused by caustic burns to eyes, skin and mucous membranes from battery electrolyte (contains diluted sulfuric acid) or metal spatter due to short circuit. Risk of burn injuries caused by short circuit. Risk of poisoning caused by swallowing battery electrolyte (contains diluted sulfuric acid) or absorption of lead ove the skin or orifices | No fire, sparks, open flames or smoking. Wear acid-resistant gloves and clothing and safety glasses with side guards. Do not place any conductive objects on the battery and avoid any short circuit from battery positive to ground. Only pour liquid battery electrolyte (diluted sulfuric acid) into suitable and appropriately | AS54.10-Z-0001-01A |
| 6 | Disconnect battery ground line | | AR54.10-P-0003G |
| 7 | Notes on battery Pivot left sun visor (1) and right sun visor (2) to side and unscrew bolts (3) from | All models | AH54.10-P-0001-01A |
| 8 | corresponding brackets (4). Remove left sun visor (1) and right sun visor (2) | i Disconnect electrical connectors. | |
| 9 | Remove bearing (5) from left sun visor (1) and right sun visor (2) | The bolt is located behind the cover (6), which can be folded downward. | |
| 10 | Remove overhead control panel control unit (N70) | | AR82.20-P-1000GM |
| 11 | Remove rearview mirror (7) | | AR68.40-P-0001GM |
| 12 | Detach electrical connector (14) at rain senso (B38) | | |
| 13 | Remove inside rearview mirror bracket (12) | i Remove bolts (13). | |
| 14 | Remove hands-free system microphone (B25 from headliner (21) | Disconnect electric connector. | *115589035900 |
| 15 | Remove paneling on A-pillar. | Remove left A-pillar paneling (8) and right A-pillar paneling (9). | AR68.30-P-4050H |
| 16 | Remove paneling on B-pillar | Model 463.243/245/246/248/249/323/333 up to 31.5.04 wheelbase of 2850 mm Model 463.243/245/246/248/249/323/333 As of 1.6.04 Model 463.236/237/270/271/341/346 | AR68.30-P-4700GN AR68.30-P-4700GY |
| 17 | Remove rear paneling from roof frame. | | AR68.30-P-4470GR |
| 18 | Remove belt guide (24) on center seat belt from headliner (21). | i Only on model 463.243/245/246/248/249/323/333 as of 1.06.04, Model 463.222/236/237/270/271/336/340/341/346 | |
| 19 | Remove grab handles (10) | i Slide back covers (11) and unscrew bolts. | |
| 20 | Remove cargo retaining net holder (22) | i Remove bolt (23) . | |
| 21 22 | Remove rear seat reading lights Remove interior protection transmitter and receiver (A26/5) | 3 | AR82.20-P-1120GR *115589035900 |
| 23 | Remove chrome molding (15) | i Only with code (D27) Electric tilting/sliding roof i The chrome molding (15) is fastened with six bolts (16). | |
| 24 | Unscrew bolts (17) from both guide rails (18) | i Only with code (D27) Electric tilting/sliding roof | |
| 25 | Remove guide rails (18) and coverings below | i Only with code (D27) Electric tilting/sliding roof i Installation: Coat left and right slide shoes with lubricant paste. | *BR00.45-Z-1004-06A |
| 26 | Carefully separate headliner (21) from roof skin at the gluing points | i Only with code (D27) Electric tilting/sliding roof i Installation: Remove adhesive residues and re-glue headliner (21) to specified points. | *BR00.45-Z-1002-02A |
| 27 | Unhook headliner (21) from tilting/sliding roof opening | i Only with code (D27) Electric tilting/sliding roof i To do this, detach the sheet metal clips (19). | |
| 28 | Remove bolts (20) from headliner (21) | | |
| 29 | Separate velcro connections (arrows) between roof panel and headliner (21). | i Secure headliner (21) against falling down with aid of second person | |
| 30 | Lower headliner (21) on right and remove diagonally through rear door opening | | |

| 32 | Deactivate service mode in Telematic Alarm Identification on Demand | i Only on model 463.243/244/245/250/309/322/323/332/333 with code (ET2) TELE AID car telephone emergency call system, 463.247/248/254/270 up to 1.4.07 with code (ET2) TELE AID car telephone | AR82.95-P-0005-03GR |
|-------------|---|---|---------------------|
| i | Notes regarding the TELE AID emergency call system | emergency call system Model 463.243/244/245/250/309/322/323/ 332/333, Model 463.247/248/254/270 up to 1.4.07 | AH82.95-P-0001-01GA |
| 33 | Read out fault memory and erase | i STAR DIAGNOSIS Stored faults which may be caused by removed cables or by a simulation, must be processed and erased in the fault memories after completing the work. | |
| ⊯ AD | Connect STAR DIAGNOSIS and read out fault memory | | AD00.00-P-2000-04A |
| 34 | Check all removed components for proper function | | |



Repair materials

| Number | Designation | Order number |
|--------------------|---|-----------------|
| BR00.45-Z-1002-02A | Adhesive Terokal 2444 | A 000 989 92 71 |
| BR00.45-Z-1004-06A | Synthetic grease, sliding roof 500 g, DB supply specification 6827.60 | A 001 989 46 51 |