AIOC

All-In-One-Cable Quick Start

1. Radio off. Push both K1 plugs fully in.
2. Connect USB-C to your computer.
3. Radio on, then open your software.

No drivers on Windows, Linux or macOS.

Scan for the full guide

Software setup · PTT fixes

`therealkamisama.github.io/AIOC-Guide`

One cable: sound card + PTT + serial

Sound card	Shows as “All-In-One-Cable”: mono, 48 kHz, RX + TX audio. Select it in your app only, or system sounds will transmit.	
PTT	**VPTT**	PTT1, as shipped: TX audio keys the radio. No PTT setup needed in your software.
	PTT2	CM108 GPIO4, for dual-PTT radios only.
	Others	CM108 GPIO3 and serial DTR/RTS are off. Add them in AIOC Toolkit → PTT Sources.
Serial	Radio programming (CHIRP). Windows `COMx` · Linux `/dev/ttyACMx` macOS `/dev/cu.usbmodem*`	

Transmitting needs a licence. Test into a dummy load or on low power.