AIOC

All-In-One-Cable Quick Start

1. Radio off. Push both K1 plugs fully in.
2. Connect USB-C to your computer.
3. Radio on, then open your software.

No drivers on Windows, Linux or macOS.

Scan for the full guide

Software setup · PTT fixes

`therealkamisama.github.io/AIOC-Guide`

One cable: sound card + PTT + serial

Sound card	Shows as “All-In-One-Cable”: mono, 48 kHz, RX + TX audio. Select it in your radio app. Don’t make it the system default.	
PTT	**CM108**	HID GPIO3. On by default. Try this first.
	Serial	DTR=1 and RTS=0. On by default.
	VPTT	Keys on TX audio, for apps with no PTT control. Firmware 1.3.0 or newer. Enable in AIOC Toolkit.
Serial	Radio programming (CHIRP) and serial PTT. Windows `COMx` · Linux `/dev/ttyACMx` macOS `/dev/cu.usbmodem*`	

Transmitting needs a licence. Test into a dummy load or on low power.