## Creality CR-X、CR-5S Setup For Cura 3.X

#### 1 Software Installation

Download the Cura From:

https://ultimaker.com/en/products/ultimaker-cura-software



Install Cura


Default path: C:\Program Files\Ultimaker Cura 3.4\




Install the set file in the same path

Default path: C:\Program Files\Ultimaker Cura 3.4\


### 2 Select language





Select settings $\rightarrow$ Configure setting visibility...  $\rightarrow$ General $\rightarrow$ language,Select language & Restart Cura.


#### 3 Add Printer



Official Website: www.creality3d.cn



深圳市创想三维科技有限公司 Shenzhen Creality 3D Technology Co., LTD.



Select settings →Add Printer...→Other→Select your printer model.

#### **4 Dual Print**




Select Dual Extrusion→Check the Enable Prime Tower→modify values


Official Website: www.creality3d.cn E-mail: cs@creality3d.cn

# CREALITY

深圳市创想三维科技有限公司 Shenzhen Creality 3D Technology Co., LTD.




Open the dual model




E-mail: cs@creality3d.cn

Official Website: www.creality3d.cn

Right-click→Select one of them→Check Extruder 1



Right-click $\rightarrow \rightarrow$ Select the another one $\rightarrow$ Check Extruder 2




E-mail: cs@creality3d.cn

Official Website: www.creality3d.cn



#### 深圳市创想三维科技有限公司 Shenzhen Creality 3D Technology Co., LTD.

Right-click→Select Selsct All Models



Right-click→Select Center Selected Models



Prepare & Save the Gcode.

Official Website: www.creality3d.cn E-mail: cs@creality3d.cn