Table 5.1. Data stream package.

<table>
<tr><td>Data stream package</td><td>> | S | B1 | B2 | … | Bn | <</td></tr>
<tr><td>Decimal view</td><td>62 | 83 | B1 | B2 | … | Bn | 60</td></tr>
<tr><td>Package length</td><td>27</td></tr>
</table>

Table 5.2. Data stream items.

Byte number	Item name	Item source	Item range (binary values)
B1	EMG CH1 low byte	DIAC0[1]	0 – 255
B2	EMG CH1 high byte		0 – 3
B3	EMG CH2 low byte	DIAC1	0 – 255
B4	EMG CH2 high byte		0 – 3
B5	Hand strength (set-point) low byte	DIAC11	0 – 255
B6	Hand strength (set-point) high byte		0 – 3
B7	Hand battery status	DIAC13	0 – 100
B8	Main actual position	DIAC 75	0 – 255
B9	Hand mech grip state	DIAC 82	0 – lateral mode 1 – opposition mode 4 – neutral mode
B10	Hand motion type	DIAC 84	0 – lateral close 1 – opposition close 2 – opposition open 3 – lateral open
B11	Thumb force	DIAC 87	0 – 255
B12	Rotator actual position	DIAC 105	0 – 255
B13	Bit 1 (MSB) – Hand connection status Bit 2-8 - TR-FB battery status	TR-FB	0 – 255
B14[2]	Vibration motors statuses	TR-FB	0 – 255
B15	Vibration intensity of the motor 1	TR-FB	0 – 100
B16	Vibration intensity of the motor 2	TR-FB	0 – 100
B17	Vibration intensity of the motor 3	TR-FB	0 – 100
B18	Vibration intensity of the motor 4	TR-FB	0 – 100
B19	Vibration intensity of the motor 5	TR-FB	0 – 100
B20	Vibration intensity of the motor 6	TR-FB	0 – 100
B21	Vibration intensity of the motor 7	TR-FB	0 – 100
B22	Vibration intensity of the motor 8	TR-FB	0 – 100
B23	Hand speed TRFB-Control low byte	TR-FB	0 – 255

[1] DIAC - Data stream item activation code – according to Ottobock protocol (Michelangelo hand is the item source).
[2] B18 is calculated as follows:

$$B18 = sum([VB1, VB2, VB3, VB4, VB5, VB6, VB7, VB8] .* [2^0, 2^1, 2^2, 2^3, 2^4, 2^5, 2^6, 2^7]),$$

where $VBn = \begin{cases} 0, if\ VBn\ is\ turned\ off \\ 1, if\ VBn\ is\ turned\ on \end{cases}$

B24	Hand speed TRFB-Control high byte	TR-FB	0 – 3