

Vestax Pro Cross Fader by Penny & Giles

Service Information

1.0 INTRODUCTION

This manual describes how to service the Penny & Giles Vestax Series crossfader. Servicing is limited to cleaning, re-lubrication and replacement of some components, such as the slider and track assembly. Periodic maintenance of these parts will provide a smooth operating feel and will extend the life of the unit. Cleaning of the unit may also be necessary if it is used in dirty or dusty environments or if contaminants have reached inside.

Please note that the fader must be removed from the panel before servicing.

2.0 SPARE PARTS

The following replacement parts are available for the Vestax Series cross fader from your local Vestax dealer.

Description	Vestax Part No.
Complete slider assembly	PG-CSA
Complete track assembly	PG-CTF
Service kit	PG-SERV

3.0 INSTRUCTIONS

- 3.1 Remove the two screws from the end of the unit where the wires exit and pull away the end block. Withdraw the dust cover and damping washer. Taking great care remove the slider assembly, ensuring the wiper contacts are not damaged as this will affect the operation of the unit. Cleaning of the slider assembly is possible by gently wiping the wiper contacts and slider bearings using a tissue or cotton bud. If the slider bearings are excessively worn, as seen by excessive slider rocking, a replacement assembly should be fitted.
- 3.2 Remove the single screw that secures the remaining end block to the body. Remove the end block and guide rod together. Clean the guide rod, using a tissue or cloth, removing all traces of dirt or contamination
- 3.3 Remove the track by carefully withdrawing from the unit and placing face up on the desk. It may be cleaned with a lint free cloth, rubbing firmly along the track in order to ensure no debris remains. If necessary, the track can be washed in warm water, wiped gently and then dried thoroughly using a dry cloth. When dry, wipe with a lint free cloth and check for marks along the track. (Note: lint-free clothes are recommended to avoid dust/fibres being deposited). If the track appears excessively worn, or if cleaning does not improve operation, replacement may be necessary.
- 3.4 Examine the centre channel of the fader body and if dirty, clean using cotton buds.
- 3.5 Re-assemble and lubricate the fader as follows:-
 - 1) Secure the end block and guide rod onto the fader body
 - 2) Insert Track into the fader body
 - 3) Insert slider assembly onto guide rod and into the fader body
 - 4) Lubricate the guide rod by placing one small drop of silicon oil, using a cocktail stick, either side of the slider assembly. Move the slider from end to end in order to disperse the oil evenly. Carefully wipe away any excess oil using a tissue or cloth.
 - 5) Insert the dust cover, damping washer and slide the track into fader body
 - 6) Secure the remaining end block ensuring track wires are not pinched.
- 3.6 Once assembled, move the slider from end to end and ensure operation is smooth.
- 3.7 Re-assemble into your mixer.

