

1: Plugging in a Microphone



Plug in microphone into central input in front of the stage

Plug cable labeled "Mic 2" into the mixer

2: Setting the Levels

- Move to the U (unitity gain) position. This knob controls the sensitivity of mic
- Ensure that the button is pressed down
- Set the next 4 knobs to the 12 o'clock position
 - o First knob: High/Trebel frequencise
 - o Second & third knob: Mid Vocal frequencies
 - o Fourth knob: Low/Bass frequencies







the

3: Setting the Volume

- Ensure that purple button is pressed down
- Set the slider to the '0' position and change acording to preference

4: Outputting to Speakers









 Plug in 2 XLR cables of the amplifier

into the mixer and then plug them into Channel A & B

- Plug in the SpeakON Cable label "Main" into The Bridge (Central) plug
- Turn on the amplifier by pressing the power button
- Turn the Channel A & B level knobs all the way to the right

5: Setting main Volume

• Set both of the main volume sliders according to preference

Miscellaneous

- \bullet To plug in an audio device such as a phone/laptop find cable labelled RCA \rightarrow 3.5
- Plug it into the 2TK Input on mixer
- Ensure that "2TK to Mix" button is pressed down



• Turn the "2TK Level" knob to adjust volume







Light

Board

