FLX4 controls

PERFORMANCE MAP · 0.3.4
Any content on any deck
Track / arrangement layout below

TEMPO PICKUP. Requires AP's −1…+1 TempoSlider API. OSC Feedback: Toggle All on, including TempoSlider. Move the fader through AP's reported value to pick up.

SHIFT + LOAD
Left: Deck 1 ↔ 3
Right: Deck 2 ↔ 4

FADERS / KNOBS
Mixer + tempo: pickup
Shift + filter: Filter2

BROWSE / LOAD
Turn: up/down · press: enter
Shift + press: back · LOAD: selected deck

TRANSPORT
SYNC tap: sync · hold: master
CUE: hold · Shift + CUE: Grid Start

Decks: hold that side's Shift and tap LOAD. Left 1↔3 and right 2↔4 switch independently; check the console. Other decks keep playing; mixer/tempo pickup re-arms.

Banks: mode button = normal bank; Shift + mode = alternate bank, then release Shift. Shift + pad = that bank's shifted action. Pads 1–4 top; 5–8 bottom.

HOT CUE
Track / clip cues · arrangement override on page 2

1	2	3	4
5	6	7	8

Shift + pads 1–8: unassigned. Cue jumps without playback are not mapped.

PAD FX · SLIP LOOPS
Hold lengths · bars · tap timing switches

1/32	1/16	1/8	1/4
1/2	— unassigned	D toggle dotted	T toggle triplet

D/T exclusive. Tap active one again for straight. Timing stays selected per deck.

BEAT JUMP
Fixed sizes · all amounts in beats

−1	+1	−2	+2
−4	+4	−8	+8

Hold Shift: −16,+16,−32,+32 / −64,+64,−128,+128. No range cycling.

SAMPLER · LANES
Sampler decks only · selection, not sample hits

1	2	3	4
5	6	7	8

Select a lane, then choose a step bank. Step editing is on page 2.

SHIFT + HOT CUE
Pitch / formant · track pitch needs P on

−12 pitch	−1 pitch	+1 pitch	+12 pitch
RESET pitch	− formant	RESET formant	+ formant

Formant Mode must be Manual. Formant pads unavailable on clips.

SHIFT + PAD FX
Loop movement / length tools

−1 beat	+1 beat	−1 bar	+1 bar
−4 bars	+4 bars	IN halve*	OUT double*

*Halve/double while looping; otherwise sets loop start/end.

SHIFT + BEAT JUMP
Deck tools · sampler override on page 2

½ hold speed	×2 hold speed	REV hold	GRID start
EARLY hold	LATE hold	RESET phase	1× normal speed

Avoid overlapping speed holds. Releases clear the held switch, not a saved prior state.

SHIFT + SAMPLER
Navigation / locks · sampler override on page 2

− zoom	+ zoom	PREV marker page	NEXT marker page
ON slip	OFF slip	ON P / key lock	OFF P / key lock

Marker pages: arrangements only. Switch pads set an explicit state.

No hidden jump range. Shift + a mode button selects a bank; holding Shift + a pad is a different gesture. Each deck remembers its bank.

Watch the console. It shows LEFT / RIGHT deck, player type, bank and selected repeat timing. Unsupported type-specific controls are blocked, not guessed.

Content-aware control

No fixed deck roles
AP PlayerType feedback selects the layout

Arrangement → marker pages

HOT CUE · AUTOMATIC ARRANGEMENT LAYOUT

1 marker	2 marker	3 marker	4 marker
5 marker	GRID start	PREV page	NEXT page

Five visible markers, then paging. Shift + pads 1–8 are unassigned.

Clip → documented routes only

PLAY, CUE, Grid Start, hot cues, pitch and phase are translated to AP's Clip routes. Hot cues are taps, not held previews.

Clip looping exists in AP, but the published Clip/Loop route means **restart at end**. It is not substituted for the track loop control. Unsupported slip/jump/formant/speed controls remain blocked.

Slip loops → one owner per deck

1. Tap D or T to select timing; tap the active one again for straight.
2. Keep holding pad A; press and hold pad B to hear B's repeat.
3. Release B while still holding A to return to A's repeat.
4. Release the final length: stop loop; keep the timing selected.

Timing starts straight and stays selected per deck. D/T changes during a hold retrigger the active repeat. Mouse D/T edits are not tracked; graceful exit clears D/T. Resuming a loop does not promise to preserve its old region.

Sampler → fixed 16-step editing

SAMPLER: pads select lanes 1–8. These do not trigger samples.

SHIFT + BEAT JUMP
Steps 1–8

1	2	3	4
5	6	7	8

SHIFT + SAMPLER
Steps 9–16

9	10	11	12
13	14	15	16

Release Shift after selecting the bank.
Pad = step ON. Hold Shift + pad = step OFF.

Steps target AP's currently selected lane. Switch to SAMPLER to choose another lane, then return to the step bank. No cycling page, guessed toggle state or extra feedback requirement.

Save in AP to retain the pattern. No pad step-state LEDs, velocity editing, lane mute or direct sample hits are assigned.

Deck selection → two sides, four decks

LEFT: DECK 1 ↔ 3
Left Shift + left LOAD

RIGHT: DECK 2 ↔ 4
Right Shift + right LOAD

Hold that side's Shift, tap LOAD, then release Shift. The sides switch independently; startup/restart selects **1 / 2**.

- **Check the console** for the selected deck. Mode lights show the bank, not the deck number.
- **Controls follow selection:** transport, pads, main mixer channel, headphone CUE, LEDs/meter and ordinary LOAD.
- **Other decks keep playing.** Selection does not load, stop, sync or take master. Each deck retains its bank and repeat timing.
- **Pickup re-arms:** mixer and tempo controls wait until hardware reaches AP's reported position. Missing feedback blocks pickup.

Shift + mode selects a bank, not a deck. In AP: four-deck view; FLX4 MIDI input off; OSC input 9090; feedback 127.0.0.1:9096, 30 Hz, Toggle All checked. See README for setup.

Known boundaries: routes may require visible controls in AP. No jog/scratch, crossfader, FX, learned cue-preview mappings or arrangement-internal mixing. Stop/restart after an AP restart or uncertain state. Ctrl+C attempts graceful releases; UDP loss and force-kills cannot guarantee them.