

Dixell XW60K — Modbus RTU Register & Parameter Map

Firmware v1.1

Quelle: XW60K_002C000B0002.xw5 | **9600 8N1** | Protokoll: **Modbus RTU** | Slave-ID: konfigurierbar

Firmware-spezifisch: Setpoint-Schreibadresse 0x035E gilt nur für v1.1. SetPoint R (0x0600) ist versionsunabhängig. Parameter-Basisadresse 0x0400 gilt für alle XWEB-500-Versionen (v1.1–v14.7).

Teil 1 — Live-Register (Messwerte, Status, Sollwert)

Messwerte

FC	Adresse	Dez.	Name	Einheit	Skalierung	Typ	R/W	Hinweis
FC03	0x0108	264	Probe 1	°C	×0.1	INT16	R	
FC03	0x0109	265	Probe 2	°C	×0.1	INT16	R	
FC03	0x010A	266	Probe 3	°C	×0.1	INT16	R	
FC03	0x0100	256	Probe R	°C	×0.1	INT16	R	
FC03	0x0108	264	Probe 1-I	°C	×0.1	INT16	R	
FC03	0x0109	265	Probe 2-I	°C	×0.1	INT16	R	
FC03	0x010A	266	Probe 3-I	°C	×0.1	INT16	R	
FC03	0x0100	256	Probe R-I	°C	×0.1	INT16	R	
FC03	0x0600	1536	Set Point R	°C	×0.1	INT16	R	
FC03	0x0600	1536	Set Point R-I	°C	×0.1	INT16	R	
FC03	0x010B	267	Probe 4	°C	×0.1	INT16	R	
FC03	0x010B	267	Probe 4 -I	°C	×0.1	INT16	R	

Sollwert

FC	Adresse	Dez.	Name	Einheit	Skalierung	Typ	R/W	Hinweis
FC03	0x0600	1536	Set Point R (aktiv)	°C	×0.1	INT16	R	Immer gleich, alle Versionen
FC03	0x035E	862	Set Point	°C	×0.1	INT16	R/W	Schreiben: FC16, Wert ×10
FC03	0x035E	862	Set Point	°C	×0.1	INT16	R/W	Schreiben: FC16, Wert ×10
FC03	0x035E	862	Set Point-F	°C	×0.1	INT16	R/W	Schreiben: FC16, Wert ×10

Status / Alarme

FC	Adresse	Dez.	Name	Einheit	Skalierung	Typ	R/W	Hinweis
FC01	0x0216	534	On/Off Out	bit	0x0100	BOOL	R	(reg & 0x0100) != 0
FC01	0x0216	534	Defrost	bit	0x0200	BOOL	R	(reg & 0x0200) != 0
FC01	0x0216	534	Defrost 2	bit	0x0400	BOOL	R	(reg & 0x0400) != 0
FC01	0x0216	534	Alarm	bit	0x0800	BOOL	R	(reg & 0x0800) != 0
FC01	0x0216	534	Light	bit	0x1000	BOOL	R	(reg & 0x1000) != 0
FC01	0x0216	534	Fan	bit	0x2000	BOOL	R	(reg & 0x2000) != 0
FC01	0x0216	534	Aux	bit	0x4000	BOOL	R	(reg & 0x4000) != 0
FC01	0x0216	534	Generic out 1	bit	0x8000	BOOL	R	(reg & 0x8000) != 0
FC01	0x0216	534	Compressor	bit	0x0001	BOOL	R	(reg & 0x0001) != 0
FC01	0x0216	534	Compressor 2	bit	0x0002	BOOL	R	(reg & 0x0002) != 0
FC01	0x0200	512	On	bit	0x0001	BOOL	R	(reg & 0x0001) != 0
FC01	0x0200	512	Defrost	bit	0x0002	BOOL	R	(reg & 0x0002) != 0
FC01	0x0200	512	Fast Freezing	bit	0x0004	BOOL	R	(reg & 0x0004) != 0
FC01	0x0200	512	Keyboard	bit	0x0008	BOOL	R	(reg & 0x0008) != 0
FC01	0x0200	512	Buzzer	bit	0x0010	BOOL	R	(reg & 0x0010) != 0
FC01	0x0200	512	DI	bit	0x0080	BOOL	R	(reg & 0x0080) != 0
FC01	0x0208	520	Error Pb1	bit	0x0100	BOOL	R	(reg & 0x0100) != 0
FC01	0x0208	520	Error Pb2	bit	0x0200	BOOL	R	(reg & 0x0200) != 0
FC01	0x0208	520	Error Pb3	bit	0x0400	BOOL	R	(reg & 0x0400) != 0
FC01	0x0208	520	Error Pb4	bit	0x0800	BOOL	R	(reg & 0x0800) != 0
FC01	0x0208	520	High Value Pb1	bit	0x1000	BOOL	R	(reg & 0x1000) != 0
FC01	0x0208	520	Low Value Pb1	bit	0x2000	BOOL	R	(reg & 0x2000) != 0
FC01	0x0208	520	High Value Pb2	bit	0x4000	BOOL	R	(reg & 0x4000) != 0

FC01	0x0208	520	Low Value Pb2	bit	0x8000	BOOL	R	(reg & 0x8000) != 0
FC01	0x0208	520	External Alarm	bit	0x0001	BOOL	R	(reg & 0x0001) != 0
FC01	0x0208	520	Severe Alarm	bit	0x0002	BOOL	R	(reg & 0x0002) != 0
FC01	0x0208	520	Open Door	bit	0x0004	BOOL	R	(reg & 0x0004) != 0
FC01	0x0208	520	EEPROM Failure	bit	0x0008	BOOL	R	(reg & 0x0008) != 0

Teil 2 — Parameter (FC03 lesen / FC16 schreiben, Basis 0x0400)

Alle 87 Parameter sind R/W. Skalierung: Temperaturwerte $\times 0.1$, Zeitwerte in Minuten (soweit nicht anders angegeben).

Regulation

Idx	Adresse	Dez.	Code	Beschreibung
000	0x0400	1024	SEt	Set point
001	0x0401	1025	Hy	Differential
002	0x0402	1026	LS	Minimum set point
003	0x0403	1027	US	Maximum set point
004	0x0404	1028	ot	Thermostat probe calibration
005	0x0405	1029	P2P	Evaporator probe presence
006	0x0406	1030	oE	Evaporator probe calibration
007	0x0407	1031	P3P	Third probe presence
008	0x0408	1032	o3	Third probe calibration
009	0x0409	1033	P4P	Fourth probe presence
010	0x040A	1034	o4	Fourth probe calibration
011	0x040B	1035	Ods	Outputs delay at start up
012	0x040C	1036	Ac	Anti-short cycle delay
013	0x040D	1037	Ac1	Second compressor start delay
014	0x040E	1038	tMC	MAX time compressor ON
015	0x040F	1039	r t r	P1-P2 percentage for regulation
016	0x0410	1040	CCt	Continuous cycle duration
017	0x0411	1041	CCS	Set point for continuous cycle
018	0x0412	1042	Con	Compressor ON time with faulty probe
019	0x0413	1043	CoF	Compressor OFF time with faulty probe
020	0x0414	1044	CH	Kind of action: heating cooling
049	0x0431	1073	ACH	Kind of action for auxiliary relay
050	0x0432	1074	SAA	Set point for auxiliary relay
051	0x0433	1075	SHy	Differential for auxiliary relay
052	0x0434	1076	ArP	Probe selection for auxiliary relay
053	0x0435	1077	Sdd	Auxiliary relay switched off during defrost
082	0x0452	1106	HES	Differential for Energy Saving
083	0x0453	1107	pbC	Kind of probe

Display

Idx	Adresse	Dez.	Code	Beschreibung
021	0x0415	1045	CF	Temperature measurement unit
022	0x0416	1046	r ES	Resolution
023	0x0417	1047	Lod	Probe displayed
024	0x0418	1048	Red	X-REP display
025	0x0419	1049	dLy	Display temperature delay
026	0x041A	1050	d t r	P1-P2 percentage for display

Defrost

Idx	Adresse	Dez.	Code	Beschreibung
027	0x041B	1051	t dF	Defrost type
028	0x041C	1052	dFP	Probe selection for first defrost
029	0x041D	1053	dSP	Probe selection for second defrost
030	0x041E	1054	d t E	Defrost termination temperature first defrost
031	0x041F	1055	d t S	Defrost termination temperature second defrost
032	0x0420	1056	I dF	Interval between defrost cycles
033	0x0421	1057	MdF	(Maximum) length for first defrost
034	0x0422	1058	MdS	(Maximum) length for second defrost

035	0x0423	1059	dSd	Start defrost delay
036	0x0424	1060	dFd	Displaying during defrost
037	0x0425	1061	dAd	MAX display delay after defrost
038	0x0426	1062	Fdt	Draining time
039	0x0427	1063	dPo	First defrost after start-up
040	0x0428	1064	dAF	Defrost delay after fast freezing

Fans

Idx	Adresse	Dez.	Code	Beschreibung
041	0x0429	1065	Fnc	Fan operating mode
042	0x042A	1066	Fnd	Fan delay after defrost
043	0x042B	1067	FCt	Differential of temperature for forced activation of fans
044	0x042C	1068	FS t	Fan stop temperature
045	0x042D	1069	Fon	Fan on time with compressor off
046	0x042E	1070	FoF	Fan off time with compressor off
047	0x042F	1071	FAP	Probe selection for fan
048	0x0430	1072	FSU	Kind of action of fan

Alarms

Idx	Adresse	Dez.	Code	Beschreibung
054	0x0436	1078	ALP	Probe selection for temperature alarms
055	0x0437	1079	ALC	Temperature alarms configuration
056	0x0438	1080	ALU	Maximum temperature alarm
057	0x0439	1081	ALL	Minimum temperature alarm
058	0x043A	1082	AFH	Differential for temperature alarm recovery
059	0x043B	1083	ALd	Temperature alarm delay
060	0x043C	1084	dAo	Delay of temperature alarm at start up
061	0x043D	1085	AP2	Probe selection for condenser temperature alarms
062	0x043E	1086	AL2	Condenser low temperature alarm
063	0x043F	1087	AU2	Condenser high temperature alarm
064	0x0440	1088	AH2	Differ. for condenser temp. alarm recovery
065	0x0441	1089	Ad2	Condenser temperature alarm delay
066	0x0442	1090	dA2	Delay of condenser temper. alarm at start up
067	0x0443	1091	bLL	Compressor off for condenser low temperature alarm
068	0x0444	1092	AC2	Compressor off for condenser high temperature alarm
069	0x0445	1093	tbA	Alarm relay switched off by pushing a key

Digital Input

Idx	Adresse	Dez.	Code	Beschreibung
076	0x044C	1100	i1P	Digital input polarity
077	0x044D	1101	i1F	Digital input configuration
078	0x044E	1102	d i d	Digital input alarm delay
079	0x044F	1103	nPS	Number of activation of pressure switch
080	0x0450	1104	0dc	Compress and fan status when open door
081	0x0451	1105	r r d	Regulation restart with door open alarm

Configuration

Idx	Adresse	Dez.	Code	Beschreibung
072	0x0448	1096	oA1	First relay configuration
073	0x0449	1097	oA2	Second relay configuration
074	0x044A	1098	oA3	Third relay configuration
075	0x044B	1099	AOP	Alarm relay polarity
084	0x0454	1108	onF	On/off key configuration
085	0x0455	1109	LPC	Light key configuration
086	0x0456	1110	dPC	Defrost key configuration

Other1

Idx	Adresse	Dez.	Code	Beschreibung
070	0x0446	1094	nP1	Min. display time for msg ENG probe P3
071	0x0447	1095	nP2	Min. display time for msg ENG probe P4