# Service

# HiPath 4000 Troubleshooting

Service Manual

A31003-H3130-S100-4-7620

www.siemens.com/enterprise



Copyright © Siemens Enterprise Communications GmbH & Co. KG 2008 Hofmannstr. 51, D-81359 München

Reference No.: A31003-H3130-S100-4-7620

The information provided in this document contains merely general descriptions or characteristics of performance which in case of actual use do not always apply as described or which may change as a result of further development of the products. An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract. Subject to availability. Right of modification reserved. The trademarks used are owned by Siemens Enterprise Communications GmbH & Co. KG or their respective owners.

A9015

A9000 -- F1000 -- F2000 -- F3000 -- F4000 -- F5000 -- F6000 -- F7000 -- F8000 A9000 A9001 A9002 A9003 A9004 A9005 A9006 A9007 A9008 A9009 A9010 A9011 A9012 A9013 A9014

# A9000 NMCALARM SET ALARM LOW for SP300-V3.1 MINOR ALARM ON from SP300-V3.2

*Type:* Service-Specific (Format 2C)

Short text: Alarm Message

Cause: Low-priority alarm is set.

Action: Save error message data and contact your next level of support. The device class affected is output in the DEV-CLASS line. In addition, the individual alarm affected is output in the line **ALARM-NAME**:. From SP300-V3.4/R6.3 the device class affected is output in the ALARM-CLASS line.

Interpretation of auxiliary data: The ALARM NAME concerned is output as clear text.

# A9001 NMCALARM SET ALARM HIGH *for SP300-V3.1* MAJOR ALARM ON *from SP300-V3.2*

*Type:* Service-Specific (Format 2C)

Short text: Alarm Message

Cause: High-priority alarm is set.

**Action:** The device class affected is output in the DEV-CLASS line.

Action: Save error message data and contact your next level of support. The device class affected is output in the DEV-CLASS line. In addition, the individual alarm affected is output in the line **ALARM-NAME**:. From SP300-V3.4/R6.3 the device class affected is output in the ALARM-CLASS line.

Interpretation of auxiliary data: The ALARM NAME concerned is output as clear text.

# A9002 NMCALARM RESET ALARM LOW for SP300-V3.1 MINOR ALARM OFF from SP300-V3.2

*Type:* Service-Specific (Format 2C)

Short text: Alarm Message

Cause: Low-priority alarm has been reset.

**Action:** Positive acknowledgment of A9000, no action necessary.

# A9003 NMCALARM RESET ALARM HIGH *for SP300-V3.1* MAJOR ALARM OFF *from SP300-V3.2*

*Type:* Service-Specific (Format 2C)

**Short text:** Alarm Message

Cause: High-priority alarm has been reset.

**Action:** Positive acknowledgment of A9001, no action necessary.

#### A9004 NMCALARM

#### **ALARM MIRROR up to SP300-V3.3**

Type: Service-Specific (Format 2C)
Short text: Alarm mirror for all device classes

Cause: Alarm mirror alarm for all device classes (DEV CLASS) of the system processor concerned. The DEV CLASS line shows the sum of the individual alarms set. No

longer in use, as of SP300-V3.4.

Action: Save error message data and contact your next level of support. This summary alarm message cannot be requested via external command, but is output automatically after each functional system unit restart or switchover. Determine reason for functional system unit restart.

#### **NMCALARM**

# PERIOD ALARM MIRROR from SP300-V3.2

*Type:* Service-Specific (Format 2C)

Short text: Alarm Message

Cause: Alarm mirror requested via AMO GRA (from SP300-V3.3) or external NMC/DMS command. The DEV CLASS line shows the sum of the individual alarms set. No longer in use, as of SP300-V3.4/R6.3.

**Action:** Manually requested alarm mirror, no action necessary.

#### **NMCALARM**

# **DEVICE ALARM ON** *from SP300-V3.4/R6.3*

*Type:* Service-Specific (Format 2C)

**Short text:** Alarm message

Cause: The DEVICE ALARM was introduced for monitoring vital system components (e.g. lines). The system reports a failure of the system component(s) being monitored.

Action: Save error message data and contact your next level of support. The

device class affected is output in the ALARM-CLASS line.

# A9007 NMCALARM

# **DEVICE ALARM OFF** *from SP300-V3.4*

*Type:* Service-Specific (Format 2C)

**Short text:** Alarm message

Cause: DEVICE ALARM has been reset.

Action: Positive acknowledgment of A9006, no action necessary.

#### **NMCALARM**

MIRROR: CENTRAL GRP ab SP300-V3.4/R6.3

Type: Service relevant (Format 30)

**Short text:** Alarm messages

Cause: This alarm message is displayed after every module restart or switch. The

alarm message contains the alarm mirror for all central SWU or SM (ADP) alarms.

System reaction:

**Action:** Save error message data and notify your next level of support.

Interpretation of auxiliary data:

Bytes 1 to 8 contain the 64 central alarms.

#### **NMCALARM**

MIRROR: SWU-PER GRP SP300-V3.4/R6.3 and later

*Type:* Service relevant (Format 30)

**Short text:** Alarm messages

Cause: The alarm message is displayed after every module restart or switch. This

alarm message contains the alarm mirror for all SWU periphery alarms.

System reaction:

**Action:** Save error message data and notify your next level of support.

Interpretation of auxiliary data:

Byte 1 - 4 contains the 32 SWU periphery alarms.

#### **NMCALARM**

MIRROR: SWU-LOG GRP from SP300-V3.4

Type: Service-Specific (Format 30)
Short text: Alarm Message (from SP300-V3.4)

Cause: This alarm message is output after each functional system unit restart or

switchover. Alarm mirror for all the logical alarms of the SWU (SWU-LOG).

**Action:** Save error message data and contact your next level of support.

Interpretation of auxiliary data:

11: Byte 1 contains the 8 individual alarms

22: Byte 2 - 65 contains the 512 destination-specific alarms

33: Byte 66 - 73 contains the 64 user-specific alarms

#### A9011 NMCALARM

MIRROR: SM-PER GRP from SP300-V3.4

*Type:* Service-Specific (Format 2C)

**Short text:** Alarm Message

Cause: This alarm message is output after each functional system unit restart or

switchover. Alarm mirror for all the peripheral alarms of the server/ADP (SM-PER).

Action: Save error message data and contact your next level of support.

Interpretation of auxiliary data: Bytes 1 - 3 contain the 24 server periphery alarms

See also: Alarm concept and SM periphery alarm class.

#### **NMCALARM**

PER-MIR: CENTRAL GRP from SP300-V3.4

Type: Service-Specific (Format 2C)
Short text: Alarm Message (from SP300-V3.4)

Cause: Alarm mirror requested via AMO GRA (from SP300-V3.3) or external NMC/DMS command. Alarm mirror for all the central alarms of the SWU (CENTRAL) or server/

ADP.

Action: See NMC Administrator Handbook (A31003-G8014-A100-\*-7635) or AMO

GRA.

Interpretation of auxiliary data: see A9008 and Central alarm class.

#### **NMCALARM**

PER-MIR: SWU-PER GRP from SP300-V3.4

*Type:* Service-Specific (Format 2C)

**Short text:** Alarm Message

Cause: Alarm mirror requested via AMO GRA (from SP300-V3.3) or external NMC/DMS command. Alarm Mirror alarm for all the peripheral alarms of the SWU (**SWU-PER**). Action: See NMC Administrator Handbook (A31003-G8014-A100-\*-7635) or AMO

GRA.

Interpretation of auxiliary data: see A9009 and SWU periphery alarm class.

#### **NMCALARM**

**PER-MIR: SWU-LOG GRP** *from SP300-V3.4 Type:* Service-Specific (Format 2C)

**Short text:** Alarm Message

Cause: Alarm mirror requested via AMO GRA (from SP300-V3.3) or external NMC/DMS command. Alarm mirror for all the logical alarms of the SWU (**SWU-PER**).

Action: See NMC Administrator Handbook (A31003-G8014-A100-\*-7635) or AMO

GRA.

Interpretation of auxiliary data: see A9010 and SWU logical alarm classes.

#### **NMCALARM**

PER-MIR: SM-PER GRP from SP300-V3.4

*Type:* Service-Specific (Format 2C)

**Short text:** Alarm Message

Cause: Alarm mirror requested via AMO GRA (from SP300-V3.3) or external NMC/DMS command. Alarm mirror for all the peripheral alarms of the server/ADP (**SM-PER**). See NMC Administrator Handbook (A31003-G8014-A100-\*-7635) or AMO

GRA.

Interpretation of auxiliary data: see A9011 and SM periphery alarm class.