

Boiler Pressure Fault Resolution Guide Document ID: DOC-2026-IPMS-BOIL Category:
Core Equipment Maintenance

1. Initial Assessment

1. Immediately approach the boiler unit and check the physical pressure gauge reading.
2. Determine if the needle indicates Overpressure (above 15 bar) or Zero/Underpressure (0 bar or below).

2. Scenario A: Overpressure (Exceeds 15 bar)

1. If the pressure exceeds 15 bar, immediately and manually open the safety release valve to vent excess steam.
2. Shut down the main burner from the control panel.
3. Keep the safety valve open until the pressure drops back into the safe operating green zone (typically 5-10 bar).
4. Do not restart the system until the pressure normalizes and the release mechanism is inspected.

3. Scenario B: Zero Pressure or Gauge Malfunction (0 bar or below)

1. Do **NOT** open the safety release valve.
2. Immediately shut down the main burner to prevent dry-firing or catastrophic heat damage to the empty boiler shell.
3. Inspect the pressure sensor wiring and power supply for loose, burnt, or disconnected cables.
4. Check the main water feed line to ensure the boiler is actively receiving water.
5. If the gauge needle is physically bent or pinned below the zero mark, the physical gauge is broken and must be replaced before the system can be safely restarted.