


PARKS

18-INCH WOOD-AND METAL-CUTTING BAND SAW

assembly • operating • repair parts



Pointer, Table Tilt
Pulley, Wood Cutting
Screw, Set, 5/16-18 x 1/2 Soc. Hd.
Belt, V — 1/2" x 46"
Nut, Jam, 1/2-13 Heavy Hex.
Rod, Motor Adjusting

B-70 B-43 B-52 B-16 B-114 9-1646 B-120 B-29 B-29

Description

Part No.

Screw, No. 8 Drive Scale, Table Tilt

Bracket, Motor Mounting 1*Bolt, Carriage 5/16-18 x 3/4 Rod, Mounting Bracket *Collar, 3/8" Pulley, 4 Step Casting, Table Tilt

B-116 B-30 M-111

Key No.	40	41	42	43	44	45	46	47	48	49	20	51	52	53	54	22	26	22	28	59	9	61	62	63	2	65	99	29	89	69	. 70	71	72	73	74	75	16	77	
Description	Saw Blade, 3/8" x 11' (for wood)	Saw Blade, 1/4" x 11' (for metal)	*Screw, Set. 1/4-20 x 1/2 Rd, Hd.	*Washer, 1/2	Bearing, Ball	Fitting, 1/8 Alemite	Wheel, Upper	Band, Rubber Wheel	Shaft, Upper Wheel	Support, Wheel Pivot	Pin, Hinge	*Screw, Set, 3/8-16 x 3/8 Soc. Hd.	*Screw, Set, 1/4-20 x 1/4 Soc. Hd.	Casting, Wheel Slide	Spring	Nut, Tension	*Collar, 1/2"	Pointer	*Lockwasher, 3/8"	*Bolt, 3/8-16 x 1-1/4 Hex. Hd.	Bar, Slide	Frame, Wheel Slide	Knob, Wheel Tilt Adjusting	Frame	Knob, Adjusting Bar	Knob, Blade Tensioning (w/Stud)	"Screw, 1/4-20 x 1-3/4 Rd. Hd.	*Nut, 1/4-20	*Bolt, 3/8-16 x 1-3/4 Hex. Hd.	t *Washer, 3/8"	Nut, Clamping	Saw Guide Assy.	Bracket, Saw Guide	Guard, Blade	Bar, Adjusting	Block, Adjusting Bar	Shaft, Guide Bracket	Guide, Blade - Wood-Cutting	Guide, Blade - Metal-Cutting
Part No.	8-38	M-108	B-51	B-61	B-32	B-40	B-1	B-39	B-18	8-8	B-19	B-49	B-50	B-7	B-36	B-9	B-47	B-208	99-B	8-54	M-28	B-74	8-15	M-3	B-14	B-12	B-28	B-69	B-56	B-68	B-5	BS-187	B-10	B-33	B-20	B-11	B-27	B-34	M-107
Key No.	-	2	e	4	LO.	9	7	8	6	10	=	12	13	14	15	16	17	18	19	20	21	22	23	24	52	56	27	28	29	30	31	32	33	ਲ	32	36	37	38	39

opio ippiit opiit			, ,
Knob, Wheel Tilt Adjusting	62	M-21	Shaft, Jack
Frame	63	B-53	Oiler
Knob, Adjusting Bar	29	M-23	Housing, Jack Shaft
Knob, Blade Tensioning (w/Stud)	65	B-42	Cleaner, Blade
*Screw, 1/4-20 x 1-3/4 Rd, Hd.	99	B-122	Screw, 10-32 x 5/8 Ro
*Nut. 1/4-20	29	B-2	Wheel, Lower
*Bolt, 3/8-16 x 1-3/4 Hex. Hd.	89	B-71	*Screw, Set, 3/8-16 x 3
t*Washer, 3/8"	69	B-119	Screw, Hex. Hd.
Nut, Clamping	- 70	B-67	Knob, Bottom Rear D
Saw Guide Assy.	71	B-118	Scale
Bracket, Saw Guide	72	B-46	Knob, Upper Door
Guard, Blade	73	M-A	Table
Bar, Adjusting	74	M-35	Insert, Table
Block, Adjusting Bar	75	M-17	Bar, Miter Gauge
Shaft, Guide Bracket	92	9-8	Head, Miter Gauge
Guide, Blade - Wood-Cutting	77	841	Knob, Miter Gauge
Guide, Blade - Metal-Cutting			11

5/8 Rd. Hd. Mach.

Bearing, Ball fNut, Jam, 5/16-18 Heavy Hex. *Key, No. 9 Woodruff

f Motor,

Spring Bushing Knob, Table Tilt Locking Nut, Special Lock

B-75 B-37 B-48 B-13 M-99 B-31 B-121 B-72

16 x 3/4 Soc. Hd.

Rear Door

*Standard Hardware Item - May be Purchased Locally.

repair parts

FIGURE 2 GEAR BOX ASSEMBLY

*Standard Hardware Item — May be Purchased Locally.




FIGURE 3 SWITCH ASSEMBLY

Key No.	Part No.	Description
-	B-123	Switch 220 V
2	B-124	*Screw, 1/4-20 x 1/2 Rd. Hd. Mach.
3	8-125	Grip, Cord
v	B-126	Cable, 3 Wire
10	B-127	Nut, Lock

*Standard Hardware Item - May be Purchased Locally.

PARTS LIST FOR WOOD AND METALCUTTING BAND SAW

FIGURE 4 FOOT PEDAL BRAKE ASSEMBLY

Description	*Screw, Set, 1/4-20 x 1/4 Soc. Hd.	Arm, Brace	Contact, Brake Adj. Nylon	*Screw, Cap, 5/16-18 x 2-1/4 Hex. Hd.	*Screw, Cap, 5/16-18 x 1 Hex. Hd.	*Screw, Cap, 1/4-20 x 3/4 Soc. Hd.	Block, Stop	*Washer, 5/16" Flat	*Screw, Cap, 5/16-18 x 5/8 Hex. Hd.	*Screw, Cap, 3/8-16 x 1 Hex. Hd.	Assy. Unit, Welded	Angle, 2 x 2 x 1/4 Foot Pedal	Nut, Jam, 3/8-16 Heavy Hex.	*Washer, 3/8" Flat	Nut, Stp, 5/16-18 Elastic	Shaft, 3/4 x 1/2 Vertical Control	Bracket, Pivot
Part No.	8-128	B-129	B-130	B-131	B-132	B-133	B-134	B-135	B-136	B-137	B-138	B-139	B-142	B-141	B-140	B-143	B-144
Key No.	-	2	8	4	2	9	7	8	6	10	=	12	13	14	15	16	17

*Standard Hardware Item - May be Purchased Locally.

