
X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS

SOUND/SPEECH ASSY. (A6), COMPONENT LOCATION



SOUND/SPEECH ASSY. (A6), PARTS LIST

REFERENCE	DESCRIPTION	PART NUMBER	REFERENCE	DESCRIPTION	PART NUMBER
C1, C2 C4, C13 C15, C16, C19 C20, C21, C23 C25, C26 C28-C30, C33 C42, C44 C31-C32 C37 C3, C38-C41 C14, C24 C22 C27 C36 C45, C46 C47 CR1 CR2 Q1, Q3 Q2 R1, R4, R5 R11, R12 R2, R3 R6, R13 R6A, R7, R23-R30 R8, R8A, R14 R6B R9	Capacitor, .047UF, 25V Capacitor, .047UF, 25V Capacitor, 4.7UF, 35V Capacitor, 47UF, 50V Capacitor, 100PF Capacitor, 100PF Capacitor, 300PF Capacitor, 1UF, 50V Capacitor, 470UF, 35V Capacitor, 31UF, 50V Capacitor, .01 UF, 100V Diode, 1N4 148 Diode, 1N4 148 Diode, 1N4 148 Diode, 1N4 148 Potention, .01 UF, 100V Resistor, .01 UF, 100V Resistor, .01 UF, 100V Diode, 1N4 148 Capacitor, .01 UF, 100V Capacitor, .01 UF, 50V Capacitor, .01 UF, 50V Capacitor, .01 UF, 50V Capacitor, .02 UF, .0	MA-2 16 XO-248 XO-222 XO-29 1 XO-2 10 XO-223 XO-217 XO-284 XO-277 XO-202 XO-261 XO-269 XO-320 XO-320 XO-32 1 XO-19 XO-18 XO-18 XO-18 XO-18 XO-18 XO-27	R 15, R 16 R 18, R2 1 R22 R31 RP1, RP2 SB1 SW1 U1 U2 U3 U4 U5, U6 U7-U9, U11, U18 U10 U12 U13 U14 U15 U16 U17 U19, 20 U21, U22 U23 U24 U25 Y1	Potentiometer, 10K ohm Resistor, 100K ohm, 5%, 1/4W Resistor, 2K ohm, 5%, 1/4W Resistor, 2K ohm, 5%, 1/4W Resistor, Olip Switch, Dip Switch, Dip Switch, Momentary Pushbutton IC, 74 14 IC, SN74LS74N CPU, R6502-13 IC, SN74LS138N EPROM, 27 16 IC, SN74LS75 IC, SN74LS02N IC, SN74LS02N IC, SN74CS02N IC, Inverter, SN74LS05N Voice Chip, SC0 1 RRIOT, R6532-18 IC, SN74LS30N Converter, PMI, 1408A-6P IC, LM74 1CP IC, LM379S IC, Dual Comparitor, LM 193 Inverter, 7404 Crystal, 3.579545MHZ Socket 22 Pin Dip Socket 24 Pin (2)	XO-109 XO-45 XO-189 XO-168 XO-505 XO-515 XO-397 XO-434 XO-360 XO-437 PR-53 XO-394 XO-428 XO-384 XO-411 XO468 XO-411 XO468 XO-361 XO-4 18 XO-393 XO-395 XO-396 XO-492 XO-402 XO-456 XO-456 XO-457 XO-529 XO-530
R 10	Resistor, 1.5K ohm, 5%, ¼W	XO-20		, , ,	

X. WIRING AND SCHE

