



HOW TO PLAY "ZOAR"

- The year is 2020 AD
- "ZOAR" is one of the last survivors of Federation defenses. HE is the best pilot in the swiftist and most deadly air-craft in a future world.
- "ZOAR" is flying an aircraft that will give you 3-dinensional play. The joy stick moves the craft from left to right and raises or lowers altitude.
- The LOWER ZOAR flies the faster he attacks.
- The fire button will shoot rockets at the Dynasty airships. They, too, are changing altitude.
- The bomb button will destroy Dynasty vessels and ground installations.
- TOUCH landing strip for extra points!
- USE accelerate button for additional speed.

Large Red Airship--500 points

Small Airship --300 points

PT Boats -- 80 points

Submarine --100 points

Destroyer --100 points

Aircraft Carrier --500 points

Control Tower -- 50 points

Missile Launcher -- 80 points

Fuel Dump --150 points

Missile Silo --300 points

I. POWER SUPPLY

+5V 5A

+12V 1A (INCLUSIVE OF AUDIO AMP.)

II. CRT MONITOR

1) COLOR SIGNAL R.G.B. SEPARATION

BALCK 0 - +2V

IMAGE SIGNAL +2.5V - +4V

2) SYNCHRONIZE SIGNAL COMPOSITE


0 0 - 0.5V

1 +3V - +5V

3) SCREEN IMAGE SIZE

IMAGE CAN BE SHRUNK BOTH HORIZONTALLY & VERTICALLY
BY 10%. ADJUST MONITOR TO WIDEN THE SCREEN IMAGE.


III. VOLUME CONTROL



IV. EXAMPLE OF STANDARD CONNECTION

Terminal Nos.


1) TWO(2) COIN SWITCHES CAN BE INSTALLED.




2) MONITOR CONNECTION

MONITOR IN-PUT COMPOSITE SIGNALS - HORIZ/VERT ON +5V
CIRCUIT CAN BE CONNECTED.

CIRCUIT DIAGRAM OF EACH SIGNAL SHOWN BELOW.




CONTROL PANEL



- * be certain that dip switch settings are correctly positioned since there is an unused option to eliminate the accelerate button and separate air-to-air /air-to-ground buttons.


8 way stick		
LEVER	PLAYERS	CRAFT
left		left
right		right
up		low
down		high

- * FOR COCKTAIL TABLE: up/down movement is reversed when #7 key on dip switch #1 is turned off.
- * Accelerate button allows swifter left/right and high/low movement.
- * air-to-air button shoots opposing airplanes
- * air-to-ground button bombs ships & ground targets.






DIP SWITCH SETTINGS

DIP SWITCH I					DIP SWITCH II			
1 COIN SELECTOR 1					1	OFF	ON	ACCREDITED AIRCRAFT
I OFF ON OFF ON					3		5	
2 OFF OFF ON ON								
Coin 1 1 1 2						BONUS POINTS		
Credit 1 2 3 1					2	2	OFF ON OFF ON	
3 COIN SELECTOR 2					3	5000 PTS	10000 PTS	15000 PTS
3 OFF ON OFF ON								20000 PTS
4 OFF OFF ON ON								
Coin 1 1 1 2						OFF	ON	
Credit 1 2 3 1					4	EASY	DIFFICULT	
5 OFF DON'T CHANGE					5		ON	
							PANEL B	
6 OFF DON'T CHANGE					6	OFF	DON'T CHANGE	
7 OFF ON CONTROL PANEL					7	OFF	DON'T CHANGE	
TABLE UPRIGHT								
8 OFF ON SCREEN					8	OFF	DON'T CHANGE	
TABLE UPRIGHT								



TA GO ELECTRONICS
ZOAR HARNESS
T. DELGADO
© 1982 DATA EAST USA, INC






©1982 Data East USA, Inc.

DSPP-10
10512

DSR-10
10412




記事	記号	担当	年月日	改訂個所	特号	器品、圖面番号	名稱	仕様、材質	備註
材質		處理			公差		名稱 C X - 9 D S P - 10		1 12




ZOAR
©1982 Data East USA Inc

DSP-102



三





開通番号
仕様名
記事





ZOAR
©1982 DATA EAST USA, Inc.

DSP-10
4.612













ZOAR
©1982 DATA EAST USA, INC
Dsp-10 6512






ZOAR
©1982 DATA EAST USA, INC.
DSP-10 9 of 12




記事	件號	年月日	改打個所	所用 器具、圖面書號	名稱	種類	仕樣、材質
財質			處理	公差	名稱 CK-9 D S P - 10		



ZOAR
©1982 Data East USA, Inc.
DSP-10
10612




記事		記事	記事	記事	記事	記事	記事	記事	記事	記事	記事
年月日	年月日	改訂箇所	改訂箇所	符号	部品、回路番号	名稱	仕様	材質	年月日	年月日	年月日
58.3.8	58.3.8	58.3.8	58.3.8	○	CX-9	CX-9	○	○	DS-P-10	DS-P-10	DS-P-10
58.3.8	58.3.8	58.3.8	58.3.8	○	K-0495	K-0495	○	○	10	10	10






DSR-16
© 1982 DRAPEAU-LEADER
ZODIAC



記号	担当	年月日	改訂個所	符号	部品、圖面番号	名稱	規格	仕様、材料
材質			處理	公差		名称	C X - 9	
小括	機器	機器	機器	規格	規格	規格	D S P - 10	






© 1992 E&ESN USA, Inc.

B61-7 Component List

The logo for Tango Electronics features the word "Tango" in a bold, italicized, black font. A horizontal line extends from the top of the letter "T" across the width of the word. To the right of "Tango", the word "ELECTRONICS" is written in a smaller, all-caps, black font.


Copyright 2014 Ems + USA, Inc.

B61-7 Component




卷之三

四
六




記事		部品、前面番号	名 称	仕様、材質	
記号	相当年月日			単位	規格
材質		公差	名称 C X-9 B S I - '7	mm	K = 104.96 5





~~ZOAR~~
© 1982 DATA EAST USA, INC
DSI-7 3015






© Data ZONE USA, Inc

卷之三



4.4.5



圖面番号
名稱



20A
© 1982 Data East USA Inc.
BSI-7
5615



品名	担当	年月日	改訂箇所	行番	部品、図面番号	名稱	基材	仕様	材質
BSI-7	6/13	87.7.13			CX-9		BSI-7		
					K-10496				