RAIDEN 2 OPERATOR'S MANUAL

SEIBU KAIHATSU INC.,

雷電2 取扱説明書

●仕 様

Oエッジコネクター EDGE CONNECTOR

| SOLDER SIDE(半田面) | NO | NO | PARTS SIDE(部品面) GND | | | | |
|------------------|-----|------|------------------------|--|--|--|--|
| GND | Α | 1 | | | | | |
| GND | В | 2 | GND | | | | |
| +5V | С | 3 | +5V | | | | |
| +5V | D | 4 | +5V | | | | |
| | Ε | 5 | | | | | |
| +12V | F | 6 | +12V | | | | |
| | Н | 7 | | | | | |
| COIN COUNTER 2 | J | 8 | COIN COUNTER 1 | | | | |
| | K | 9 | | | | | |
| SPEAKER(-) | L | 10 | SPEAKER(+) | | | | |
| | М | 11 | | | | | |
| VIDEO GREEN | N | 12 | VIDEO RED | | | | |
| VIDEO SYNC | Р | 13 | VIDEO BLUE | | | | |
| SERVICE SW | R | 14 | VIDEO GND | | | | |
| | S | 15 | | | | | |
| COIN IN 2 | Т | 16 | COIN IN 1 | | | | |
| 2P START | U | 17 | 1P START | | | | |
| 2P UP | ٧ | 18 | 1P UP | | | | |
| 2P DOWN . | W | 19 | 1P DOWN | | | | |
| 2P LEFT | Х | 20 | 1P LEFT | | | | |
| 2P RIGHT | Υ | 21 | 1P RIGHT | | | | |
| 2P PUSH 1 | Z | 22 | 1P PUSH 1 | | | | |
| 2P PUSH 2 | а | 23 | 1P PUSH 2 | | | | |
| | b | 24 | 0 | | | | |
| | С | 25 | | | | | |
| | d | 26 | | | | | |
| GND | . е | 27 | GND | | | | |
| GND | f | - 28 | GND | | | | |

○JAMMA規格 JAMMA STANDARD

○夕テ画面 VERTICAL SCREEN

○コントロールパネル CONTROL PANEL

8Way Joystick

PUSH 1

PUSH 2

SHOT (ショット)

BOMB (ボンバー)





〇電源 POWER SOURCE

+5V5A

+12V ·····1A

(PARTS SIDE)

VOL

JAMMA

DIP 2

DIP 1

雷電2 DIPSW表

DIP-SW 1

| | | | | | | | | - | |
|--|--|-----|-----|------------|-----------|-----------|------------|-----------|-----------|
| | 1/1 | OFF | OFF | OFF | | | | | |
| | 1/2 | ON | OFF | OFF | | | | | |
| | 1/3 | OFF | ON | OFF | | | | | |
| COIN 1 | 1/4 | OFF | OFF | ON | | | | | |
| (COIN/CREDIT) | 2/1 | ON | ON | OFF | | | | | |
| | 3/1 | ON | OFF | ON | | | | | |
| | 4/1 | OFF | ON | ON | | | | | |
| | 1/1 | | | | OFF | OFF | OFF | | |
| | 1/2 | , , | | | ON | OFF | OFF | | |
| | 1/3 | | | | OFF | ON | OFF | | |
| COIN 2 | 1/4 | | | | OFF | OFF | ON | | |
| (COIN/CREDIT) | 2/1 | | | | ON | ON | OFF | | |
| | 3/1 | | | .1 | ON | OFF | ON | | |
| | 4/1 | | 9 - | | OFF | ON | ON | | |
| | FREE PLAY | ON | ON | ON | ON | ON | ON | | |
| STARTING COIN | NORMAL | | | | | | | OFF | |
| ゲーム開始時のクレジット | ×2 | | | | - | | | ON | |
| SCREEN FLIP | NORMAL | | | | | | | | OFF |
| 画面反転 | FLIP | | | | | | | | ON |
| DEFAULT SETTING 出荷時の設定 | | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| DIP-SW 2 | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| | 普通 Normal | OFF | OFF | | | | | | |
| 難易度 | 簡単 Easy | OFF | ON | | | | | | |
| DIFFICULTY | 少し難しい | 011 | | | | | | | |
| | Hard | ON | OFF | | | | | | |
| | 難しい Very Hard | ON | OFF | | | | | | |
| | 難しい | | | OFF | OFF | | | | |
| プレイヤー数 | 難しい Very Hard | | | OFF OFF | OFF ON | | | | |
| プレイヤー数 NUMBER OF PLAYERS | 難しい Very Hard 3 | | | | | | | | |
| | 難しい Very Hard 3 4 | | | OFF | ON | | | | |
| | 難しい Very Hard 3 4 2 | | | OFF | ON OFF | OFF | OFF | | |
| | 難しい Very Hard 3 4 2 | | | OFF | ON OFF | OFF ON | OFF OFF | | |
| NUMBER OF PLAYERS | 難しい Very Hard 3 4 2 1 200000/500000 | | | OFF | ON OFF | | | | |
| NUMBER OF PLAYERS ボーナスプレイヤー | 難しい Very Hard 3 4 2 1 200000/500000 400000/1000000 | | | OFF | ON OFF | ON | OFF | | |
| NUMBER OF PLAYERS ボーナスプレイヤー | 難しい Very Hard 3 4 2 1 200000/500000 400000/1000000 1000000/3000000 | | | OFF | ON OFF | ON OFF | OFF ON | OFF | |
| NUMBER OF PLAYERS ボーナスプレイヤー EXTEND PLAYER | 難しい Very Hard 3 4 2 1 200000/500000 400000/1000000 1000000/3000000 No Extend | | | OFF | ON OFF | ON OFF | OFF ON | OFF ON | |
| NUMBER OF PLAYERS ボーナスプレイヤー EXTEND PLAYER デモプレイ中のサウンド | 難しい Very Hard 3 4 2 1 200000/500000 400000/1000000 1000000/3000000 No Extend YES | | | OFF | ON OFF | ON OFF | OFF ON | | OFF |
| NUMBER OF PLAYERS ボーナスプレイヤー EXTEND PLAYER デモプレイ中のサウンド DEMO SOUND | 難しい Very Hard 3 4 2 1 200000/500000 400000/1000000 1000000/3000000 No Extend YES NO | | | OFF | ON OFF | ON OFF | OFF ON | | OFF ON |

注意事項

- 1. PCボードの取り付け、取り外しは必ず電源を切ってから行って下さい。
- 2. 本ボードに張ってあるシリアルナンバーシールを剝がした場合や、無断で改造した場合には、故障に際して保障期間内であっても有償又は対象外となります。
- 3. 回路は一部バッテリーバックアップされており、テスターなどで導通検査などを するとショートの原因になりますので絶対に御止め下さい。また絶対にバッテリー は外さないで下さい。
- 4. PCボードを輸送する際には、スポンジやエアキャップなどで包み、段ボール箱 などに入れ強い衝撃を加えないようご注意下さい。

SEIBU KAIHATSU INC., 有限会社 セイブ開発

〒101 東京都千代田区三崎町2-20-1

2-20-1 Misaki-Cho Chiyoda-Ku, Tokyo 101

TEL.03(3238)9169 FAX.03(3238)9187