TELL 0

CIRCUS CHARLIE OPTIONAL DIP SWITCH SETTINGS

A. Dip Switch No.1 (8P Dip Switch)

Credits

0 - 4 -	0.1				Γ	T	, 		
Coin	Plays	SW1	SW2	SW3	SW4	SW5	SV6	SW7	SMS
1	1	Off	Off	Off	Off	Off	Off	Off	Off
	2	0 n	Off	Off	Off	On	Off	Cff	0 f f
	3	Off	0 n	Off	Off	Off	On	Off	Off
1	5	On	0 n	Off	Off	On	On -	Off	Off
1	5	Off	Off	0 n	Off	Off	Off	On	Off
	6	On	Off	0 n	Off	0n	Off	On	Off
1	,	Off	0n	0n	Off	077	0n	On	Off
200	1	Cn	Cn	.0n	Off.	0 n	- 0 n	On	Off
4 2	3 5	Off	Off.	Off	0 n	Off	Off	Off	On
2) 1	0n	Off	Off	0 n	On	Off	Off	Qn
3 3	1 2	Off	อิา	Off	0n	Off	On -	Off	0 n
3	4	On Off	Ûn.	Off	0n	ûn	On	0ff -	0 n
2			07f	0 n	0n	Off	Off	0 n	On
1 -	3	On Off	Orf	On	0n	0n	Off	On -	0n
ŧ '	5124	0n	On On	0n	0 n	n ff	Qn	0 n	0 n
1.66	Play	011	i On sa	On	0 n	0 n	Gn	0 n	0 n

B: Dip Switch No.2 (8P Dip Switch)

1. Number Of Clewns

Number	SWI	SW2
0 3 5 7	Off On Off On	Off Off On On

2. Game Type

Style	SW3	Players
Table	Off	1 cr 2 Players
Upright	On	Only 1 Player

3. Bonus Points Setting

First	And Every	SW4	SW5
O 20,000	70,000	Off	Off
30,000	80,000	On	Off

B. Dip Switch No.2 (continues)

4. Play Difficulty

Option	SW6	SW7
Easy	Off	0ff
O Normal	On	0ff
Hard	Off	0n
Difficult	On	0n

5. Audio Attraction

Sound Mode	SW8
No Sound In Attract Mode Sound In Attract Mode	Off On

O Denotes Normal Settings





