

WARNING F.C.C. REGULATION COMPLIANCE

THIS EQUIPMENT COMPLIES WITH THE REQUIREMENTS IN PART 15 OF FCC RULES FOR A CLASS A COMPUTING DEVICE. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA MAY CAUSE UNACCEPTABLE INTERFERENCE TO RADIO AND TV RECEPTION REQUIRING THE OPERATOR TO TAKE WHATEVER STEPS ARE NECESSARY TO CORRECT THE INTERFERENCE.



815 Mittel Drive, Wood Dale, Illinois 60191
Telephone: (312) 595-1443, Telex: 6871385 KONAM UW, Fax: (312) 595-2973



INSTRUCTION MANUAL

MAIN EVENTTM is a registered trademark of Konami Inc. © 1988 Konami Inc. KONAMI® is a trademark of Konami Industry Co., Ltd.

MAIN EVENT: WIRING HARNESS

E COLOR KEY:	Solder Side ←			→ Parts Side	
BLACK	GND	Α	1	GND	BLACK
BLACK	GND	В	2	GND	BLACK
RED	+ 5V DC	С	3	+5V DC	RED
RED	+ 5V DC	D	4	+5V DC	RED
	NOT USED	E	5	NOT USED	
ORANGE	+ 12V DC	F	6	+ 12V DC	ORANGE
	*KEY	Η	7	*KEY	
	(EMPTY)	J	8	COIN COUNTER	GREEN/GRAY
	(EMPTY)	K	9	(EMPTY)	
YELLOW	SPEAKER (-)	L	10	SPEAKER (+)	BLUE
	(EMPTY)	М	11	(EMPTY)	
WHITE/GREEN	VIDEO GREEN	N	12	VIDEO RED	RED/WHITE
WHITE	VIDEO SYNC	Р	13	VIDEO BLUE	BLUE/WHITE
	(EMPTY)	R	14	VIDEO GROUND	BLACK
	(EMPTY)	S	15	(EMPTY)	
VIOLET/WHITE	COIN 2	Т	16	COIN 1	BLUE/BROWN
RED/GREEN	2P START	U	17	1P START	PINK/YELLOW
BLUE/YELLOW	2P UP	V	18	1P UP	ORANGE/WHITE
VIOLET/YELLOW	2P DOWN	W	19	1P DOWN	BLACK/WHITE
ORANGE/GREEN	2P LEFT	Х	20	1P LEFT	RED/GRAY
ORANGE/YELLOW	2P RIGHT	Υ	21	1P RIGHT	GRAY/WHITE
BLACK/YELLOW	2P TAG	Z	22	1P TAG	RED/WHITE
ORANGE/GRAY	2P ACTION	а	23	1P ACTION	GREEN/BROWN
	NOT USED	b	24	NOT USED	
	NOT USED	С	25	NOT USED	
	NOT USED	d	26	NOT USED	
BLACK	GND	е	27	GND	BLACK
BLACK	GND	f	28	GND	BLACK
			<u> </u>	_	

(BASE COLOR/LINE COLOR)

MAIN EVENT: SUB HARNESS

_	_		
	1	Coin 3	White/Violet
	2	Empty	
	3	3P Left	White/Red
	4	3P Right	White/Yellow
	5	3P Up	White/Black
	6	3P Down	White/Blue
CN3	7	3P Tag	White/Brown
3P	8	3P Action	White/Orange
CONTROLS	9	Empty	
	10	Empty	
	11	Empty	
	12	Empty	
	13	Empty	
	14	Empty	
	15	Ground	Black
	1	Coin 4	Blue
	2	Empty	
	3	4P Left	Yellow/Black
	4	4P Right	Brown/Black
	5	4P Up	Green/Yellow
	6	4P Down	Yellow/Red
CN4	7	4P Tag	Yellow/White
4P	8	4P Action	Yellow/Blue
CONTROLS	9	Empty	
	10	Empty	
	11	Empty	
	12	Empty	
	13	Empty	
	14	Empty	
	15	Ground	Black
	1	Lamp 1	Violet
CN2	2	Lamp 2	Blue
ACTION	3	Lamp 3	Green
LAMP	4	Lamp 4	Yellow
OUTPUTS	5	Empty	
	6	+ 12 Volts	Black

٠

DIP SWITCH SETTINGS

DIP SWITCH NO. 1 SETTINGS

1. COIN 1

1. 00114	<u> </u>					
SW	1	2	3	4	COIN	CREDIT
•	OFF	OFF	OFF	OFF	1	1
	ON				1	2
	OFF	ON			1	3
,	ON		<u> </u>		1	4
	OFF	OFF	ON	OFF	1	5
	ON				1	6
	OFF	ON			1	7
	ON				2	1
	OFF	OFF	OFF	ON	2	3
	ON				2	5
	OFF	ON]		3	1
	ON				3	2
	OFF	OFF	ON	ON	3	4
	ON				4	1
	OFF	ON			4	3
	ON				4	5

SW5 through SW8 are not used.

DIP SWITCH NO. 2 SETTINGS

1. BONUS ENERGY

SW	1	2	ENERGY
	OFF	OFF	90
•	ON		80
	OFF	ON	70
	ON		60

2. DIFFICULTY OF THE GAME

sw	6	7	DIFFICULTY
	OFF	OFF	EASY
•	ON		NORMAL
	OFF	ON	DIFFICULT
	ON	,	VERY DIFFICULT

3. SOUND IN ATTRACTIVE MODE

sw	8	SOUND
	OFF	OFF
•	ON	ON

SW 1, SW2 and SW3 are not used.

DIP SWITCH NO.3 SETTINGS

1. VIDEO SCREEN FLIP

S	W	1	
	•	OFF	NORMAL
		ON	UPSIDE DOWN

2. CHANGE OF MODE

SW	3	MODE
•	OFF	GAME
	ON	TEST

SW2 and SW4 are not used.

Shows recommended settings

MAIN EVENT: AC FLOW CHART

- 1. GREEN/YELLOW
- 2. BLACK
- 3. RED















