


Service Manual



UNIVERSAL

Thank you for your purchase of *UNIVERSAL'S MR. DO'S CASTLE CONVERSION KIT.*® Before attempting installation make certain that your conversion kit is complete.

Your kit includes:

- A. (1) Mr. Do's Castle P.C.B. (contained in a R.F. shield)
- B. (1) Audio Amplifier P.C.B.
- C. (1) License Sticker
- D. (1) Main Harness Assembly
- E. (1) 4-Way Joystick
- F. (4) Push Buttons (complete with housing)
- G. (1) 24" X 9" Clear Control Panel Plexi Glass
- H. (1) set of Control Panel Decals
- I. (1) Policarbonate Control Panel Overlay
- J. (1) Mr. Do's Castle Marquis Plexi
- K. (1) set of Mr. Do's Castle Side Decals

Caution:

Installation of conversion kits or any other such modification to any coin operated video game should be attempted only by qualified service personel.


CONTENTS

1.	How to play								
H. '	. Various optional settings								
Ш.	I. How to conduct self-testing3—4								
IV.									
V. '	/. Wiring diagram (Connector)								
VI.	/I. Main circuit board schematic diagram8–1								
VII.	Block diagram								
Cauti	on I. (to prevent X-ray exposure from	the CRT)	12						
Cauti	on II.(to prevent interference to radio a	and TV reception)							
	DEFEDENCE								
	REFERENCI	E.DRAWINGS							
Fig. 1	Main Circuit Board IC Location								
Fig. 2	Wiring Diagram (Connector)								
Fig. 3	Main Circuit Board Schematic Diagram (No	. 1)							
Fig. 4	Main Circuit Board Schematic Diagram (No	. 2)							
Fig. 5	Main Circuit Board Schematic Diagram (No	. 3)							
Fig. 6	Main Circuit Board Schematic Diagram (No	. 4)							
Fig. 7	Block Diagram								
	SPECIFIC	SNOITA							
		ATIONS							
	TABLE TYPE	LIPR	GHT TYPE						
		0111	10111 1 11 Ę						
ı	64 m/m (D) AC100V/115V/230V	800 m/m (D)	AC100V/115V230V						
	63 m/m (W) 50/60Hz 680 m/m (H) 140W (18'')	640 m/m (W) 1750 m/m (H)	50/60Hz 180W (20'')						
","	330 m/m (11)	1730 m/m (H)	100W (20)						
l	₹ 95-2447	₹ 95-1653							



I. HOW TO PLAY

- 1. Operate Mr. Do! by means of the lever.
- 2. After dropping a block by use of the hammer, skillfully drop the unicorn into the hole. Then drop the block onto the unicorn and you can exterminate it.
- 3. You can also exterminate the unicorn by dropping a block onto it while it is walking.
- 4. You can hit and knock over a unicorn by use of the hammer in scenes 1 and 2.
- 5. Make good use of the skull blocks, and you can wipe out several unicorn at a time. When dropping both skull blocks, the blocks between them will also drop at the same time.
- 6. Only Mr. Do! can remove the ladder.
- 7. If Mr. Do! has been trapped between two unicorns on the blocks, you can help him escape by dropping a block with the hammer.
- 8. When three of the key blocks have been dropped, the door on the top level will open and a shield will appear. If you wipe it out the unicorns will change to EXTRA.
- 9. You can exterminate EXTRA by hammering it or dropping Mr. Do! on it. When it has been wiped out, a flag will be run up on the pole.
- 10. Another Mr. Do! will appear if you succeed in running up five flags, E X T R A on the pole.
- 11. The last unicorn in scenes 1 and 2, will change and split into the blue unicorns after 20 seconds after a further 25 seconds, the blue unicorns will split into double unicorns, and then after another 5 seconds these will become eight there will be no further increase.
- 12. Red unicorns will become green if Mr. Do! hits them four times with the hammer, and green unicorns will become blue when he hits them once with it.





II. VARIOUS OPTIONAL SETTINGS

DESCRIPTIONS OF DIP SWITCHES

• Dip Switch A

1. Number of Mr. Do! Given (SW1, 2)

No. of Mr. Do!	SW1	SW2
3	OFF	OFF
4	OFF	ON
5	ON	OFF
2	ON	ON

2. Game Style (SW3)

Style	SW3
Table	OFF
Upright	ON

3. Difficulty of EXTRA (SW4)

Difficulty	SW4
Easy	OFF
Difficult	ON

4. SW5 is not used.


5. Automatic Renewal of Screen (SW6)

Automatic renewal	SW6
Made	OFF
Not made	ON

6. Difficulty of the Games (SW7, 8)

Difficulty	SW7	SW8
1 (Beginner)	OFF	OFF
2	OFF	ON
3	ON	OFF
4 (Advanced)	ON	ON

• Positions of Dip Switches



• Dip Switch B (Coin & Credit)

	0 111		Left-sid	e chute		Right-side chute			
Coin	Credit	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
1	1	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1	.2	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
1	3	OFF	OFF	ON	OFF	OFF	OFF	ON	OFF
1	4	OFF	OFF	ON	ON	OFF	OFF	ON	ON
1	5	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
2	1	OFF	ON	OFF	ON	OFF	ON	OFF	ON
2	3	OFF	ON	ON	OFF	OFF	ON	ON	OFF
3	1	OFF	ON	ON	ON	OFF	ON	ON	ON
3	2	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
4	1	ON	OFF	OFF	ON	ON	OFF	OFF	ON
1	1	ON	OFF	ON	OFF	ON	OFF	ON	OFF
1	1	ON	OFF	ON	ON	ON	OFF	ON	ON
1	1	ON	ON	OFF	OFF	ON	ON	OFF	OFF
1	1	ON	ON	OFF	ON	ON	ON	OFF	ON
1	1	ON	ON	ON	OFF	ON	ON	ON	OFF
Free play ON ON ON ON ON				ON	ON	ON			

Standard and Custom Price Settings

The game price set by a combination of dip SWs is displayed on the monitor when coin credit is 0.

- a) When the settings for right and left chutes are the same,
 "1 coin 1 credit", "2 coins 3 credits", etc. are displayed.
- b) When the settings for right and left chutes are provided differently, their respective contents can be displayed.



III. HOW TO CONDUCT SELF-TESTING

★ This machine has a self-testor which locates any abnormalities with the machine should they occur.

[Self-Testing Procedure]

Turn power ON while pressing the push-button or either the 1st or the 2nd player side, and self-testing will follow automatically.

[Self-Testing Items]

(1)	RAM Test:	
	When normal -	"RAM OK" will appear on the screen, and the test will proceed to the next step
	When abnormal —	"RAM " will appear, and the test will be suspended.
		Abnormal RAM No.
(2)	ROM Test:	
	When normal -	"ROM OK" will appear on the screen, and the test will proceed to the next step.
	When abnormal -	"ROM
		Abnormal ROM data
		Abnormal ROM No.

(3) Sound OFF:

"SOUND OFF" will appear on the screen, and the sound that has been made to that time will stop, then, the test will proceed to the next step. The machine is out of order if the sound does not stop or the test does not proceed to the next step.

(4) Switch Test:

Switch names are displayed on the left side of the screen, while input conditions will be displayed on the right side. When the switch is ON, "0" is displayed for input, and when it is OFF, "1" is displayed. Conduct test while turning each switch ON-OFF — the test will advance to the next step after a minute.

Switch name	Input condition		Switch name	Input condition
2P DOWN	1		COIN LEFT	1
LEFT	1		COIN RIGHT	1
UP	0	7	PAUSE	1
RIGHT	1	7//	SERVICE	1
1P DOWN	1		TEST	1
LEFT	1	\neg $ $	TILT	1
UP	1	¬ \		
RIGHT	1	一	//	
2P START	.1		/ /	
NOT USED	1) ON \	\
2P JUMP	1		/ N. A	\
FIRE	1			1
1P START	1			"0" will appear when pushing
NOT USED	1	7		1
1P JUMP	1	7	\ \ \ \	the pushbutton on the 1st
FIRE	1	7		player's side.
NOT USED	1			
NOT USED	1			


Dip switch A	1	0	1	1	0	1	1	1
" В	1	1	1	1	1	1	1	0

(5) TV Monitor Test:

Cross hatch pattern will appear on the entire screen. Monitor adjustment can be done by means of the pattern.

- Self-testing will stop at this point. Turn ON power again when you want to resume game or execute self-test again.
- * In case you have found any abnormality as a result of the self-test, contact the dealer who sold the machine to you.

IV. MAIN CIRCUIT BOARD IC LOCATION AND PARTS LIST



[1] Integrated Circuit

Item No. Q'ty Description 74LS 00N 2 TTL 74LS 01 1 " 74LS 04 4 " 74LS 08 1 " 74LS 20 2 " 74LS 27 1 " 74LS 32 1 " 74LS 74 5 " 74LS 86 7 " 74LS 138 3 "	-
74LS 01 1 " 74LS 04 4 " 74LS 08 1 " 74LS 20 2 " 74LS 27 1 " 74LS 32 1 " 74LS 74 5 " 74LS 86 7 "	
74LS 01 1 " 74LS 04 4 " 74LS 08 1 " 74LS 20 2 " 74LS 27 1 " 74LS 32 1 " 74LS 74 5 " 74LS 86 7 "	
74LS 04 4 7 74LS 08 1 " 74LS 20 2 " 74LS 27 1 " 74LS 32 1 " 74LS 74 5 " 74LS 86 7 "	
74LS 20 2 " 74LS 27 1 " 74LS 32 1 " 74LS 74 5 " 74LS 86 7 "	_
74LS 20 2 74LS 27 1 " 74LS 32 1 " 74LS 74 5 " 74LS 86 7 "	
74LS 27 1 " 74LS 32 1 " 74LS 74 5 " 74LS 86 7 "	
74LS 32 1 74LS 74 5 " 74LS 86 7 "	
74LS 86 7 "	
74L3 00	
74LS138 3 "	
74LS139 3 "	
74LS157 6 "	
74LS161 3 "	
74LS244 3 "	
74LS245 1 "	
74LS257 4 "	
74LS273 6 "	
74LS283 3 "	
74LS373 1 "	
74LS374 4 "	
74ALS04N 1 "	
74ALS08 1 "	
74S374N 1 "	
Z80A 3 NMOS CPU (4MHz)	
2764-300 8 NMOS 64K bits EP ROM	
(Access 300nsec)	
27128-300 2 NMOS 128K bits ROM	
(Access 300 nsec)	
N82S147 2 4096 bits Fuse ROM	
TMS4164-200 16 64K DRAM	
MB8128-150 5 NMOS 16K bits Static R/	AΜ
(Access 150nsec)	
MB8128-100 1 NMOS 16K bits Static RA	AΜ
(Access 100nsec)	
CF37201N 1 Custom Function	
NE556 1 Timer	
MB3730 1 Audio Amplifier	
SN76489AN 4 Programable Sound Gener	ator
TMS1025N2CL 2 CMOS	
HD46505SP 1 CRTC	
10D1 4 Diode	
UA7805 1 Regulator	

This drawing provides standard information.
Universal reserves the right to change without notice.

[2] Capacitors

Rating	Q'ty	Description
0.1μF16V	22	Ceramic Capacitor
0.1μF25V	3	,,
0.001μF25V	4	"
400PF50V	3	"
100PF50V	1	,,
50PF50V	1	"
47μF16V	1	"
10μF16V	2	"
22μF16V	1	,,
47μF16V	1	"
470μF6.3V	1	. "
0.22μF16V	1	ES Capacitor
1000μF16V	1	"


[3] Registors

	1	
Rating	Q'ty	Description
4.7Ω	2	Carbon Solid
20Ω	1	"
100Ω	1	"
200Ω	3	"
330Ω	4	. "
390Ω	3	"
510Ω	4	"
820Ω	2	"
1ΚΩ	3	"
1.5ΚΩ	4	"
2ΚΩ	1	"
22ΚΩ	1	,,
5.1ΚΩ	1	"
100Ω	28	"
120Ω	4	"
51Ω	1	"
330 x 8	3	Resistor Array
1K x 8	2	"
10K x 8	2	"
1ΚΩΒ	1	"

[4] Misc


Name	Q'ty	Description
Dip SW	2	8 Elements Switch Array
X tal	1	9.828MHz
"	1	4.000MHz
20P	2	IC Socket
28P	10	"

V. WIRING DIAGRAM (CONNECTOR)



MR. DO'S CASTLE HARNESS PIN ASSIGNMENT


SOLDER SIDE COMPONENT SIDE




NOTE:

CONNECTION FOR USE WITH COIN METER

CONNECTION FOR USE WITHOUT COIN METER







^{*} BE SURE TO REMOVE COMP SYNC LINE WHEN INSTALLING THE POSITIVE INDEPENDANT SYNC LINES.

NOTE: IN MOST CASES WHERE BY A SEPERATE HORIZONTAL AND VERTICAL NEGATIVE SYNC. PULSE IS NEEDED, THE COMPOSIT SYNC. SIGNAL CAN BE USED BY CONNECTING THE WHITE WIRE (PIN C) TO BOTH NEGATIVE HORIZONTAL AND VERTICAL INPUTS ON THE MONITOR CHASIS.


NVERSAL

VI. MAIN CIRCUIT BOARD SCHEMATIC DIAGRAM





NIVERSAL.



IN IVERSAL

VII. BLOCK DIAGRAM

