

# INSTRUCTION MANUAL

OCTOBER-15,1985

#### MEMETRON PRESENTS

THE PRO WRESTLING EVENT OF THE CENTURY!


# MAT MANIA

COPYRIGHT 1985
TAITO AMERICA CORPORATION
LICENSED BY TECHNOS, JAPAN
DISTRIBUTED BY MEMETRON INC.

FOR THE SERVICE THAT KEEPS YOU GOING 312-565-2828 2350 BRICKVALE DRIVE ELKGROVE VILLAGE, IL. 60007

# **VIDEO GAME OPERATOR:**

Don't Get Involved In A Federal Crime. Don't Buy Or Operate Copy Or Unauthorized Boards In Your Games.





Every operator who buys or operates a counterfeit or unauthorized board (imported or domestic) is contributing to the end of our industry and committing a FEDERAL CRIME.

New criminal laws have recently been enacted that provide for maximum penalties of \$250,000 or five years in prison or both, per offense, EACH GAME IS A SEPARATE OFFENSE.





#### WARNING

Fathers are principle tolers, covil and crement peraffect for the unauthorized reproduction distribution, or richitorized copyrighted public-scale repts; and value gament.

The father Bress of brightering management adoptions of comment

If you have any information about any unauthorized games to the United States, contact wore local FBI or.

American Amusement Machine Association

205 The Strand Suite 3 Alexandria, Virginia 22314 (703) 548-8044

## IMPORTANT F.C.C. WARNING

"This Kit is intended for use only on coin operated video games manufactured after October 1, 1983, which have been verified for compliance with the requirements in Part 15 of FCC rule for class A computing devices. Improper connection of the kit or connection to any other coin operated video game not so manufactured or verified for compliance may cause unacceptable interference to radio and T.V. reception requiring the operator to make necessary changes to correct the interference. Memetron, Inc., takes no responsibility for kits improperly connected and those connected to games for which use is not intended."

#### Warnings & Notices

#### WARNING

For safety and reliability, Memetron Inc., does not recommend or authorize any substitute parts or modifications of Memetron equipment.

Use of non-Memetron parts and modifications of game circuitry may adversely affect game performance.

Substitute parts or equipment modifications may void FCC type acceptance.

Since this game is protected by Federal copyright, trademark and patent laws, unauthorized game-conversions may be illegal under federal Law.

This "conversion" principle also applies to unauthorized facimiles of Memetron Inc., equipment, logos. designs, publications, assemblies and games ( or features not deemed to be in the public domain ), whether manufactured with Memetron components or not.

#### WARNING

Three-Wire Plug this game must be plugged into a properly-grounded outlet to prevent shock hazard and to assure proper game operation. Do Not use a "cheater" plug to defeat the ground pin on the power cord, and do not cut off the ground pin.

#### NOTICE

Parts salvaged from your old game are required to complete your kit. These salvaged parts MUST operate perfectly, or the converted game can not perform perform properly of safely. Always repair circutboard malfunctions and cabinet damage before conversion is attempted.

#### NOTICE

This kit is not intended for use with X-Y monitors. Suitable monitors are the horizontal or vertical raster-type with inputs for red, green and blue video as well as negative sync. (These inputs should be compatiable with TT1 logic levels.) Note: Mat Mania™ uses a vertical monitor.

#### NOTICE

Be sure the power supply from your old game is capable of +5vdc regulated at 6A and +12VDC regulated at 1A. These operating voltages are necessary for your Kit.

#### Notice

Mat Mania is a registered trademark of Taito America Corp. Under License from Technos, Japan. Distributed by Memetron Inc., 1985.

#### NOTICE is evomed imus primaris an doug vilmente and

Please make sure you clean and lubricate your old coin mechanisms. It is important that you service tham in order for this game to earn the maximum projected earnings.

#### KING KIT'S PARTS LIST PROVIDED

| [] | PCB BOARD                  | (1)     |
|----|----------------------------|---------|
| [] | JOY STICK                  | (1)     |
| [] | CONTROL PANEL OVERLAY      | (1)     |
| [] | PLEXI CRT got no tro bab o | oud (1) |
| [] | PLEXI MARQUEE              |         |
| [] | WIRING HARNESS             |         |
| [] | INSTRUCTIONS               |         |
| [] | PLAY INSTRUCTIONS          |         |
| [] | MISC CONTROL STICKERS      |         |
| [] | DRILLING TEMPLATE          |         |
| [] | JOYSTICK STAR              | (1)     |
| [] | BUTTONS                    | (4)     |
| [] | FCC CAGE                   | (1)     |

## Tools and supplies required

- [] SCREWDRIVER
- [] WIRE CUTTERS | LODITION D ROBU TOHOM TOM : STOVE | . STOVE |
- [] ELECTRIC DRILL
- II SOLDERING IRON & SOLDER
- [] PLIERS
- 11 PHILLIPS SCREWDRIVER Be sure the power supply from your old gan
- II HEX DRIVER
- [] 180-GRIT SANDPAPER
- [] FIRE ENGINE RED, SEMI-GLOSS LATEX PAINT
- [] GREASE PENCIL OR MARKER
- [] X-ACTO KNIFE
- [] HACKSAW or JIGSAW

#### CABINET 1210 Indet License from Technos, Jopen 1910, 3105

Inspect your old cabinet for any gouges or items stuck on the extremity such as chewing gum. Remove all foreign objects and fill in the gouges with any type if quick hardening wood putty. Sand to make sure the surface is smooth and wipe clean the outside of the old cabinet. Remember the reason you are converting your game is to have the earnings of a new game. Making it look like a new game will increase your earnings and player interest.

#### CRT & MARQUEE

Remove the new crt and marquee from the kit box. Place and center the old marquee and crt on top of the new crt and marquee. Stick masking tape on the area where you intend to cut the plexiglass. Take your grease pencil and draw a straight line to use as a cutting guide. Using your hacksaw or jigsaw cut the plexiglass down to size. Replace the new cut to size plexiglass marquee and crt cover on your game. If done correctly your game should look almost new.

#### CONTROL PANEL

Remove the old control panel buttons or joysticks. Clean and sand smooth any imperfections on the existing vynil material.

Place the template that comes with the game on the control panel in order to design the best possible positioning for your buttons, joystick and control panel instructions.

Please leave your 1 or 2 player start button holes where they are. Drill holes as needed for installation of the joystick and other buttons. Any hole that is no longer needed we suggest plugging with wood blocks, putty, cardboard or epoxy. Remove the backing from the rear and carefully place the control panel overlay on the old control panel being careful not to get any air bubbles in the vynil when it's applied.

After the control panel is securely on, with an exacto knife knife or razor blade carefully cut out holes on the control panel. Next stick the joystick stars and button stickers on the control panel. Replace your buttons on the control panel and tighten them down. Return the control panel to the game for the next step in the kit process.

#### GAME PLAY INSTRUCTIONS

Your game comes with two sets of instruction decals, one to mount horizontally and the other to mount vertically. Depending on the amount room around the Crt. After conversion choose set A or set B for installation on your game but not both.

#### Nonce

Refer to the decal layout sheet for more information on graphics position.

Refer to the control panel template for control layout suggestions.

If the control panel that you are going to use is wood and is too thick for use with the enclosed button holders, than remove the switches from the holders and shim them with spacers.

Make sure that the control panel is on straight.

## WIRING PROCEDURES INSTALLING INTERBOARD WIRING

[] Disconnect the old wiring harness from the CPU board. Using the schematic drawings from your old game, carefully note the function of each wire. Label the wires if this helps.

[] Carefully remove all circutboards and the metal curcutboard panel from the game.

[] Leaving several inches of wire from the old wiring harness at each connector, cut the wires near the games coin door, moniter, player panel, power-supply and speaker wires to the new CPU-board harness. Using electrical tape, be sure to insulate all splices.

[] If your game has series-pass transistors for the power supply on a separate heatsink, remount the metal heatsink beside the power supply board.

[] Check and clean the input jack on the power-supply board. Replace any burned or damaged pins.

THONK YOU FOR YOUR DURCHOSE OF 9,

MEMETRON KING KIT.

DIR SWITCH SETTINGS

#### MAIN HARNESS

#### MAT MANIA

|     | SOLDER        | R SIDE        | PARTS SIDE |     |             |            |    |  |
|-----|---------------|---------------|------------|-----|-------------|------------|----|--|
| GA. | WIRE/COLOR    | SIGNAL NAME   | PIN        | NO  | SIGNAL NAME | WIRE/COLOR | GA |  |
| 18  | YEL-GRN       | -5V           | A1         | В1  | +12V        | YEL-RED    | 18 |  |
| 22  | VIO-WHT       | SPEAKER GND   | A2         | B2  | SPEAKER     | VIO        | 22 |  |
| 22  | BLU-YEL       | 1P SHOOT 1    | A3         | В3  | 1P UP       | ORG        | 22 |  |
| 22  | BRN-WHT       | 1P RIGHT      | A4         | В4  | 1P LEFT     | BRN        | 22 |  |
| 22  | GRAY          | 1P START      | A5         | В5  | 2P START    | ORG-WHT    | 22 |  |
|     | main 2.V      | 2P SHOOT      | A6         | В6  | 2P UP       |            |    |  |
|     | Very depyr at | 2P DOWN       | A7         | В7  |             | Halle D    |    |  |
|     | atmakki tol   | 2P LEFT       | A8         | В8  | 2P RIGHT    |            |    |  |
| 22  | BLU-RED       | COIN COUNTER1 | A9         | В9  | 1P DOWN     | GRY-YEL    | 22 |  |
|     | 110           |               | A10        | B10 | COIN 1      | BLU-GRY    | 22 |  |
|     | 310           |               | A11        | B11 |             |            |    |  |
| 22  | BLU-GRN       | 1P SHOOT 2    | A12        | B12 | 2P SHOOT 2  |            |    |  |
| 22  | GREEN         | VIDEO GREEN   | A13        | B13 | VIDEO BLUE  | BLUE       | 22 |  |
| 22  | RED           | VIDEO RED     | A14        | B14 | VIDEO SYNC  | WHITE      | 22 |  |
|     |               |               | A15        | B15 |             |            |    |  |
| 18  | BLACK         | GND           | A16        | B16 | GND         | BLACK      | 18 |  |
| 18  | BLACK         | GND           | A17        | B17 | GND         | BLACK      | 18 |  |
| 18  | YELLOW        | +5V           | A18        | B18 | +5V         | YELLOW     | 18 |  |
|     |               | 8             |            |     |             | THE STATE  |    |  |
| -   | -             |               |            |     |             |            |    |  |

Degree of Difficulty-

#### DIP SWITCH SETTINGS

#### DIP SWITCH 1


| 1     | 2       | 3      | 4           | 5     | 6     | 7     | 8            |                         |
|-------|---------|--------|-------------|-------|-------|-------|--------------|-------------------------|
|       |         |        | Critically. |       |       |       |              | Coin-A                  |
| OFF " | OFF     |        |             |       |       |       |              | 1 Coin – 1 Play         |
| ON    | OFF     | 0.0000 |             |       |       |       |              | 1 Coin – 2 Play         |
| OFF   | ON      |        |             |       |       |       |              | 1 Coin – 3 Play         |
| ON    | ON      | WENT   | MAI U       | Note: | 011   | da I  | SUMME        | 2 Coin – 1 Play         |
|       |         |        |             |       |       |       |              | Coin-B                  |
|       | ero ven | OFF *  | OFF .       |       |       |       |              | 1 Coin – 1 Play         |
|       |         | ON     | OFF         |       | 7.4   | 100   |              | 1 Coin – 2 Play         |
|       | 0.0     | OFF    | ON          | 0,510 | 200   | 10    | ((76), 16    | 1 Coin – 3 Play         |
|       | 0.1     | ON     | ON          | 1.11  | 7.0   | EA-   | LT           | 2 Coin - 1 Play         |
|       | 108     |        | 731         | 191   |       | M     | new Pri      | Sound for Demonstration |
|       | W-11    |        |             | OFF   |       |       |              | 可 Sound                 |
|       |         |        |             | ON    |       |       |              | 不可 Not sound            |
|       |         |        |             |       | -     | 200   | 13           | TV-Screen               |
|       |         |        |             |       | OFF   | 114   |              | Table type use          |
|       |         |        | 7000        | 1.75  | ON °  | BA    |              | Up-right type use       |
|       | IY-YE   |        | -258        | 1.41  | 188   | PA II | STAUE        | Check Program           |
| 100   | 1D-U.1  |        |             |       | onel  | OFF " |              | OFF                     |
|       |         |        |             |       | na.   | ON    |              | ON                      |
| -     |         |        | 1001        | 1 11  | I I I | SIA   | ON *         | Don't Touch             |
|       |         |        |             |       | -     | ****  | Committee of | Wester   Committee      |

(normal screen)
(flipp screen vertically)

#### DIP SWITCH 2

| 1    | 2    | 3                   | 4     | 5                            | 6  | 7     | 8      |                 |  |
|------|------|---------------------|-------|------------------------------|----|-------|--------|-----------------|--|
|      |      | 4 5   5   5   5   5 |       | ●難 度<br>Degree of Difficulty |    |       |        |                 |  |
| OFF  | OFF  |                     | NOO   | No.                          | Ŏ. | ON.   | DON'T  | 普 通 Normal      |  |
| ON ' | OFF* |                     | -     | J.                           | Ť  | 10000 | 5183.7 |                 |  |
| OFF  | ON   |                     | SE SE | 3S                           | SE | 3S    | JSU    |                 |  |
| ON   | ON   |                     |       |                              |    |       |        | むずかしい Difficult |  |

<sup>\*</sup> Suggested factory setting



HOLE COMPLETELY THROUGH, THEN DRILL I-1/8" HOLE TO 5/16" DEPTH.

FOR WOOD CONTROL PANELS, DRILL

d

