Konami_®



OPTIONAL DIP SWITCH SETTINGS

DIP SWITCH NO.1 (8P DIP SWITCH)

COIN-1 SWITCH SETTINGS

COIN	PLAYS	SW1	SW2	SW3	SW4
1 1 1 1 1 1 1 1 2 2 2 3 3 3 4 4 FREE	123456713512413 PLAY	F F F F F F F F F F F F F F F F F F F	0FF 0FF 0FF 0FF 0FF 0FF 0FF 0FF 0FF 0FF	00000000000000000000000000000000000000	0FF 0FF 0FF 0FF 0FF 0NN 0NN 0NN 0N 0N 0N

COIN-2 SWITCH SETTINGS

OPTIONAL DIP SWITCH SETTINGS

DIP SWITCH NO.2 (8P DIP SWITCH)

NUMBER OF MIKIES

SW1	SW2
OFF	OFF
ON	OFF
OFF	ON
ОИ	ON
	OFF ON OFF

GAME TYPE

STYLE	SW3
TABLE	OFF
UPR I GHT	ON

BONUS MIKIES

FIRST	EVERY	SW4	SW5
20,000 30,000 30,000 40,000	50,000 60,000 	OFF ON OFF ON	OFF OFF ON ON

GAME LEVEL OF DIFFICULTY

LEVEL	SW6	SW7
1 (EASY)	OFF	OFF
2	ON	OFF
3	OFF	ON
4 (HARD)	ON	ON

AUDIO ATTRACTION

AUDIO MODE	SW8
SOUND OFF	OFF
SOUND ON	ON



