

Torque Specifications

Apply the torque values below with a calibrated wrench. The table continues on the next page.

Part	Code	Torque (N·m)	Interval
Spark plug 1	SP-001	21	200 h
Spark plug 2	SP-002	22	300 h
Spark plug 3	SP-003	23	400 h
Spark plug 4	SP-004	24	100 h
Spark plug 5	SP-005	25	200 h
Spark plug 6	SP-006	26	300 h
Spark plug 7	SP-007	20	400 h
Spark plug 8	SP-008	21	100 h
Spark plug 9	SP-009	22	200 h
Spark plug 10	SP-010	23	300 h
Spark plug 11	SP-011	24	400 h
Spark plug 12	SP-012	25	100 h

Part	Code	Torque (N·m)	Interval
Spark plug 13	SP-013	26	200 h
Spark plug 14	SP-014	20	300 h
Spark plug 15	SP-015	21	400 h
Spark plug 16	SP-016	22	100 h
Spark plug 17	SP-017	23	200 h
Spark plug 18	SP-018	24	300 h

Table 1 (continued). Torque specifications.