

OPERATOR'S MANUAL

WELDING MACHINE, ARC

Section 1. Controls

Set the current switch to LOW
before starting the engine.

Section 2. Lubrication

Check the oil level every 8 hours.

Use grade OE-30 above 32 F.