
SMARTCON SOLUTIONS

Field Commissioning Job Aid

HILTON CONVENTION

HILTON CONVENTION CENTER SAVANNAH, GA

Generated: July 13, 2026 | Prepared by: Devon Brown | Revision: 3 | Service ID: SRV-20260713-AUTO

1. Site Submittal Extraction

Target Property	HILTON CONVENTION
City / State	HILTON CONVENTION CENTER SAVANNAH, GA
Revision	3
Date	04-JUN-2026
Drafter	DC
Reviewer	SCD
Vendor / Platform	Honeywell INNCOM
Thermostat Model	E7-WHITE
Network Type	ZigBee Mesh
HVAC Description	BY DATE
HVAC Model	Not found
Voltage	24 VAC
Equipment Code	Not found
Fan Speed	Not found
Occupied Cool	Not found
Occupied Heat	Not found
Unoccupied Cool	Not found
Unoccupied Heat	Not found
Grace Period	Not found
PMS	PEP
PAN ID	Not found
RF Channel	Not found

Door Locks	Dormakaba Saflok
Occupancy Sensors	S541
Door Contact	Yes - specified in submittal

2. Commissioning & Pairing Procedure

Platform: Honeywell INNCOM | Tool: EngINN

INITIALIZATION MODE

1. Ensure thermostat is mounted and connected to the Smart Wall Plate before starting.
2. When properly connected, thermostat enters INITIALIZATION MODE and displays 'rld'.
3. If not connected, unit displays 'SWp' alert until Smart Wall Plate is connected.

SET ROOM ID

1. Once 'rld' is displayed press MODE button. Default Room ID (65535) scrolls across screen.
2. The 5-digit Room ID is entered in three parts: highest digit, middle two digits, lowest two digits.
3. Use UP/DOWN arrows to set the highest digit (range 0-6) then press the FAN button to confirm.
4. Set the middle 2 digits (range 0-99) and press FAN button to confirm.
5. Set the lowest 2 digits (range 0-99) and press MODE button to confirm.
6. The new Room ID scrolls across the display and the unit beeps when stored to memory.
7. Press DOWN arrow to display HVAC menu.

SET HVAC TYPE

1. Once HVAC menu is displayed press MODE button.
2. Use UP/DOWN arrows to select the correct HVAC type from the hvac_types list.
3. Press FAN button to accept. Unit beeps to confirm.
4. Press DOWN arrow to display Fan Speed menu.

SET FAN SPEED

1. Use UP/DOWN arrows to select fan speed: 00, Lo, LH, or LMh.
2. NOTE: For heat pump models using reversing valve, medium fan speed is not available.
3. Press FAN button to execute. Unit beeps to confirm.
4. Press the temp unit button to exit INITIALIZATION MODE.
5. 'STr' is displayed confirming setup values stored in memory.
6. Unit reboots and begins operating HVAC as configured.

ENTERING SERVICE MODE

1. Press and hold the temp unit button.
2. While holding, press and release MODE, then press and release FAN.
3. Release the temp unit button. Thermostat is now in Service Mode.

RESETTING ROOM ID IN SERVICE MODE

1. NOTE: Only follow this if Room ID needs to change after Initialization Mode.
2. In service mode navigate to 'rld' parameter and press MODE.
3. Default Room ID (65535) scrolls across screen.
4. Set highest digit and press FAN. Set middle 2 digits and press FAN. Set lowest 2 digits and press MODE.
5. New Room ID scrolls across screen to confirm.

SETTING PAN ID AND RF CHANNEL

1. INNCOM Deep Mesh Network uses PAN ID and RF Channel to group rooms per Edge Router.
2. Assign PAN ID and RF Channel as per Edge Router configuration in EngINN.
3. For standalone property or model room: set PAN ID to 1 and RF Channel to 26.
4. In service mode navigate to 'PAN' (PAN ID) and press MODE.
5. Use UP/DOWN arrows to set the PAN ID and press FAN to confirm.
6. Navigate to RF Channel parameter, press MODE, set correct RF Channel, press FAN to confirm.

ENGINN CONFIGURATION

1. Requires PC/laptop, dongle PC-503, and Inncom proprietary tool EngINN.
2. In EngINN Deployment Data window populate the Room ID.
3. Verify RF Channel, PAN ID, and Room ID in EngINN match the installed E7.
4. Assign the same RF Channel for PC503 in EngINN.
5. In EngINN go to Deployment Data, Room Type, select the E7 thermostat and click BIND.
6. Press Ping button to confirm device is online.
7. Click Write Configuration to upload. Task Manager window shows upload status.

CHANGE E7 ADDRESS MULTI HVAC SUITE

1. In service mode navigate to E7 parameter and press MODE.
2. Use UP/DOWN arrows to set the E7 address and press FAN to confirm.
3. Press temp unit button to exit service mode.
4. Click Write Configuration in EngINN to upload the new address.

BINDING S541 RFD OCCUPANCY SENSOR

1. In EngINN go to Deployment Data, Room Type, select the S541.RFD device and click BIND.
2. Press Send button to transmit the bind message.
3. Press the blue S1 switch on the S541.RF to accept the bind.
4. Success: LED flashes 3 times and EngINN beeps 3 times and displays Device is online.

BINDING K594 RF DOOR SENSOR

1. In EngINN go to Deployment Data, Room Type, select the K594.RF device and click BIND.
2. Press Send button to transmit the bind message.
3. Press the recessed Bind button next to the status LED on the K594.RF using a paper clip.
4. Success: LED flashes 3 times and EngINN beeps 3 times and displays Device is online.

CHECKING FUNCTIONALITY

1. HVAC: Test all available fan speeds, cooling and heating operations.
2. Balcony/Window Switch: In service mode navigate to 'bln' (Balcony) and press MODE.
3. Thermostat displays and beeps if balcony is open.
4. When closed thermostat counts open/close events. Allow count to reach at least 3 for valid test.
5. Press temp unit button 3 times to return to normal operation.