


| | | |
|---|---|---|
| Sheet: /<br>File: hellenbms46.kicad_sch | | |
| **Title:** | | |
| Size: A4 | Date: | **Rev:** |
| KiCad E.D.A. 8.0.8 | | Id: 1/6 |

BMS46 X60001
ECU POWER




BMS46 X60002
TRANS, NBO2, MAIN REL




BMS46 X60003
ENGINE LOOM




BMS46 X60004
BODY LOOM




BMS46 X60005
IGN COIL




J203
Conn_02x12_Top_Bottom




LSU4.9 CONN
Same as UAEFI

J201
Conn_02x03_Top_Bottom




Sheet: /conn/
File: conn.kicad_sch

**Title:**

Size: A3 | Date: | **Rev:**

KiCad E.D.A. 8.0.8 | Id: 2/6


M301
Module:mega-mcu100/0.3
IGN1_(PC13)
IGN2_(PE5)
IGN3_(PE4)
IGN4_(PE3)
IGN5_(PE2)
IGN6_(PB8)
IGN7_(PB9)
IGN8_(PE6)
SPI2_SCK_/_CAN2_TX_(PB13)
SPI2_MISO_(PB14)
SPI2_MOSI_(PB15)
SPI2_CS_/_CAN2_RX_(PB12)
uSD card and accelerometer on SPI1 bus
SPI3_SCK_(PC10)
SPI3_MISO_(PC11)
SPI3_MOSI_(PC12)
SPI3_CS_(PA15)
PG_5VP
CANH
CANL
{CANH CANL}
I2C_SDA_(PB11)
I2C_SCL_(PB10)
Barometer on this I2C bus
OUT_INJ1_(PD3)
OUT_INJ2_(PA9)
OUT_INJ3_(PD11)
OUT_INJ4_(PD10)
OUT_INJ5_(PD2)
OUT_INJ6_(PA8)
OUT_INJ7_(PD15)
OUT_INJ8_(PD12)
OUT_PWM1_(PD13)
OUT_PWM2_(PC6)
OUT_PWM3_(PC7)
OUT_PWM4_(PC8)
OUT_PWM5_(PC9)
OUT_PWM6_(PD14)
UART8_RX_(PE0)
UART8_TX_(PE1)
F40x does not have UART8
UART2_RX_(PD6)
UART2_TX_(PD5)
IN_CRANK_(PB1)
IN_CAM_(PA6)
IN_VSS_(PE11)
USBP_(PA12)
USBM_(PA11)
USBID_(PA10)
VBUS
USB.DP
USB.DM
USB.VBUS
{DP DM VBUS}
IN_TPS_(PA4)
IN_PPS_(PA3)
IN_IAT_(PC3)
IN_CLT_(PC2)
SWCLK_(PA14)
SWDIO_(PA13)
SWO_(PB3)
Internal TC2030 connector
IN_O2S_/_CAN_WAKEUP_(PA0)
IN_O2S2_(PA1)
nReset
BOOT0
Internal buttons
IN_MAP1_(PC0)
IN_MAP2_(PC1)
LED_GREEN
LED_YELLOW
IN_AUX1_(PB0)
IN_AUX2_(PC4/PE9)
IN_AUX3_(PA7)
IN_AUX4_(PC5)
IN_KNOCK_(PA2)
IN_D1_(PE12)
IN_D2_(PE13)
IN_D3_(PE14)
IN_D4_(PE15)
VREF1
VREF2
V33_REF
V33_SWITCHABLE
V33
V5A_SWITCHABLE
GNDA
Connected
OUT_PWR_EN_(PE10)
IN_VIGN_(PA5)
VBAT
VCC
GND
PWR_EN
+5V
Ignition
IGN_OUT1
IGN_OUT2
IGN_OUT3
IGN_OUT4
IGN_OUT[1..4]
File: IGN.kicad_sch
Injection
INJ_OUT1
INJ_OUT2
INJ_OUT3
INJ_OUT4
INJ_OUT[1..4]
File: INJ.kicad_sch
AIN.TPS
AIN.IAT
AIN.CLT
AIN.MAP
AIN.OILTEMP1
AIN.OILTEMP2
AIN{TPS IAT CLT MAP OILTEMP1 OILTEMP2}
KnockAmps
VREFD
KNOCK_HP1D
KNOCK_HP2D
KNOCK_OUT2D
KNOCK_OUT1D
KNOCK[1..2]
File: knockamps.kicad_sch
M306
Module-power_12and5V-0.2
V12_RAW
V12_PERM
IN_VIGN
EN_5VP
V12
VBAT
VIGN
V5
5VP
PG_5VP
+12V_RAW
+12V_PERM
+12V_FROM_KEY
JP301
SolderJumper_2_Bridged
D301
1N4148WS
BT301
Battery_Cell
M302
Module-can-0.1
CAN_VIO
CAN_RX
CAN_TX
CANL
CANH
GND
M303
Module-wbo-0.5
V33_OUT
SWCLK
SWDIO
nReset
VDDA
V5_IN
LSU_H-
LSU_H+
LSU_Rtrim
LSU_Ip
LSU_Vm
LSU_Un
PULL_UP1
SEL1
PULL_DOWN1
PULL_UP2
SEL2
PULL_DOWN2
Power GND
Heater negative
Internal TC2030 connector
Analog/digital GND
LSU.H+
LSU.Rtrim
LSU.Ip
LSU.Vm
LSU.Un
LSU{H+ Rtrim Ip Vm Un}
M304
Module-lin-0.1
12V
5V
UART_RX
UART_TX
LIN
J301
USB_B
VBUS
D+
D-
GND
Shield
GNDND
Sheet: /rusefi/
File: rusefi.kicad_sch
Title:
Size: A3
Date:
Rev:
KiCad E.D.A. 8.0.8
Id: 3/6

Remove R20-R22, R26-R28, and install Q7-Q12 for use with dumb coils




rusEFI.com

Sheet: /rusefi/Ignition/
File: IGN.kicad_sch

**Title: UAEFI**

| Size: A4 | Date: 2024-08-15 | **Rev: D** |
|---|---|---|
| KiCad E.D.A. 8.0.8 | | Id: 4/6 |




| | | |
|---|---|---|
| **rusEFI.com** | | |
| Sheet: /rusefi/Injection/<br>File: INJ.kicad_sch | | |
| ***Title: UAEFI*** | | |
| Size: A4 | Date: 2024-08-15 | **Rev: D** |
| KiCad E.D.A. 8.0.8 | | Id: 5/6 |




| | | |
|---|---|---|
| Sheet: /rusefi/KnockAmps/ | | |
| File: knockamps.kicad_sch | | |
| **Title:** | | |
| Size: A4 | Date: | **Rev:** |
| KiCad E.D.A. 8.0.8 | | Id: 6/6 |