

SkillSync X200 User Manual (Fixture)

The SkillSync X200 is a fictional bench-top controller used only as a sample for this project. Any resemblance to a real product is coincidental.

Overview

The X200 reads sensor input over a serial bus and reports status through three LEDs: power, link, and fault.

Installation

The X200 requires a host computer running the SkillSync Console, version 4 or later, and a free USB-C port capable of supplying 500 mA. Mount the unit on a flat, grounded surface.

Configuration

Assign a static address in the 192.168.50.0/24 range from the Console's device list. Run the guided calibration wizard once per sensor; values are stored on the unit itself.

Troubleshooting

If the link LED never turns solid, confirm the static address does not collide with another device on the same subnet, then hold the control button for five seconds to reboot.