TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
No suction	Pump not turned on.	Turn pump on.
	Pump not running.	Call your authorized Air Techniques dealer for repair service.
	Vaccum lines reversed.	Check hose connections to Separator Tank. Hose from vacuum pump inlet must be connected to swivel tee fitting on a CAS™ Tank.
	Kinked or collapsed suction hose.	Check the suction line from the unit to the Separation Tank and the Separation Tank to the opertory line. If clogged, collapsed or kinked call your authorized Air Techniques dealer for repair service.
	CAS™ Separator Tank full.	Shut unit "OFF" for 2 minutes then turn back "ON".
	CAS™ Separator Tank is full and will not drain.	*SEE BELOW.*
CAS™Separator Tank is full and will not drain.	· · · · · · · · · · · · · · · · · · ·	*SEE BELOW.* If Tank is not connected to an open or vented drain, call your authorized Air Techniques dealer for repair or service.
Tank is full and	will not drain. Separator Tank must be connected to an open or	If Tank is not connected to an open or vented drain, call your authorized Air Techniques dealer for repair or service. Call your authorized Air Techniques dealer
Tank is full and	will not drain. Separator Tank must be connected to an open or vented drain. Check valve located in the drain (after Guardian Amalgam Collector	If Tank is not connected to an open or vented drain, call your authorized Air Techniques dealer for repair or service. Call your authorized Air Techniques dealer
Tank is full and	will not drain. Separator Tank must be connected to an open or vented drain. Check valve located in the drain (after Guardian Amalgam Collector	If Tank is not connected to an open or vented drain, call your authorized Air Techniques dealer for repair or service. Call your authorized Air Techniques dealer for a replacement, or service. If check valve is NOT stuck, see other
Tank is full and	will not drain. Separator Tank must be connected to an open or vented drain. Check valve located in the drain (after Guardian Amalgam Collector Outlet) clogged or stuck closed.	If Tank is not connected to an open or vented drain, call your authorized Air Techniques dealer for repair or service. Call your authorized Air Techniques dealer for a replacement, or service. If check valve is NOT stuck, see other possible causes below. Call your authorized Air Techniques dealer

TROUBLE SHOOTING

Poor or low suction Restricted air exhaust. Check air exhaust pipe to make sure it

conforms to specs. Check and clear possible restrictions in exhaust line.

Restricted air suction. Check the suction line from the unit to the

Separation Tank and the Separation Tank to the opertory line. If clogged, collapsed kinked call your authorized Air Techniques

dealer for repair service.

Relief valve set low or stuck

open.

Call your authorized Air Techniques dealer

to readjust setting.

Excessive suction Relief valve set high or stuck

closed.

Call your authorized Air Techniques dealer

for repair service.

Relief valve screen clogged. Call your authorized Air Techniques

dealer for repair service.