

Pi-Ager install on Raspberry Pi 3/Pi 4/Pi 5/Pi zero (2)w under Pi OS 12 Lite bookworm

- **For all Pi:**

Download and install Raspberry Pi Imager v1.8.4 or later.

Start Raspberry Pi Imager, then select:

Raspberry Pi Device:

NO FILTERING

Operating System:

Raspberry Pi OS Lite (32-bit) (A port of Debian Bookworm with no desktop environment)


Storage:

Use an USB Reader and choose your SD-Card, min. 8 GB

Then click 'NEXT'

In popup Window 'Use OS customisation' select 'EDIT SETTINGS'.

In the 'GENERAL' Tab edit your settings:




The screenshot shows the 'OS Customisation' window with the 'GENERAL' tab selected. The window has three tabs: 'GENERAL', 'SERVICES', and 'OPTIONS'. The 'GENERAL' tab contains several settings:

- ☒ Set hostname: RaspberryPi.local
- ☒ Set username and password
 - Username: pi
 - Password: [masked]
- ☒ Configure wireless LAN
 - SSID: [masked]
 - Password: [masked]
 - ☐ Show password ☐ Hidden SSID
 - Wireless LAN country: DE
- ☒ Set locale settings
 - Time zone: Europe/Berlin
 - Keyboard layout: de

A red 'SAVE' button is located at the bottom center of the window.

In the 'SERVICES' Tab enable SSH:



Then 'SAVE' and apply OS customisation settings with 'YES'.

The customized OS is now written to your SD-Card.

Put your SD-Card in your Raspberry Pi and power on your Pi device.

Login via SSH (e.g. use PuTTY) or connect a HDMI monitor and USB keyboard to your Raspberry device and continue with the setup as described below.

- To allow root login:
In /etc/ssh/sshd_config : remove # from PermitRootLogin and replace prohibit-password to yes. Then restart ssh server: `sudo service ssh restart`
Set your root password with: `sudo passwd root`
- Run raspi-config and disable login shell on serial port and enable serial port
- Edit config.txt in /boot/firmware to support I2C and SPI devices:

CAUTION: If you want to edit config.txt ,cmdline.txt and setup.txt under Windows in a Terminal Window, e.g. using Terminal Apps like PuTTY, the Linux folder /boot/firmware on

the SD-Card is mapped to a windows partition FAT32 USB Drive named bootfs and contains the above mentioned files.

```
# Additional overlays and parameters are documented /boot/overlays/README
# Use Pi-Ager Pins 11/13 GPIO 17/27 for I2C
dtoverlay=i2c-gpio,bus=3,i2c_gpio_sda=17,i2c_gpio_scl=27
# Use Pi-Ager Pin 16 for MCP3204
dtoverlay=spi1-1cs,cs0_pin=16
```

at the end of config.txt add the following lines to support bluetooth and Nextion TFT displays via serial port /dev/serial0 :

```
[all]
enable_uart=1
dtoverlay=miniuart-bt
dtparam=uart0=on
# force_turbo=1
```

- Add in /boot/firmware/cmdline.txt at the end of line this to enable USB camera with fswebcam :
`fsck.mode=force dwc_otg.fiq_fsm_mask=0x3`
- Reboot system
- Edit /etc/modules to load i2c-dev at boot, add this line :
`i2c-dev`
- Add file :
`sudo touch /etc/modprobe.d/raspi-blacklist.conf`
- Install git: `sudo apt install git`
- Get a copy from Pi-Ager repository to your local system:
`git clone --depth=1 -b master https://github.com/Tronje-the-Falconer/Pi-Ager`
All project file are now in the folder ./Pi-Ager/
Change working directory to Pi-Ager
`cd Pi-Ager`
- Copy setup.txt from local repository to /boot/ and edit it as needed:
`sudo cp ./boot/firmware/setup.txt /boot/firmware/`
- Reboot system
- Update system:
`sudo apt-get update`
`sudo apt-get upgrade`
- Install php 8:
`sudo apt install php-fpm php-cli`
`sudo apt install php`
`sudo apt install php-common php-sqlite3`
- Install additional modules for php:

```
sudo apt install php-mbstring php-zip php-curl
```

- Install lighttpd:

```
sudo apt-get install lighttpd  
sudo systemctl status lighttpd
```

```
sudo nano /etc/lighttpd/lighttpd.conf  
and change/add Parameter
```

```
server.document-root = "/var/www/html"  
to  
server.document-root = "/var/www"  
add "mod_auth" to server.modules list  
add "mod_authn_file" to server.modules list  
Save and close nano
```

```
/*----- not used -----*/
```

To enable PHP8 in Lighttpd, we must modify `/etc/php/8.2/fpm/php.ini` and uncomment the line `cgi.fix_pathinfo=1`. In my `php.ini` file, I found it on line 807. To uncomment, just remove the semicolon in the beginning.

```
/*-----*/
```

```
sudo usermod -G www-data -a pi  
sudo chown -R www-data:www-data /var/www  
sudo chmod -R 755 /var/www
```

- Reboot system

For testing the web server, generate html-page:

```
sudo nano /var/www/test.html  
with content:
```

```
<html>  
<head><title>Test-Seite</title></head>  
<body>  
<h1>Das ist eine Test-Seite.</h1>  
</body>  
</html>
```

Change owner: `sudo chown www-data:www-data /var/www/test.html`

Enter your IP Address into the browser followed by `/test.html`

In addition we need `.htcredentials` to contain user and password.

For that we use the Online-Tool <https://websistent.com/tools/htdigest-generator-tool/>

Username: pi-ager

REALM: Pi-Ager

Password: raspberry

Caution! All entries are case sensitive!

Open this file now

```
sudo nano /var/.htcredentials
```

and fill in the string output from the generator tool.

Save file with “STRG+o”, “RETURN” and close with “STRG+x”

Now we have to setup the password authentication in lighttpd:

```
sudo nano /etc/lighttpd/conf-available/05-auth.conf
```

The following lines are added under `server.modules += („mod_auth“)` :

```
auth.backend          = "htdigest"
auth.backend.htdigest.userfile = "/var/.htcredentials"
```

```
auth.require          = ( "/settings.php" =>
(
    "method" => "digest",
    "realm" => "Pi-Ager",
    "require" => "user=pi-ager"
),
"/admin.php" =>
(
    "method" => "digest",
    "realm" => "Pi-Ager",
    "require" => "valid-user"
),
"/webcam.php" =>
(
    "method" => "digest",
    "realm" => "Pi-Ager",
    "require" => "valid-user"
),
"/notification.php" =>
(
    "method" => "digest",
    "realm" => "Pi-Ager",
    "require" => "valid-user"
)
)
```

Then we activate this modul:

```
sudo lighty-enable-mod auth
```

In addition we have to edit :

```
sudo nano /etc/lighttpd/conf-available/15-fastcgi-php-fpm.conf
```

Add “broken-scriptfilename” and “x-sendfile” :

```
fastcgi.server += ( ".php" =>
((
    "socket" => "/run/php/php-fpm.sock",
```

```
        "broken-scriptfilename" => "enable",
        "x-sendfile" => "enable"
    ))
)
```

save and close nano

Now enable these modules:

```
sudo lighty-enable-mod fastcgi-php-fpm
```

Now reload the the webserver:

```
sudo service lighttpd force-reload
```

Now continue to install additional modules:

- Install smbush

```
sudo apt-get install python3-smbus2
```
- Install sqlite3:

```
sudo apt install sqlite3
```
- Install pip3

```
sudo apt install python3-pip
```

CAUTION :

```
sudo pip3 install <module>
```

 no longer supported.

If you see an error message, try to install the module with

```
sudo apt install python3-<module name>
```

. If this does not work, try install modules with

```
sudo pip3 install <module name> --break-system-packages
```

```
error: externally-managed-environment
```

```
× This environment is externally managed
```

```
↳ To install Python packages system-wide, try apt install
python3-xyz, where xyz is the package you are trying to
install.
```

If you wish to install a non-Debian-packaged Python package,
create a virtual environment using `python3 -m venv path/to/venv`.
Then use `path/to/venv/bin/python` and `path/to/venv/bin/pip`. Make
sure you have `python3-full` installed.

If you wish to install a non-Debian packaged Python application,
it may be easiest to use `pipx install xyz`, which will manage a
virtual environment for you. Make sure you have `pipx` installed.

See `/usr/share/doc/python3.11/README.venv` for more information.
note: If you believe this is a mistake, please contact your Python
installation or OS distribution provider. You can override this, at the
risk of breaking your Python installation or OS, by passing `--break-system-
packages`.
hint: See PEP 668 for the detailed specification.

- Install SHT1x sensors
`sudo pip3 install pi-sht1x --break-system-packages`
- Install libgd-dev (needed for new version of fswebcam)
`sudo apt install libgd-dev`
- Install openssl dev package
`sudo apt install libssl-dev`
- Install fswebcam:
`sudo apt install fswebcam`
- Install cryptography
`sudo apt install python3-cryptography`
- Install uuidgen
`sudo apt install uuid-runtime`
- Install wiringpi new version with Pi 5 support :
`cd /tmp`
`sudo apt purge wiringpi`
`wget`
https://github.com/phylax2020/WiringPi/releases/download/3.16/wiringpi_3.16_armhf.deb
`sudo apt install ./wiringpi_3.16_armhf.deb`
- Install RPi.GPIO new version with support for RPi 5
`cd /tmp`
`sudo apt purge python3-RPi.GPIO` or
`sudo pip3 uninstall RPi.GPIO --break-system-packages`
`wget` https://github.com/phylax2020/RPi.GPIO/releases/download/v0.8.6/python3-rpi.gpio_0.8.6-1_armhf.deb
`sudo apt install ./python3-rpi.gpio_0.8.6-1_armhf.deb`
- Nextion serial client (HMI Display support)
`sudo pip3 install nextion --break-system-packages`
`sudo pip3 install pyserial-asyncio --break-system-packages`
- Install lsof command:
`sudo apt install lsof`
- Install Locale en-GB and de-DE UTF-8 using
`sudo raspi-config`
- Enable Serial Interface, disable login, needed for HMI Nextion Display
`sudo raspi-config`
- Install zip and unzip:
`sudo apt install zip unzip`
- Install schedule

sudo apt install python3-schedule


- Install MQTT client

sudo apt install python3-paho-mqtt

- Unblock wifi for Pi4, add rfkill unblock wifi and disable power management for wlan0:

cd /etc

sudo nano rc.local



```
pi@pi-ager: ~
GNU nano 7.2 /etc/rc.local
#!/bin/sh -e
#
# rc.local
#
# This script is executed at the end of each multiuser runlevel.
# value on error.
#
# In order to enable or disable this script just change the execution
# bits.
#
# By default this script does nothing.
#
# Print the IP address
_IP=$(hostname -I) || true
if [ "$_IP" ]; then
    printf "My IP address is %s\n" "$_IP"
fi
# start pi-ager
systemctl start pi-ager_main.service

# disable power management for wlan0 to increase WLAN reliability
rfkill unblock wifi
sleep 1
# iwconfig wlan0 power off
iw wlan0 set power_save off

# enable AP-STA mode
iw dev wlan0 interface add wlan1 type __ap
sleep 1

iw wlan1 set power_save off

# enable captive portal
nodogsplash

exit 0

[ 36 Zeilen gelesen ]
^G Hilfe      ^O Speichern ^W Wo ist     ^K Ausschneid^T Ausführen  ^C Position
^X Beenden    ^R Datei öffn^_ Ersetzen   ^U Einfügen  ^J Ausrichten^/ Zu Zeile
```

Then change protection and owner:

sudo chown root:root /etc/rc.local

sudo chmod +x /etc/rc.local

- Only if wanted: Generate/edit crontab to prepare for automatic enable pi-ager_backup.sh

```
pi@pi-ager:~$ sudo crontab -l
#-----
# Shell variable for cron
SHELL=/bin/bash
# PATH variable for cron
PATH=/usr/local/bin:/usr/local/sbin:/sbin:/usr/sbin:/bin:/usr/bin:/usr/bin/X11
#M S T M W Befehl
#-----
#* */6 * * * /usr/bin/flock -w 0 /var/run/pi-ager_backup.pid /usr/local/bin/pi-ager_backup.sh >> /var/log/pi-ager_backup
.log 2>&1
#*/2 * * * * logger "greetings from the crontab" > /dev/null 2>&1
```

- Use visudo to edit /etc/sudoers, so that the www-data User (User of Website) can execute /var/sudowebscript.sh :

`sudo visudo`

and then in sudoers following

...

#User privilege specification

root ALL=(ALL:ALL) ALL

...

adding:

`www-data ALL=NOPASSWD:/var/sudowebscript.sh, /var/show_wifi_connections.sh,
/var/updatessid.sh,/usr/bin/raspi-config,/usr/bin/nmcli`

Save and exit.

- Install access point with network manager:
Copy from repository /usr/local/bin/setup_pi-ager-ap.sh to destination.

Create virtual interface wlan1:

`sudo iw dev wlan0 interface add wlan1 type __ap`

then run script :

`cd /usr/local/bin`


`sudo ./setup_pi-ager-ap.sh`

- Install nodogsplash captive portal
`sudo apt install iptables`
`sudo apt install libmicrohttpd-dev`
`cd ~`
`git clone https://github.com/nodogsplash/nodogsplash.git`
`cd ./nodogsplash`
`make`
`sudo make install`
copy all from repository /etc/nodogsplash to /etc/nodogsplash
`sudo chmod +x /usr/bin/nodogsplash`
`sudo chmod +x /usr/bin/ndsctl`

- Install Bluetooth modules to support Bluetooth Temp./Hum Sensor from Xiaomi

- `sudo apt install libglib2.0-dev`
- `sudo pip3 install bluepy requests --break-system-packages`
- `sudo apt install bluetooth libbluetooth-dev`
- `# sudo pip3 install pybluez pycryptodomex`
- Patch btle.py to stop intermittend errors:

File : /usr/local/lib/python3.11/dist-packages/bluepy/btle.py :



```

288 def _stopHelper(self):
289     if self._helper is not None:
290         DBG("Stopping ", helperExe)
291         self._poller.unregister(self._helper.stdout)
292         self._helper.stdin.write("quit\n")
293         self._helper.stdin.flush()
294         self._helper.wait()
295         time.sleep(0.1) # patch to avoid failed to execute managment command 'scanned' (code: 11, error: Rejected)
296         self._helper = None
297     if self._stderr is not None:
298         self._stderr.close()
299         self._stderr = None

```

- Now copy all files and folders from your local git repository /var/www to /var/www/
- from local repository /opt/pi-ager/ to /opt/pi-ager/

- from local repository /var/sudowebscript.sh to /var/
- `sudo chown -R www-data:www-data /var/www`
- `sudo usermod -G gpio -a www-data`
- `sudo chmod 666 /var/www/logs/logfile.txt`
- `sudo chmod 755 /var/www/logs/`
- `sudo chmod 664 /var/www/config/pi-ager.sqlite3`
- `sudo chown -R www-data:www-data /var/www/config/`
- `sudo chmod 777 /var/www/config/`
- `sudo chmod 555 /var/sudowebscript.sh /var/updatessid.sh /var/show_wifi_connections.sh`
- from local repository /usr/local/bin/*.sh copy all to /usr/local/bin/ (pi-ager_backup.sh, pi-ager_image.sh, setup_pi-ager.sh)
Set +x mode to the scripts :
`sudo chmod +x /usr/local/bin/*.sh`
- Bluetooth sensor: Make ATC_XXXXXX.py executable
`sudo chmod +x /opt/ATC_MiThermometer/ATC_XXXXXX.py`
- from local repository /lib/systemd/system copy the following files to /lib/systemd/system/ :
`pi-ager_main.service`
`setup_pi-ager.service`
Then reload these services:
`sudo systemctl daemon-reload`
- from local repository /usr/bin copy the following file to /usr/bin/. This is a newer version of fswebcam with re-get frame on error.
`fswebcam`
Set +x mode to fswebcam:
`sudo chmod +x /usr/bin/fswebcam`
- from local repository /usr/share/man/man1/fswebcam.1.gz copy the following file to /usr/share/man/man1/
`fswebcam.1.gz`
- enable setup_pi-ager.service to start only once after reboot
`sudo systemctl enable setup_pi-ager.service`
- Restart system
`sudo reboot`

How to generate and deploy Pi-Ager Images

There are some steps to do for generating and deploying a new image from a running Pi-Ager system:

1. Setup a NFS Server to store a new image. The best way is using a Raspi 4B or 5 equipped with an USB Memory stick with 128GB or more. Using RPi 5 it is now possible to add a NVME SSD so that there will be enough space for storing one or more images.
2. On the NFS Server System Install Pi Power Tools using the well-known Pi-Apps.
3. On the Pi-Ager setup and start an Image backup on the ADMIN page. For example :

BACKUP

nfs Verzeichnis:	192.168.0.238:/home/public/pi-ager-v400-noshrink
Anzahl Backups:	3
Backup Name:	PiAgerBackup
nfs Option:	nosuid,nodev
Backup Aktiv:	☒

Speichern
Backup manuell
pi-ager_backup.log in einem neuen Tab öffnen

Hilfe

- Next start a terminal on the Pi-Ager and start the pi-ager_image.sh script with option -l:

```

pi@pi-ager: /usr/local/bin

pi@pi-ager:~ $ cd /usr/local/bin/
pi@pi-ager:/usr/local/bin $ sudo pi-ager_image.sh -l
Backup ist inaktiv. Pi-Ager_image wird gestartet!
Überprüfe ob der NFS-Server vorhanden ist.
Checking...
192.168.0.238:/home/public/pi-ager-v400-noshrink ist vorhanden
Überprüfe ob Backup Pfad vorhanden ist.
Checking ...
/home/nfs/public ist vorhanden
Überprüfe ob NFS Mount point definiert ist.
Checking ...
/home/nfs/public ist definiert
Überprüfe ob NFS Mount point im file system angelegt ist.
Checking...
/home/nfs/public ist angelegt
NFSVOL=192.168.0.238:/home/public/pi-ager-v400-noshrink
NFSPATH=/home/nfs/public
NFSMOUNT=/home/nfs/public
umount: /home/nfs/public: not mounted.
hänge NFS-Volume 192.168.0.238:/home/public/pi-ager-v400-noshrink ein
mount with options: nosuid,nodev
mount NFS-Volume 192.168.0.238:/home/public/pi-ager-v400-noshrink successfull. Image script continues
.
Load last backup file.
Backup path is /home/nfs/public
Backup file is /home/nfs/public/PiAgerBackup_2024-02-12-103529.img
Backup path with file is /home/nfs/public/PiAgerBackup_2024-02-12-103529.img
Source File = /home/nfs/public/PiAgerBackup_2024-02-12-103529.img
do_copy = false
my image = false
Using /home/nfs/public/PiAgerBackup_2024-02-12-103529.img as source and target
#####
parted output = 2:541065216B:15931539455B:15390474240B:ext4::;
partnum = 2
partstart = 541065216
loopback = /dev/loop0
#####
parted_output boot = 1:4194304B:541065215B:536870912B:fat32::lba;
partnum_boot = 1
partstart_boot = 4194304
loopback_boot = /dev/loop1
#####
mount directory is /tmp/tmp.SfM3akt9CW
2024-02-12 10:39:10 URL:https://raw.githubusercontent.com/Tronje-the-Falconer/Pi-Ager/entwicklung/boo
t/firmware/setup.txt [3281/3281] -> "setup.txt" [1]
setup.txt copied to /tmp/tmp.SfM3akt9CW/boot/
cmdline.txt modified, added init=/usr/lib/raspberrypi-sys-mods/firstboot
rematch1 /tmp/
rematch2 tmp.SfM3akt9CW
change rootdir is tmp.SfM3akt9CW
/tmp
pi-ager_main.service disabled, will be enabled during setup_pi-ager.sh
Created symlink /etc/systemd/system/multi-user.target.wants/setup_pi-ager.service -> /lib/systemd/system/setup_p
i-ager.service.
setup_pi-ager service enabled
Running in chroot, ignoring command 'is-active'
hostname changed to pi-ager
unmount /tmp/tmp.SfM3akt9CW/boot
unmount /tmp/tmp.SfM3akt9CW
Detaching loop devices from /home/nfs/public/PiAgerBackup_2024-02-12-103529.img
The image /home/nfs/public/PiAger_image_2024-02-12-103940.img was successfully created.
pi@pi-ager:/usr/local/bin $

```

- Zip and deploy your new image.