

FR350SDJ Rear Helper Spring Kit Installation Manual

Please read these instructions carefully before starting the installation. Ensure all standard safety precautions are observed while working underneath the vehicle.

1. Parts List

Before beginning, verify that all components listed below are present in your kit.

Ref #	Description / Specifications	Qty
1	Weldment Bracket (Left-Hand & Right-Hand)	1L - 1R
2	Hollow Rubber Spring	2
3	Rubber Spacer (4" O.D. x 1/2" Thick with P Bushing)	2
4	Hex Cap Screw (HCS) M10 x 50 x 1.5 FT Gr 8.8 Z	2
5	Shim (1-3/8" L x 1/8" W x 1/32" T x 5/8" Slot)	4

2. Installation Instructions

1. Raise Vehicle: Raise the vehicle using an appropriate hoist or jack, allowing the axle to hang freely. Securely support the chassis before proceeding with any work.

2. Remove Bump Stop: Remove the existing original equipment manufacturer (OEM) bump stop assembly. Retain the original mounting hardware for later use.

3. Assemble Helper Spring Unit: Assemble the hollow rubber spring and weldment bracket. The included 1/2" rubber spacer may be installed between the spring and bracket only when additional installed height is needed for proper clearance. Secure the assembly using the M10 x 50 hex cap screw. Repeat for the opposite side.

4. Mount Assembly: Mount each assembled helper spring unit to the vehicle frame using the existing mounting holes. Utilize the retained OEM fasteners and the provided shims as necessary to achieve proper alignment and fitment.

5. Lower Vehicle: Carefully lower the vehicle back to the ground.

Installation Notes:

- Verify that brake lines or cables do not interfere with the helper spring assembly, especially during full suspension travel.
- If the vehicle's original equipment includes a peg-style casting, the helper spring is designed to make direct contact with this component. Do not remove the OEM peg.

3. Clearance Instructions & Fitting Guidance

- **Clearance:** Depending on vehicle configuration, the rubber spring may have a small clearance or light contact when the vehicle is unloaded.
- **Ride Comfort:** A small amount of clearance may help maintain a more comfortable unloaded ride. Light contact may also be normal on this application.
- **Spacer Use:** Use the included **1/2" spacer** when unloaded clearance is noticeably excessive, such as on some leveled or lifted vehicles. If a small clearance or light contact already exists, the spacer may not be needed. Avoid excessive preload.
- **Load Effects:** A partial load, cargo, or aftermarket vehicle accessories may reduce or eliminate any initial clearance.

Important Safety Warnings:

- Do not exceed the vehicle manufacturer's recommended axle weight rating / GAWR.
- Inspect for potential interference between the hollow rubber spring and adjacent vehicle components. Under load, the rubber spring will expand in diameter.

INSTALLATION DIAGRAM

