

GMRCK25D Rear Helper Spring Kit Installation Manual

Model: GMRCK25D (Rear Suspension Package)

Please read these instructions carefully before starting the installation. Ensure all standard safety precautions are observed while working underneath the vehicle.

1. Parts List

Before beginning, verify that all components listed below are present in your kit.

Ref #	Description / Specifications	Qty
1	Hollow Rubber Spring	2
2	Rubber Locator / Spacer (3.36" O.D. x 1" Thick)	2

2. Installation Instructions

- 1. Raise Vehicle:** Elevate the vehicle using an appropriate lift or jack, ensuring the axle is fully extended and hangs freely. Support the chassis securely before proceeding.
- 2. Remove OEM Bump Stop:** Carefully remove the existing factory bump stop by prying it out of its mounting cup.
- 3. Position Spring Assembly:** Insert the helper spring assembly into the bump stop cup. The assembly consists of the hollow rubber spring and its locator.
- 4. Lubricate and Seat Assembly:** Apply a small amount of soapy water to the helper spring assembly. Position it into the bump stop cup, then push and twist simultaneously to fully seat the assembly.
- 5. Verify Seating:** Confirm that the helper spring assembly is securely and correctly seated within the bump stop cup.
- 6. Ensure Full Seating (Optional):** To aid in fully seating the helper spring assembly, a temporary spacer such as a short 2x4 wood block may be placed between the axle and the spring assembly. Carefully lower the vehicle onto the temporary spacer, then raise the vehicle again and remove it.
- 7. Final Lowering:** Gently lower the vehicle completely to the ground.

Installation Notes:

- To ensure proper seating, a temporary 2x4 wood block may be used between the axle and the spring assembly during installation. Remove the temporary block before driving.
- The supplied rubber locator / spacer (Ref 2) is part of the spring assembly and is not an optional gap-adjustment spacer. Keep it installed as designed.

3. Clearance Instructions & Fitting Guidance

- Recommended Clearance:** With the vehicle unloaded and at normal ride height, approximately **1/2" to 1-1/2" (13-38 mm)** of clearance between the rubber spring and its contact point is recommended.
- Excessive Clearance:** A leveling kit, suspension lift, or other ride-height modification may increase the clearance. Excessive clearance may cause the helper spring to engage later, reducing its effectiveness in controlling sag and sway.
- Insufficient Clearance:** Too little clearance or excessive preload may cause the helper spring to engage too early and may result in a firmer unloaded ride.
- Under Load:** Cargo, accessories, or vehicle load may reduce or eliminate the clearance as the helper spring engages.
- Note:** Actual clearance may vary depending on vehicle configuration, ride height, suspension condition, and load. If the unloaded clearance is significantly outside the recommended range, verify vehicle ride height, suspension modifications, load condition, and correct installation.

Important Safety Warnings:

- Do not exceed the vehicle manufacturer's recommended axle weight rating / GAWR.
- Inspect for potential interference between the hollow rubber spring and adjacent vehicle components. Under load, the rubber spring will expand in diameter.

Note: Illustrations are for reference only. Vehicle configuration and actual component appearance may vary. Install according to the vehicle-specific mounting points and standard mechanical practices.