

DR2500CA Rear Helper Spring Kit Installation Manual

Model: DR2500CA (Rear Suspension Package)

Please read these instructions carefully before starting the installation. Ensure all standard safety precautions are met while working underneath the vehicle.

1. Parts List

Before beginning, verify that all components listed in the table below are present in your kit.

Ref #	Description / Specifications	Qty
1	Weldment Bracket (Left-Hand & Right-Hand)	1L - 1R
2	Rubber Spacer (4" O.D. x 1" Thick with AH Bushing)	2
3	Hollow Rubber Spring	2
4	Hex Cap Screw (HCS) 3/8" x 1-3/4" UNC Gr 5 Z	2
5	Hex Cap Screw (HCS) 3/8" x 2-3/4" UNC Gr 5 Z	2

2. Installation Instructions

- 1. Raise Vehicle:** Raise the vehicle using an appropriate hoist or jack, allowing the axle to hang freely. Support the chassis securely before proceeding.
- 2. Remove Bump Stop:** Remove the existing OEM vehicle bump stop.
- 3. Assemble Springs:** Assemble the hollow rubber spring and bracket.
- 4. Mount Assembly:** Mount the complete assembly to the vehicle frame using the OEM fasteners.
- 5. Lower Vehicle:** Lower the vehicle back to the ground.

Installation Notes:

- Rubber spacer (Ref. 2) and hex cap screw (Ref. 5) may be utilized to achieve a specific ride height.
- When disassembling OEM fasteners, the application of penetrating fluid is highly recommended.

3. Clearance Instructions & Fitting Guidance

- **Clearance Gap:** For rear helper spring installations on light-duty trucks and vans, an optimal clearance of 1/2" to 1-1/2" should be maintained between the rubber spring and the vehicle's contact point when the vehicle is unladen.
- **Load Effects:** The presence of a partial load, cargo, or aftermarket vehicle accessories will diminish or eliminate this specified clearance.
- **Heavy-Duty Applications:** For medium and heavy-duty trucks, trailers, and motorhomes, the helper spring assembly is designed for continuous contact, thus no clearance gap is expected.

Important Safety Warnings:

- The vehicle manufacturer's recommended axle weight rating must not be exceeded.
- Inspect for potential interference between the hollow rubber spring and adjacent vehicle components. Under load conditions, the rubber spring's diameter will increase.

Note: Illustrations are for reference only. If no specific reference image is provided, please install according to the standard mechanical guidelines.