

FR250SDJ Rear Helper Spring Kit Installation Manual

Model: FR250SDJ (Rear Suspension Package)

Please read these instructions carefully before commencing the installation process. Ensure all standard safety protocols are observed when working beneath the vehicle.

1. Parts List

Before beginning, verify that all components listed in the table below are present in your kit.

Ref #	Description / Specifications	Qty
1	Suspension Bracket Weldment	2
2	Hollow Rubber Spring	2
3	Hex Cap Screw (HCS) M10 x 40 x 1.5 Gr 8.8 Z	2
4	Shim 1-3/8" L x 1/8" W x 1/32" T with 5/8" Slot	4

2. Installation Instructions

1. Remove OEM Bump Stop: Remove the existing original equipment manufacturer (OEM) bump stop assembly. Retain any OEM fasteners for subsequent re-installation.

2. Assemble Helper Spring Unit: Assemble the hollow rubber spring onto the suspension bracket weldment.

3. Install Helper Spring Unit: Mount the assembled helper spring unit to the vehicle frame. Utilize the existing mounting holes and the retained OEM fasteners or supplied shims as necessary.

Installation Notes:

- Verify that vehicle brake lines or cables do not interfere with the helper spring's position or operation.
- If the vehicle's original equipment includes a peg-style casting, the helper spring is engineered to contact this peg. Do not remove the OEM peg.

3. Clearance Instructions & Fitting Guidance

- Clearance Gap: Rear helper spring kits for light-duty trucks and vans should maintain a clearance gap of 1/2 inch to 1-1/2 inches between the rubber spring and its contact point when the vehicle is unladen.
- Load Effects: The presence of a partial load, cargo, or vehicle accessories will reduce or eliminate this initial clearance gap.
- Heavy-Duty Applications: For medium and heavy-duty trucks, trailers, and motorhomes, the helper springs are designed for constant contact with no clearance gap.

Important Safety Warnings:

- Do not exceed the vehicle manufacturer's recommended axle weight rating.
- Inspect for potential interference between the hollow rubber spring and other vehicle components. Under load, the rubber spring's diameter will expand.

Note: Illustrations are for reference only. If no specific reference image is provided, please install according to the standard mechanical guidelines.