

GMFK15A Front Helper Spring Kit Installation Manual

Model: GMFK15A (Front Suspension Package)

Please read these instructions carefully before commencing installation. Ensure all standard safety protocols are observed when working beneath the vehicle.

1. Parts List

Before beginning, verify that all components listed in the table below are present in your kit.

Ref #	Description / Specifications	Qty
1	Spring Locator Bracket	2
2	Beveled Washer	2
3	Spacer Disc (2.5" OD x 13/32" ID x 3/16" THK)	2
4	Hollow Rubber Spring	2
5	Socket Head Cap Screw (M10 x 35mm, 1.5 pitch, Grade 8.8)	2

2. Installation Instructions

- 1. Raise Vehicle:** Elevate the vehicle using an appropriate lift or jack, ensuring the front axle hangs freely. Secure the chassis with stands before proceeding.
- 2. Remove OEM Bump Stop:** Carefully remove the existing factory bump stop from its mounting cup, typically by prying it out.
- 3. Adjust Suspension Components (Optional):** If necessary, loosen and then re-tighten the upper shock absorber mounting bolts to facilitate additional control arm separation, which may aid in the installation of the helper spring assembly.
- 4. Install Helper Spring Assembly:** Position the pre-assembled helper spring unit (comprising the hollow rubber spring, spacer disc, beveled washer, and locator bracket) into the bump stop mounting cup. Apply simultaneous pushing and twisting force until the assembly is fully seated. Verify that the beveled washer is oriented with its thinner edge tapering towards the vehicle frame.
- 5. Lower Vehicle:** Carefully lower the vehicle to the ground.

Installation Notes:

- Apply thread-locking compound to the M10 x 35mm socket head cap screws (Ref. 5) during assembly.

3. Clearance Instructions & Fitting Guidance

- **Clearance Gap:** Front helper spring kits are typically designed for constant contact with the suspension components when the vehicle is at rest.
- **Load Effects:** The presence of a partial load, cargo, or aftermarket vehicle accessories will maintain or increase the compression of the helper springs.

Important Safety Warnings:

- Do not exceed the vehicle manufacturer's recommended Gross Axle Weight Rating (GAWR).
- Check for potential interference between the helper spring and other vehicle components. Under load, the rubber spring will expand in diameter.

Note: Illustrations are for reference only. If no specific reference image is provided, please install according to the standard mechanical guidelines.