

GMRCK15S Rear Helper Spring Kit Installation Manual

Model: GMRCK15S (Rear Suspension Package)

Please read these instructions carefully before starting the installation. Ensure all standard safety precautions are met while working underneath the vehicle.

1. Parts List

Before beginning, verify that all components listed in the table below are present in your kit.

Ref #	Description / Specifications	Qty
1	Hollow Rubber Spring	2
2	Disc Spacer (4" OD x 13/32" ID x 3/16" THK)	2
3	Hex Cap Screw (HCS) (M10 x 60 x 1.5 Gr 8.8 Z)	2
4	Flat Washer (M10 Gr 4.6 Z)	2
5	Nylock Locknut (M10 x 1.5 Gr 8.0 Z)	2

2. Installation Instructions

- 1. Raise Vehicle:** Raise the vehicle using an appropriate hoist or jack, allowing the axle to hang freely. Support the chassis securely before proceeding.
- 2. Remove Bump Stop:** Remove the existing OEM vehicle bump stop assembly. For 2007-On models, a 10mm socket may be required for removal.
- 3. Assemble Components:** Assemble the hollow rubber spring and disc spacer onto the mounting bracket. Refer to the product diagram for correct component orientation.
- 4. Mount Assembly:** Mount the assembled bracket, spring, and spacer to the vehicle frame utilizing the existing mounting holes and the provided hardware (Hex Cap Screw M10 x 60, Flat Washer M10, Nylock Locknut M10).
- 5. Lower Vehicle:** Lower the vehicle back to the ground.

3. Clearance Instructions & Fitting Guidance

- **Clearance Gap:** For light-duty trucks and vans, an ideal clearance of 1/2 inch to 1-1/2 inches should be maintained between the helper spring and the vehicle's contact point when the vehicle is unloaded.
- **Load Effects:** The presence of a partial load, cargo, or aftermarket vehicle accessories will reduce or eliminate this initial clearance gap.
- **Heavy-Duty Applications:** For medium and heavy-duty trucks, trailers, and motorhomes, the helper spring assembly is designed to maintain constant contact with the vehicle's frame, resulting in no clearance gap.

Important Safety Warnings:

- Do not exceed the vehicle manufacturer's recommended axle weight rating.
- Inspect for potential interference between the hollow rubber spring and other vehicle components. Under load conditions, the rubber spring will expand in diameter.

Note: Illustrations are for reference only. If no specific reference image is provided, please install according to the standard mechanical guidelines.