

GMRCK25D Rear Helper Spring Kit Installation Manual

Model: GMRCK25D (Rear Suspension Package)

Please read these instructions carefully before starting the installation. Ensure all standard safety precautions are met while working underneath the vehicle.

1. Parts List

Before beginning, verify that all components listed in the table below are present in your kit.

Ref #	Description / Specifications	Qty
1	Hollow Rubber Spring	2
2	Rubber Locator / Spacer (3.36" O.D. x 1" Thick)	2

2. Installation Instructions

- 1. Raise Vehicle:** Elevate the vehicle using an appropriate lift or jack, ensuring the axle is fully extended and hangs freely. Support the chassis securely before proceeding.
- 2. Remove OEM Bump Stop:** Carefully remove the existing factory bump stop by prying it out of its mounting cup.
- 3. Position Spring Assembly:** Insert the helper spring assembly into the bump stop cup. The assembly typically consists of the hollow rubber spring and its locator.
- 4. Lubricate and Seat Assembly:** Apply a small amount of soapy water to the helper spring assembly. Position it into the bump stop cup, then push and twist simultaneously to fully seat the assembly.
- 5. Verify Seating:** Confirm that the helper spring assembly is securely and correctly seated within the bump stop cup.
- 6. Ensure Full Seating (Optional):** To aid in fully seating the helper spring assembly, a temporary spacer (e.g., a 2x4 wood block) may be placed between the axle and the spring assembly. Carefully lower the vehicle onto the spacer. Then, raise the vehicle again to remove the temporary spacer.
- 7. Final Lowering:** Gently lower the vehicle completely to the ground.

Installation Notes:

- To ensure proper seating of the helper spring assembly, a temporary spacer (e.g., a 2x4 wood block) can be used between the axle and the assembly before lowering the vehicle. The vehicle must then be re-raised to remove the spacer.

3. Clearance Instructions & Fitting Guidance

- **Clearance Gap:** For light-duty trucks and vans, an ideal clearance of 1/2" to 1-1/2" should exist between the helper spring and its contact point when the vehicle is unladen.
- **Load Effects:** The presence of a partial load, cargo, or aftermarket vehicle accessories will reduce or potentially eliminate this initial clearance.
- **Heavy-Duty Applications:** For medium and heavy-duty trucks, trailers, and motorhomes, the helper spring assembly is designed to be in constant contact with no gap.

Important Safety Warnings:

- Do not exceed the vehicle manufacturer's specified Gross Axle Weight Rating (GAWR).

- Check for potential interference between the helper spring and other vehicle components. Under load, the rubber spring material will expand in diameter.

Note: Illustrations are for reference only. If no specific reference image is provided, please install according to the standard mechanical guidelines.