

GMRG25C Rear Helper Spring Kit Installation Manual

Model: GMRG25C (Rear Suspension Package)

Please read these instructions carefully before commencing the installation. Ensure all standard safety protocols are observed when working beneath the vehicle.

1. Parts List

Before beginning, verify that all components listed in the table below are present in your kit.

Ref #	Description / Specifications	Qty
1	Helper Spring Assembly (Hollow Rubber Spring with Locator Bushing, 3-25/64" OD)	2
2	Hex Cap Screw (HCS) 3/8 x 1-3/4 UNF Grade 5 Zinc Plated	2

2. Installation Instructions

1. Raise Vehicle: Elevate the vehicle using a suitable lift or jack, allowing the rear axle to articulate freely. Ensure the chassis is securely supported with appropriate stands before proceeding.

2. Remove OEM Bump Stop: Carefully remove the existing factory bump stop from its mounting cup, typically by prying it out.

3. Install Helper Spring Assembly: Insert the helper spring assembly into the bump stop mounting cup. To facilitate proper seating, a temporary spacer (e.g., a 2x4 wood block) can be placed between the axle and the helper spring assembly. Lower the vehicle slightly onto the spacer to seat the spring, then re-raise the vehicle to remove the spacer.

4. Final Lowering: Carefully lower the vehicle back to the ground.

Installation Notes:

- Ensure the helper spring assembly is fully and correctly seated within the bump stop mounting cup.
- A temporary spacer, such as a wood block, may be used between the axle and the helper spring during installation to aid in proper seating. The vehicle should then be re-raised to remove the spacer.

3. Clearance Instructions & Fitting Guidance

- **Clearance Gap:** For light-duty trucks and vans, an ideal clearance of 1/2 inch to 1-1/2 inches should exist between the helper spring and its contact point when the vehicle is unladen.
- **Load Effects:** The presence of a partial load, cargo, or aftermarket vehicle accessories will diminish or eliminate this specified clearance gap.
- **Heavy-Duty Applications:** For medium and heavy-duty trucks, trailers, and motorhomes, the helper springs are designed for constant contact with no inherent clearance gap.

Important Safety Warnings:

- Do not exceed the vehicle manufacturer's maximum recommended axle weight rating.
- Inspect for any potential interference between the helper spring and surrounding vehicle components. Note that the helper spring's diameter will increase under load.

Note: Illustrations are for reference only. If no specific reference image is provided, please install according to the standard mechanical guidelines.