

GMRTT35D Rear Helper Spring Kit Installation Manual

Model: GMRTT35D (Rear Suspension Package)

Please read these instructions carefully before commencing installation. Ensure all standard safety protocols are observed when working beneath the vehicle.

1. Parts List

Before beginning, verify that all components listed in the table below are present in your kit.

Ref #	Description / Specifications	Qty
1	Hex Cap Screw (M10 x 80 x 1.5, Grade 8.8, Zinc Plated)	2
2	Locator (3.36" Outer Diameter x 1" Thick)	2
3	Rubber Spacer (4" Outer Diameter x 1" Thick, with Bushing)	2
4	Hollow Rubber Spring	2
5	Fender Washer (3/8" x 1-1/2", Grade 2, Zinc Plated)	2
6	Nylock Locknut (M10 x 1.5, Grade 8.0, Zinc Plated)	2

2. Installation Instructions

- 1. Raise Vehicle:** Elevate the vehicle using an appropriate hoist or jack, allowing the axle to hang freely. Secure the chassis with appropriate stands before proceeding.
- 2. Remove OEM Bump Stop:** Detach the existing OEM vehicle bump stop by prying it from its mounting cup.
- 3. Position Spring Assembly:** Insert the helper spring assembly into the OEM bump stop cup.
- 4. Lubricate and Seat Spring:** Apply a soapy water solution to the helper spring assembly. Position it into the bump stop cup, applying simultaneous pushing and twisting force to fully seat it.
- 5. Verify Assembly Seating:** Confirm that the helper spring assembly is correctly seated within the bump stop cup.
- 6. Ensure Final Seating with Spacer:** To ensure proper seating, temporarily place a spacer (e.g., a short 2x4 wood block) between the axle and the helper spring assembly. Lower the vehicle onto the spacer. Then, raise the vehicle again to remove the temporary spacer.
- 7. Lower Vehicle:** Carefully lower the vehicle to the ground.

Installation Notes:

- The helper spring kit is supplied pre-assembled.

3. Clearance Instructions & Fitting Guidance

- **Clearance Gap:** Rear helper spring kits for light-duty trucks and vans should maintain a 1/2" to 1-1/2" gap between the rubber spring and its contact point when the vehicle is unladen.
- **Load Effects:** The presence of a partial load, cargo, or aftermarket vehicle accessories will reduce or eliminate this initial gap.
- **Heavy-Duty Applications:** For medium and heavy-duty trucks, trailers, and motorhomes, the helper spring assembly will typically be in constant contact with no gap.

Important Safety Warnings:

- Do not exceed the vehicle manufacturer's recommended axle weight rating.
- Check for potential interference between the hollow rubber spring and other vehicle components. Under load, the rubber spring's diameter will expand.

Note: Illustrations are for reference only. If no specific reference image is provided, please install according to the standard mechanical guidelines.