

GMRYS4 Rear Helper Spring Kit Installation Manual

Model: GMRYS4 (Rear Suspension Package)

Please read these instructions carefully before commencing installation. Ensure all standard safety protocols are observed when working beneath the vehicle.

1. Parts List

Before beginning, verify that all components listed in the table below are present in your kit.

Ref #	Description / Specifications	Qty
1	Locator Component (3-25/64 inch Outer Diameter with Bushing)	2
2	Hollow Rubber Spring	2
3	Hex Cap Screw (HCS) (3/8 x 1-1/2 UNF Grade 5 Zinc Plated)	2

2. Installation Instructions

1. Raise Vehicle: Elevate the vehicle using an appropriate lifting device, allowing the axle to articulate freely. Ensure the chassis is securely supported before proceeding.

2. Remove OEM Bump Stop: Carefully remove the existing original equipment manufacturer (OEM) bump stop from its mounting cup, typically by prying.

3. Install Helper Spring Assembly: Position the helper spring assembly into the bump stop cup. To facilitate proper seating, a temporary spacer (e.g., a 2x4 wood block) may be placed between the axle and the helper spring assembly. Lower the vehicle onto the spacer to seat the assembly, then re-raise the vehicle to remove the spacer.

4. Lower Vehicle: Carefully lower the vehicle to the ground.

Installation Notes:

- Verify that the helper spring assembly is correctly and securely seated within the bump stop cup.
- Apply thread-locking compound to fasteners as required for secure assembly.

3. Clearance Instructions & Fitting Guidance

- **Clearance Gap:** For light-duty trucks and vans, an unloaded vehicle should exhibit a 1/2 inch to 1-1/2 inch gap between the rubber spring and its contact surface.
- **Load Effects:** The presence of a partial load, cargo, or aftermarket vehicle accessories will reduce or potentially eliminate this initial clearance gap.
- **Heavy-Duty Applications:** Medium and heavy-duty trucks, trailers, and recreational vehicles are designed for constant contact, thus exhibiting no clearance gap.

Important Safety Warnings:

- Do not exceed the maximum axle weight rating specified by the vehicle manufacturer.
- Inspect for potential interference between the rubber spring and adjacent vehicle components. Note that under load, the rubber spring's diameter will increase.

Note: Illustrations are for reference only. If no specific reference image is provided, please install according to the standard mechanical guidelines.