


Shed Link Easy Setup Guide



V20221206

Latest Version of this document available at:

https://github.com/UBWH/ubwh.github.io/blob/master/assets/UserGuides

Easy Setup Guide: Shed Link

Table of Contents

1. Before You Start	3
2 Stan By Stan Configuration	1
2. Step By Step - Configuration	4
2. Step By Step - Shed Setup	7

Easy Setup Guide: Shed Link


1. Before You Start


Locate the unit in the HOUSE	Locate the unit in the main house in a room where it: • is on the side of the house closest to the shed, and • will be able to connect to the existing House WiFi signal.
Power the unit	Connect the power adapter and power up the unit.
Factory Default	The Shed Link AP must be in Factory Default state. If you are unsure: Wait until the LEDs on the front stabilise. Approx 30 sec. After power on. Using a straightened paper-clip (or similar), press and hold the Reset button on the rear panel, until the LEDs flash and turn off. Approx 10 sec.
Install ONE	Install one of the internal (rigid) antennas in the LEFT-REAR
internal antenna	antenna socket.
Know the WiFi credentials of your HOUSE	Write here the credentials of your existing (Home) WiFi:
WiFi	SSD (WiFi Name):
	Password (PSK):

Easy Setup Guide: Shed Link Page 3 of 10


2. Step By Step - Configuration

Connect a Phone or PC	Choose one of these options:
to the Unit	Connect a computer with a LAN cable between the computer and the LAN port labeled Ethernet 1 on the rear of the unit.
	2. Connect a computer using WiFi to this WiFi network: Name: TP-Link_XXXX (XXXX unique for each unit) Password/PIN: (printed on label on base of unit)
	3. Connect a smart phone using WiFi to this WiFi network: Name: TP-Link_XXXX (XXXX unique for each unit) Password/PIN: (printed on label on base of unit)
Login	Launch a web browser and browse to: http://tplinkwifi.net
	Choose your language.
	Login: admin Password: admin
	admin □ □ □
	Log In
Set Operation Mode	Status Quick Setup Operation Mode Network Quick Setup - Start
	Wireless Guest Network DHCP To continue, please click the Next button. Forwarding To exit, please click the Exit button.
	Security Parental Controls Access Control Advanced Routing





2. Step By Step - Shed Setup



Easy Setup Guide: Shed Link Page 7 of 10

Connect external antenna to Shed Link unit

Looking at the rear of the unit,

- the factory (rigid) antenna is connected to the LEFT-REAR socket.
- the external antenna is connected to the RIGHT-REAR socket.

Note: The external antenna cable only needs to be finger tight. If you don't have a hex-spanner small enough to fit into the antenna socket: hold the external antenna cable stationary and rotate the Shed Link unit.



Locate the Shed Link unit Locate the unit on a flat surface, or mount on a wall using the included Wall Mount kit.



Apply power to the unit.

The included PoE kit can be used as a 5m extension power (and ethernet) cable as needed.

PoE Kit (5 m)

Test

Using a phone or WiFi computer in the shed: Connect to the WiFi network and you should be able to browse the Internet.

A PC connected by a LAN cable to any of the LAN sockets on the rear of the unit should be able to browse the Internet

Change Use a phone or laptop in the shed and launch a web browser. Browse admin to: http://tplinkwifi.net password Select System Tools / Administrator Status Quick Setup Operation Mode Network Wireless DHCP - LED Control - Time Settings - Diagnostic - Firmware Upgrade - Factory Defaults - Backup & Restore - Reboot - Language - System Log Change the admin password.