

Quick Start Guide

»» AC1200 DualBand Wi-Fi Router

REV.E2

EN



Hardware Connection

Step 1:



Connect your modem to the Internet.

Step 2:

Connect LAN port of Modem to "WAN" port of router.

Step 3:

Plug the router in a power outlet.



Default Parameters

Login: <http://wifi.wavlink.com>

Default IP: 192.168.10.1


Login Password: admin

2.4G SSID: **WAVLINK-N**

5G SSID: **WAVLINK-AC**

In The Box

- 1 x Wi-Fi Router
- 1 x Ethernet Cable
- 1 x Power Adapter
- 1 x Quick Start Guide




WPS Button: Press and hold **2** seconds for WPS one-key encryption and connection.

Reset Button: Press and hold **6** seconds for system reset.

LED Indicators

Pink ON	The device has started up
Off	Power is off
Blue Solid	Internet connected
Blue Flashing	The router WPS is trying to connect to the adapter of your PC
Red Flashing	Internet disconnected


Tips: Try to keep the router in the relatively central spot in your home and away from anything that might block its signal such as metal objects, bodies of water, reinforced concrete walls, foil-insulated walls, and other similar construction materials that may severely weaken a wireless signal passing through it.



Configure via Web Browser

1 Connect your computer to the Router (Wired or Wireless):


1.1 Wired



1.2 Wireless

Connect to the router with current Wi-Fi name (SSID) and default password.

1.2.1 For Windows Users



- 1.2.1.1 Turn your laptop's Wi-Fi ON if it is OFF.
- 1.2.1.2 Click the Wi-Fi icon on the taskbar and connect to the router's network: **WAVLINK-N** or **WAVLINK-AC**.

1.2.2 For Mac OS X Users



- 1.2.2.1 Turn your laptop's Wi-Fi ON if it is OFF.
- 1.2.2.2 Click the Wi-Fi icon on the top right corner of the screen, and connect to the router's network: **WAVLINK-N** or **WAVLINK-AC**.

2 Setup your Wi-Fi network:


- 2.1 Enter <http://wifi.wavlink.com> or <http://192.168.10.1> in the address field of a web browser. Enter **admin** (all lowercase) for the first login.

Note: If the login window does not appear, please refer to FAQ>Q1.




- 2.2 After login, select "Country/Region", "Time Zone" respectively and then create a new password for your router. Click "Save" to proceed.

Note: Log in with your new password next time.




2.3 Select Router.



- 2.4 Select the compatible network type to complete the configuration.

2.4.1 From the **WAN Type** menu, select your Internet connection type from the drop-down list: **DHCP (Dynamic IP)**, **PPPoE** or **Static IP**. And then enter the information provided by your ISP in the corresponding fields.

Note: If you are not sure about your Internet type, please contact your Internet Service Provider (ISP); your ISP generally offers you all necessary information when your Internet service is activated. If the information is inadequate, please contact your ISP.



Tips:
If you use DSL line and you are only provided an account name and a password by your ISP, choose **PPPoE**. If you use cable TV or fiber cable, choose **DHCP(Dynamic IP)**. If you are provided information such as IP address, Subnet Mask and Default Gateway, choose **Static IP**.

- 2.4.2 The default 2.4G SSID and 5G SSID are **WAVLINK-N** and **WAVLINK-AC**. You can use the default SSIDs or create your own SSIDs here.

2.4.2.1 2.4G SSID: **WAVLINK-N**
5G SSID: **WAVLINK-AC**

- 2.4.3 From the **Security Type** menu, select a security type from the drop-down list (**WPA/WPA2 Mix** is recommended). And create a Wi-Fi password for security purpose. Wi-Fi password is case-sensitive.

2.4.3.1 Security Type: **WPA/WPA2 Mix**
Wi-Fi Password: *********

- 2.4.4 Click **Apply**. Installation and basic setup take a few minutes to complete.

Congratulations!
You have completed the quick setup.


Change Wi-Fi name and password

1. Click **Wi-Fi** > **Wi-Fi Configuration**.
2. Configure and click **Apply** button to confirm.



Change login password

1. Click **Setup** > **Login Password**.
2. Enter the old password. Then enter the new password (case-sensitive) and click **Apply** button to confirm.



3. Use the new password for future login.

Firmware Upgrade

Firmware upgrade can fix bugs of the router. However, We **DO NOT** recommend you upgrade the firmware of the router if it works properly.

1. Download the latest firmware file for the router from our website www.wavlink.com.
2. Click **Setup** > **Upgrade Firmware**.



3. Click **Browse** (or **Choose File**) to locate the new downloaded firmware file.
4. Click **Apply** button, and wait for a few minutes for the firmware upgrade to complete.

Warranty voids if you interrupt the upgrade procedure.

FAQ (Frequently Asked Questions)

Q1. Why doesn't the login page appear after entering <http://wifi.wavlink.com>?

- Make sure your computer is set to obtain an IP address automatically.
- Verify if <http://wifi.wavlink.com> is correctly entered in the web browser. Alternatively, enter <http://192.168.10.1> in the web browser.
- Use another web browser and try again.
- Reboot your router and try again.

Q2. What can I do if I cannot access the Internet?

- Check if the Internet is working normally by connecting a computer directly to the modem using an Ethernet cable. If it is not, contact your internet service provider.
- Open a web browser, enter <http://wifi.wavlink.com> or <http://192.168.10.1> and run the quick setup again.
- Reboot your router and try again.

Q3. How can I restore the router to its factory default settings?

- While the router is powered on, press and hold the **Reset** button on the back for 6 seconds.

Q4. What can I do if I forgot my Administration Management password?

- Refer to FAQ > Q3 to reset the router, and then use the default **admin** (all lowercase) to login.

Q5. What can I do if I forgot my wireless network password?

- Log in the router's web management page at <http://wifi.wavlink.com> and go to **Wi-Fi** > **Wi-Fi Setup**, you can find your Wi-Fi password here.

Q6. How to deploy the router to get the best Wi-Fi signal?

- Keep the router in the most central spot in your home and away from anything that might block its other similar construction materials may severely weaken a wireless signal passing through it.

GNU General Public License Notice

This product includes software codes developed by third parties. These software codes are subject to either the GNU General Public License (GPL), Version 2, June 1991 or the GNU Lesser General Public License (LGPL), Version 2.1, February 1999. You can copy, distribute, and/or modify in accordance with the terms and conditions of GPL or LGPL. The source code should be complete, if you want us to provide any additional source code files under GNU General Public License (GPL), please contact us in these matters. We are committed to meeting the requirements of the GNU General Public License (GPL). You are welcome to contact us local office to get the corresponding software and licenses. Please inform us your contact details (full address) and the product code. We will send you a software package with the software and license for free. The respective programs are distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Please refer to the GNU General Public License Web site for further information.

<http://www.gnu.org/licenses/old-licenses/lgpl-2.0.html>

<http://www.gnu.org/licenses/gpl.html>

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

