



SWD调试接口 CAN1_H CANH CANL CAN1_L VSS CANL VDD VIO STBY EPAD UART5_TX C ACT45B PESD1CAN PAD PAD GND GND A1257wv-s-4P Ę GND R8 P11 排针4x3 TXD RXD CAN2_H CANH CANL CAN2_L VSS CANL VDD VIO STBY EPAD VCC_5VS USB充电&通讯接口 PESD1CAN A1257wv-s-4P VCC_5V GND SM02B-GHS 트 GND 485 VCC_5VS USB-VBUS VCC_5VS GND | VCC_IN GND | CC2 SBU1 D+ USB-DM C USB-DP C USB-DM C VCC_I D-D+ D-CC1 SBU2 VBUS GND GND I VCC_3V3 USB-VBUS 10 11 12 13 14 15 16 TIM3_CH2(PB05) SPI2_CS1 | GND 485_B2 >>> 485_B2 485_B1 >>> 485_B1 VCC B SPI2_MOS RE# DE GND EP I GND GND EP GND I GND IO2 IO1 2 PSM712 U9 PSM712 USB-VBUS VCC GND 를 GND PRTR5V0U2X 485_A1 485_B1 GND SM02B-GHS Ę GND SM02B-GHS Ę GND ADC1_CH0_VBAT >> 遥控器DBUS接口 GND R20 TIM2_CH4(PB02) >> USART3_RX(PC05) VCC_5VS GND GND GND ADC1_CH1_KEY USER_KEY(PA15) Title

Size

A3

Number

Revision

SKRTLAE010

SKRTLAE010