AD 2 AERODROMI
AERODROMES

LYBE BEOGRAD/NIKOLA TESLA

LYBE AD 2.1 LOKACIJSKI INDIKATOR I NAZIV AERODROMA
AERODROME LOCATION INDICATOR AND NAME

LYBE BEOGRAD/Nikola Tesla

LYBE AD 2.2 GEOGRAFSKI I ADMINISTRATIVNI PODACI O AERODROMU
AERODROME GEOGRAPHICAL AND ADMINISTRATIVE DATA

1	***ARP coordinates and site at AD***	444910N 0201825E 122° GEO / 1500 M from THR 12L
2	***Direction and distance of ARP from centre of the city***	275° GEO, 12 KM from main railway station in Beograd
3	***ELEV / Reference temperature / Mean low temperature***	336 FT / 29.4°C (JUL) / Data not AVBL
4	***Geoid undulation at AD ELEV PSN***	142 FT
5	***MAG VAR (date of information) / Annual change***	6°E (2025) / +0.082°
6	***AD Operator address:***	BELGRADE AIRPORT d.o.o. Beograd Aerodrom Beograd Ulica 47 11180 Beograd-Surčin Srbija / Serbia
	TEL:	Operational center (H24): + 381 11 209 7405, + 381 64 848 5470 Airport duty manager (H24): + 381 11 209 4855, + 381 64 848 5442 Flight information (H24): + 381 11 209 4444, + 381 63 255 066 Flight coordination office (0600–1800; during Summer time 0500–1700): + 381 11 209 7345, + 381 64 848 5026 General enquires (0300–2300, during Summer time 0200–2200): + 381 11 209 4444, + 381 63 255 066
	FAX:	NIL
	e-mail:	Operational center (H24): operational.center@beg.aero Airport duty manager (H24): duty.manager@beg.aero Flight coordination office (0600–1800; during Summer time 0500–1700): flight.coordinator@beg.aero
	AFS:	NIL
	Website:	www.beg.aero
7	***Types of traffic permitted to use AD***	IFR-VFR
8	***Remarks***	AD reference code: 4E

LYBE AD 2.3 RADNO VREME
OPERATIONAL HOURS

1	***AD Operator***	H24
2	***Customs and immigration***	H24
3	***Health and sanitation***	HO
4	***AIS Briefing Office***	H24
5	***ATS Reporting Office (ARO)***	H24
6	***MET Briefing Office***	H24
7	***ATS***	H24
8	***Fuelling***	H24
9	***Handling***	As AD Operator
10	***Security***	As AD Operator
11	***De-icing***	As AD Operator
12	***Remarks***	Offices from items 4 and 5 of this table form one unit assigned as ARO

LYBE AD 2.4 SLUŽBE I SREDSTVA ZA OPSLUŽIVANJE HANDLING SERVICES AND FACILITIES

1	***Cargo-handling facilities***	All modern facilities handling cargo up to 7 tonnes
2	***Fuel and oil types***	JET A-1, AVGAS 100 LL / NIL
3	***Fuelling facilities and capacity***	Naftna industrija Srbije j.s.c. Novi Sad Aeroservis Beograd JET A-1: 4 trucks / 45000 litres Delivery rate 2 x 1000 litres/MIN 4 trucks / 32000 litres Delivery rate 2 x 1000 litres/MIN AVGAS 100 LL: 1 truck / 2000 litres Delivery rate 150 litres/MIN TEL: + 381 11 209 7090, + 381 11 228 6381 *Methods of payment:* Foreign customers without supply contract with NIS: 1. VISA, MASTER, AMERICAN; 2. Via reseller (customer must contact reseller who will send all necessary announcements). Domestic customers: Supply contract and prior coordination required. Cash payment: Not AVBL. NIS cannot guarantee AVGAS availability during peak hours: 0400–0600, 0930–1230, 1500–1700; during Summer time 0300–0500, 0830–1130, 1400–1600.
4	***De-icing facilities***	Call sign: BELGRADE DEICING 1 DAIC FREQ: 121.550 MHZ 6 trucks; Type I: 50% de-icing; Type II: 100% anti-icing Call sign: BELGRADE DEICING 2 DAIC FREQ: 121.750 MHZ Data not AVBL
5	***Hangar space for visiting aircraft***	Two hangars of JAT Tehnika: H1: four B737 plus two ATR72, four A320 plus two ATR72 or six ATR72 H2: two B747 or two A330 or seven B737 or five A320 or nine ATR72 Hangars are heated and fully equipped Contact: www.jat-tehnika.aero e-mail: marketing@jat-tech.rs TEL: + 381 11 267 6062, + 381 64 887 1801 JAT Tehnika MCC (H24): TEL: + 381 11 267 5578, + 381 64 887 1970 e-mail: maintenance-tbs@jat-tech.rs JAT Tehnika Line maintenance (H24): TEL: + 381 11 260 1362, + 381 64 887 3500 e-mail: maintenance-lineshift@jat-tech.rs One hangar for general aviation Contact: www.airserbia.com
6	***Repair facilities for visiting aircraft***	Aircraft line and heavy maintenance, modifications, engine/APU Honeywell G7CP85-129E/129H maintenance and replacement: B737 classic and new generation, B737 MAX, A320 family, A320 NEO, ATR42, ATR72, Sukhoi Superjet 100, A330 (from 2021). Engines CFM 56-3 test cell. CFM 56-3/-5/-7 and V2500 borescope inspection. Component maintenance per “Capability list”. EASA, FAA, BDCA and other CAA approvals. Contact: www.jat-tehnika.aero e-mail: marketing@jat-tech.rs JAT Tehnika MCC (H24): TEL: + 381 11 267 5578, + 381 64 887 1970 e-mail: maintenance-tbs@jat-tech.rs JAT Tehnika Line maintenance (H24): TEL: + 381 11 260 1362, + 381 64 887 3500 e-mail: maintenance-lineshift@jat-tech.rs
7	***Remarks***	See AIC series A (LYBE – Ground handling operators)

LYBE AD 2.5 POGODNOSTI ZA PUTNIKE
PASSENGER FACILITIES

1	***Hotel(s) at or in the vicinity of AD***	In Beograd
2	***Restaurant(s) at or in the vicinity of AD***	At AD and in Beograd
3	***Transportation possibilities***	Bus, taxi and car hire
4	***Medical facilities***	First aid at AD; hospitals in Beograd (10 KM)
5	***Bank and Post Office at or in the vicinity of AD***	At AD, open within AD HR
6	***Tourist Office***	In Beograd
7	***Remarks***	NIL

LYBE AD 2.6 SPASILAČKO-VATROGASNA SLUŽBA
RESCUE AND FIREFIGHTING SERVICES

1	***AD category for firefighting***	Category 8
2	***Rescue equipment***	According to firefighting Category 8
3	***Capability for removal of disabled aircraft***	Case category I and II for ACFT up to code letter C. Recovery Coordinator Office (H24): + 381 64 848 5442
4	***Remarks***	NIL

LYBE AD 2.7 PROCENA I IZVEŠTAVANJE O STANJU POVRŠINE POLETNO-SLETNE STAZE I PLAN ČIŠĆENJA SNEGA
RUNWAY SURFACE CONDITION ASSESSMENT AND REPORTING, AND SNOW PLAN

1	***Type(s) of clearing equipment***	Airport is serviceable all year. 4 trucks with snowplough 6 snow removal units (plough+clear+blow) 7 tractors with plough 3 snowcutters 2 RWY Multi de-icer 1 platform tractor solid de-icer 1 tractor for clearing RWY edge lights
2	***Clearance priorities***	1. RWY 2. TWY 3. Aprons
3[1)]	***Use of material for movement area surface treatment***	KAC, NAFO
4	***Specially prepared winter runway***	Not applicable
5	***Remarks***	Caution advised in winter during ice conditions. Information on snow clearance promulgated by SNOWTAM. Snow committee NOV-APR H24. TEL: + 381 64 848 5219, radio 168.200 MHZ. For information about runway surface condition assessment and reporting, and snow plan see AD 1.2, item 2.

[1)] *Explanation refers to item 3:*

KAC potassium acetate fluids

NAFO sodium formate solids

LYBE AD 2.8 PLATFORME, RULNE STAZE I LOKACIJE/POZICIJE PROVERE POLOŽAJA APRONS, TAXIWAYS AND CHECK LOCATIONS/POSITIONS DATA

1	***Designation, surface and strength of aprons***	A		CONC	ACFT stand A1: PCN 49/R/B/X/U
				ASPH	ACFT stands A2, A3, A10: PCN 49/R/B/X/U
				CONC	ACFT stands A4-A9: PCN 51/R/C/X/U
				ASPH	ACFT stands A11-A14: PCN 49/R/B/X/U
		B		CONC	PCN 61/R/B/X/U
		C		CONC	ACFT stands C1-C10: PCN 61/R/B/X/U
				CONC	ACFT stands C11-C14: PCN 73/R/C/W/T
		E		CONC	PCN 74/R/B/W/T
		N		CONC	PCN 76/R/C/W/U
		W		CONC	PCN 79/R/C/W/T
2	***Designation, width, surface and strength of taxiways***	A	23 M	ASPH	PCN 53/R/A/X/U
		B	23 M	ASPH	PCN 53/R/A/X/U
		C	23 M	ASPH	PCN 73/R/C/X/U
		D1	23 M	ASPH	PCN 53/R/A/X/U
		D2	34 M	ASPH	PCN 96/F/D/X/T
		D3	40 M	ASPH	PCN 73/R/C/X/U
		D4	38 M	ASPH	PCN 96/F/D/X/T
		D5	39 M	ASPH	PCN 96/F/D/X/T
		D6	39 M	ASPH	PCN 96/F/D/X/T
		D7	23 M	ASPH	PCN 53/R/A/X/U
		E	23 M	ASPH	PCN 53/R/A/X/U
		F		CONC	from intersection TWY G-TWY F to stop bar F4: PCN 61/R/B/X/U
				CONC	from stop bar F4 to parking stand C14: PCN 96/F/D/X/T
		FA		CONC	PCN 76/R/C/W/U
		FB		CONC	PCN 76/R/C/W/U
		G		CONC	ACFT stands A1-A9: PCN 61/R/B/X/U
				ASPH	ACFT stands A10-A14: PCN 61/R/B/X/U
		H		CONC	PCN 73/R/C/X/U
		J		CONC	PCN 73/R/C/X/U
		K		CONC	PCN 61/R/B/X/U
		L		CONC	PCN 73/R/C/X/U
		M		CONC	PCN 61/R/B/X/U
		R1	15 M	ASPH	PCN 96/F/D/X/T
		R2	23 M	ASPH	PCN 96/F/D/X/T
		R3	15 M	ASPH	PCN 96/F/D/X/T
		R4	23 M	ASPH	PCN 96/F/D/X/T
		T	23 M	ASPH	PCN 96/F/D/X/T
		Y	49 M	ASPH	PCN 96/F/D/X/T
3	***Location and ELEV of altimeter checkpoints***	Aprons A, B, C and E			323 FT
4	***Location of VOR checkpoints***	NIL			
5	***Position of INS checkpoints***	See Aircraft Parking/Docking Chart – ICAO			
6	***Remarks***	TWY F, FA, FB, G, H, J, K, L, M, T and Y are aircraft stand taxilanes			

LYBE AD 2.9 SISTEM ZA VOĐENJE I KONTROLU KRETANJA I DNEVNE OZNAKE
SURFACE MOVEMENT GUIDANCE AND CONTROL SYSTEM AND MARKINGS

1	***Use of aircraft stand ID signs, TWY guide lines and visual docking / parking guidance system of aircraft stands***	Visual docking guidance system, vehicle “follow me” Guide lines at aprons and taxiways Lighted holding position signs Retroreflective location signs of thresholds, taxiways, aprons and aircraft stands
2	***RWY and TWY markings and LGT***	*Marking aids* RWY: 12L/30R: RWY designation, threshold, displaced threshold, aiming point, touchdown zone, centreline and edges markings, turn pad. Entry/exit TWY to/ from the RWY are marked by a continuous painted yellow line from the centreline of the RWY. Exit RWY to the rapid exit TWY are marked by a continuous painted yellow line from the centreline of the RWY. 12R/30L: RWY designation, threshold, displaced threshold, aiming point, touchdown zone, centreline and edges markings, turn pad. Entry/exit TWY to/ from the RWY are marked by a continuous painted yellow line from the centreline of the RWY. TWY: centre line, retroreflective edge markers, RWY holding positions, intermediate holding positions Taxilanes: centre line, broken centre line, retroreflective edge markers, intermediate holding positions, RWY holding positions *Lights* RWY: see item LYBE AD 2.14 TWY: RWY holding positions (illuminated red); intermediate holding position lights (yellow and red); centre line lights – see item LYBE AD 2.15, row 3; RWY guard lights (a pair of yellow, flashing lights) Taxilanes: centre line lights, intermediate holding position lights (yellow), RWY holding positions (illuminated red), RWY guard lights (a pair of yellow, flashing lights)
3	***Stop bars***	On TWY A, B, C, D1, D2, D3, D4, D5, D6, D7, E, F, FA, FB, G, H, M, T, Y and on rapid exit TWY R1, R2, R3 and R4 (see AD Chart – ICAO)
4	***Remarks***	Rapid exit TWY R1, R2, R3 and R4 are equipped with NO ENTRY markings, signs and lights from RWY 12R/30L to RWY 12L/30R

LYBE AD 2.10 AERODROMSKE PREPREKE
AERODROME OBSTACLES

Area 2					
OBST ID	***Type of OBST***	***OBST position (COORD)***	***ELEV OBST / HGT***	***OBST marking / LGT type / colour***	***AVBL in electronic form***
1	***2***	***3***	***4***	***5***	***6***
LYBE_OB2B_0001	Building	444618.8N 0202529.1E	781 FT / Data not AVBL	Yes / Data not AVBL	NIL
LYBE_OB2B_0002	Building	444611.6N 0202530.7E	732 FT / Data not AVBL	NIL	NIL
LYBE_OB2B_0003	Building	444611.6N 0202532.6E	735 FT / Data not AVBL	NIL	NIL
LYBE_OB2B_0004	Tree	444614.3N 0202541.1E	761 FT / Data not AVBL	NIL	NIL
LYBE_OB2B_0005	Antenna	444530.7N 0202555.3E	814 FT / Data not AVBL	Yes / Data not AVBL	NIL
LYBE_OB2B_0006	Water tower	444533.8N 0202600.7E	903 FT / 60 FT	Yes / Data not AVBL	NIL
LYBE_OB2B_0007	Tree	444949.2N 0201647.3E	358 FT / Data not AVBL	NIL	NIL
LYBE_OB2B_0008	Tree	444949.6N 0201647.2E	358 FT / Data not AVBL	NIL	NIL
LYBE_OB2B_0009	Tree	444949.9N 0201647.1E	358 FT / Data not AVBL	NIL	NIL
LYBE_OB2B_0010	Tree	444950.2N 0201647.1E	358 FT / Data not AVBL	NIL	NIL
LYBE_OB2B_0011	Mast	444931.8N 0201709.4E	373 FT / 56 FT	Yes / CONS / R	NIL
LYBE_OB2B_0012*	Building	444824.0N 0201952.5E	353 FT / 27 FT	NIL	NIL
LYBE_OB2B_0013*	Tree	444823.9N 0201954.2E	364 FT / 36 FT	NIL	NIL

Area 2					
OBST ID	***Type of OBST***	***OBST position (COORD)***	***ELEV OBST / HGT***	***OBST marking / LGT type / colour***	***AVBL in electronic form***
1	***2***	***3***	***4***	***5***	***6***
LYBE_OB2B_0014*	Building	444819.6N 0201950.8E	370 FT / 44 FT	NIL	NIL
LYBE_OB2B_0015*	Tree	444822.1N 0201955.7E	363 FT / 33 FT	NIL	NIL
LYBE_OB2B_0016*	Building	444821.5N 0202000.9E	380 FT / 49 FT	NIL	NIL
LYBE_OB2C_0001	ATC Tower	444910.4N 0201719.0E	583 FT / 264 FT	NIL / FLG / W	NIL
LYBE_OB2C_0002	Mast	444928.9N 0201712.5E	373 FT / 56 FT	Yes / CONS / R	NIL
LYBE_OB2C_0003	Radar Tower with radome	444901.7N 0201920.2E	454 FT / 124 FT	Yes / CONS / R	NIL
LY_OBST_0001	Area 1 Obstacle (See ENR 5.4 (Serbia))				
LY_OBST_0002	Area 1 Obstacle (See ENR 5.4 (Serbia))				
LY_OBST_0003	Area 1 Obstacle (See ENR 5.4 (Serbia))				
LY_OBST_0004	Area 1 Obstacle (See ENR 5.4 (Serbia))				
LY_OBST_0005	Area 1 Obstacle (See ENR 5.4 (Serbia))				
LY_OBST_0006	Area 1 Obstacle (See ENR 5.4 (Serbia))				
LY_OBST_0007	Area 1 Obstacle (See ENR 5.4 (Serbia))				
LY_OBST_0011	Area 1 Obstacle (See ENR 5.4 (Serbia))				

* Survey report not AVBL

Area 3					
OBST ID	***Type of OBST***	***OBST position (COORD)***	***ELEV OBST / HGT***	***OBST markings / LGT type / colour***	***AVBL in electronic form***
1	***2***	***3***	***4***	***5***	***6***
To be developed					

LYBE AD 2.11 PRUŽANJE METEOROLOŠKIH INFORMACIJA METEOROLOGICAL INFORMATION PROVIDED

1	***Name of the associated MET Office***	BEOGRAD
2	***Hours of service*** ***MET Office outside these hours***	H24 –
3	***Office responsible for preparation of TAFs*** ***Periods of validity (Interval of issuance)***	BEOGRAD 24 HR (issued every 6 hours)
4	***Availability of the TREND forecast for AD*** ***Interval of issuance***	TREND 30 MIN
5	***Briefing / consultation provided***	Personal / Telephone
6	***Types of flight documentation supplied*** ***Language(s) used in flight documentation***	Charts, abbreviated plain language text English
7	***Charts and other information available for briefing or consultation***	As in flight documentation. Display of information from meteorological weather radar, satellites and aerodrome warning is available for personal briefing.
8	***Supplementary equipment available for providing information on meteorological conditions***	Satellite receiver, SADIS file transfer protocol
9	***ATS units provided with meteorological information***	BEOGRAD ATSU BEOGRAD ATCC
10	***Additional information (limitation of service, etc.)***	BEOGRAD MET Office TEL: + 381 11 381 4866

LYBE AD 2.12 FIZIČKE KARAKTERISTIKE POLETNO-SLETNE STAZE
RUNWAY PHYSICAL CHARACTERISTICS

RWY designator	*GEO BRG (DEG)*	*Dimensions of RWY (M)*	*Strength (PCN) and surface of RWY and associated SWY*	*THR COORD RWY end COORD THR GUND*	*THR ELEV and highest ELEV of TDZ of precision APP RWY*
1	*2*	*3*	*4*	*5*	*6*
12L	121.92	3400 x 45	3000 M: PCN 88/F/C/W/T ASPH 400 M: PCN 74/R/B/W/T CONC	444935.46N 0201727.51E 444837.20N 0201938.86E 143 FT	THR 317 FT TDZ 328 FT
30R	301.94	3400 x 45	400 M: PCN 74/R/B/W/T CONC 3000 M: PCN 88/F/C/W/T ASPH	444844.06N 0201923.41E 444935.53N 0201727.36E 143 FT	THR 333 FT TDZ 335 FT
12R	121.92	3500 x 45	PCN 96/F/D/X/T ASPH	444918.16N 0201750.19E 444829.95N 0201938.87E 142.6 FT	THR 321.9 FT TDZ 329.5 FT
30L	301.94	3500 x 45	PCN 96/F/D/X/T ASPH	444838.80N 0201918.91E 444929.92N 0201723.67E 143 FT	THR 331 FT –

RWY designator	*Slope of RWY-SWY*	*SWY dimensions (M)*	*CWY dimensions (M)*	*Strip dimensions (M)*	*RESA dimensions (M)*
1	*7*	*8*	*9*	*10*	*11*
12L	+0.47% (446 M), +0.26% (345 M), +0.22% (228 M), +0.19% (733 M), +0.15% (519 M), –0.19% (284 M), +0.04% (302 M), –0.20% (149 M), –0.50% (51 M), –0.02% (188 M), –0.04% (155 M)	NIL	NIL	3520 x 280	240 x 150
30R	+0.04% (155 M), +0.02% (188 M), +0.50% (51 M), +0.20% (149 M), –0.04% (302 M), +0.19% (284 M), –0.15% (519 M), –0.19% (733 M), –0.22% (228 M), –0.26% (345 M), –0.47% (446 M)	NIL	NIL	3520 x 280	240 x 150
12R	+0.7% (313 M), –0.3% (546 M), +0.5% (572 M), –0.3% (1005 M), +0.62% (676 M), –0.7% (388 M)	NIL	NIL	3620 x 280	240 x 150
30L	+0.7% (388 M), –0.62% (676 M), +0.3% (1005 M), –0.5% (572 M), +0.3% (546 M), –0.7% (313 M)	NIL	NIL	3620 x 280	240 x 150

RWY designator	*Location and description of arresting system*	*OFZ*	*Remarks*
1	*12*	*13*	*14*
12L	Data not AVBL	Yes	Precision instrument approach CAT I/II/III RWY shoulders 7.5 M paved
30R	Data not AVBL	NIL	Precision instrument approach CAT I RWY shoulders 7.5 M paved
12R	Data not AVBL	Yes	Precision instrument approach CAT I/II/III RWY shoulders 7.5 M paved
30L	Data not AVBL	NIL	Non-precision instrument approach RWY shoulders 7.5 M paved

LYBE AD 2.13 DEKLARISANE DUŽINE
DECLARED DISTANCES

RWY designator	*TORA (M)*	*TODA (M)*	*ASDA (M)*	*LDA (M)*	*Remarks*
1	*2*	*3*	*4*	*5*	*6*
12L	3400	3400	3400	3400	NIL
12L	2800	2800	2800	NU	Take-off from intersection with TWY C
30R	3400	3400	3400	3000	TORA, TODA and ASDA applicable for ACFT with wingspan up to 44.84 M, wheel base up to 18.60 M and main gear wheel span up to 10.93 M. Take-off from turn pad. Turn pad not to be used during night and in low visibility conditions.
30R	3045	3045	3045	NU	Take-off from intersection with TWY E
12R	3500	3500	3500	2814	Take-off from intersection with TWY D1
12R	3293	3293	3293	NU	Take-off from intersection with TWY D2
12R	2927	2927	2927	NU	Take-off from intersection with TWY D3
12R	2848	2848	2848	NU	Take-off from intersection with TWY D4
12R	2266	2266	2266	NU	Take-off from intersection with TWY D5
30L	3500	3500	3500	2983	Take-off from turn pad.
30L	1273	1273	1273	NU	Take-off from intersection with TWY D5
30L	2349	2349	2349	NU	Take-off from intersection with TWY D6
30L	3086	3086	3086	NU	Take-off from intersection with TWY D7

LYBE AD 2.14 PRILAZNA SVETLA I SVETLA POLETNO-SLETNE STAZE
APPROACH AND RUNWAY LIGHTING

RWY desi-gnator	*APCH LGT type LEN INTST*	*THR LGT colour WBAR*	*Type of VASIS (MEHT) PAPI*	*TDZ LGT LEN*	*RWY CL LGT LEN spacing colour INTST*	*RWY edge LGT LEN spacing colour INTST*	*RWY end LGT colour WBAR*	*SWY LGT LEN (M) colour*
1	*2*	*3*	*4*	*5*	*6*	*7*	*8*	*9*
12L	CAT II/III [1)] 900 M LIH	GRN NIL	PAPI BOTH / 3° (72 FT)	900 M	3400 M 15 M W: 2500 M R/W: FM 2500 M to 3100 M R: FM 3100 M LIH	3400 M 60 M W YCZ 600 M LIH	RED –	NIL
30R	CAT I 900 M LIH	GRN NIL	PAPI BOTH / 3° (62 FT)	NIL	3000 M 15 M W: 2100 M R/W: FM 2100 M to 2700 M R: FM 2700 M LIH	3000 M 60 M W YCZ 600 M [2)] LIH	RED –	NIL
12R	CAT II/III [1)] 900 M LIH	GRN NIL	PAPI BOTH / 3° (54 FT)	900 M	2810 M 15 M W: 1910 M R/W: FM 1910 M to 2510 M R: FM 2510 M LIH	2810 M 60 M W YCZ 600 M [3)] LIH	RED –	NIL
30L	SALS 420 M LIH	GRN NIL	PAPI BOTH / 3° (52 FT)	NIL	2985 M 15 M W: 2085 M R/W: FM 2085 M to 2685 M R: FM 2685 M LIH	2985 M 60 M W YCZ 600 M [4)] LIH	RED –	NIL
10	*Remarks*	1) With sequenced flashing lights from 900 M up to 300 M before THR 2) Red between beginning of RWY and displaced THR (400 M) 3) Red between beginning of RWY and displaced THR (690 M) 4) Red between beginning of RWY and displaced THR (515 M)						

LYBE AD 2.15 OSTALE SVETLOSNE OZNAKE, REZERVNO NAPAJANJE
OTHER LIGHTING, SECONDARY POWER SUPPLY

1	***ABN / IBN location, characteristics and hours of operation***	NIL
2	***LDI location and LGT*** ***Anemometer location and LGT***	LDI: NIL Anemometer: See AD Chart – ICAO for location; lighted
3	***TWY edge and centre line lights***	Edges: NIL Centre line: TWY A, B, C, D1, D2, D3, D4, D5, D6, D7, E, F, FA, FB, G, H, J, K, L, M, R1, R2, R3, R4, T and Y
4	***Secondary power supply / switchover time***	Diesel generator and UPS
5	***Remarks***	WDI: See AD Chart – ICAO

LYBE AD 2.16 POVRŠINA ZA SLETANJE HELIKOPTERA
HELICOPTER LANDING AREA

1	***Coordinates TLOF or THR of FATO*** ***Geoid undulation***	TLOF: 444903.68N 0201804.23E GUND: 142 FT
2	***TLOF and/or FATO ELEV***	TLOF: 322 FT
3	***TLOF and FATO area dimensions, surface type, strength, marking***	Data not AVBL
4	***True BRG of FATO***	Data not AVBL
5	***Declared distance available***	Data not AVBL
6	***APP and FATO lighting***	Data not AVBL
7	***Remarks***	1) Available to domestic operators only upon previous permission of heliport owner (Ministry of Interior of Serbia) 2) Foreign operators must use RWY for landing and take-off

LYBE AD 2.17 VAZDUŠNI PROSTOR U KOME SE PRUŽAJU ATS USLUGE
ATS AIRSPACE

1	***Designation and COORD of lateral limits***	BEOGRAD CTR 445600N 0200941E 444648N 0203417E 444000N 0202641E 445000N 0200341E 445600N 0200941E
2	***Vertical limits***	3000 FT AMSL / GND
3	***Airspace classification***	Class D
4	***ATS unit call sign*** ***Languages***	BEOGRAD TORANJ / BEOGRAD TOWER English, Serbian
5	***Transition altitude***	10000 FT
6	***Hours of applicability***	H24
7	***Remarks***	NIL

LYBE AD 2.18 SREDSTVA ZA KOMUNIKACIJU U PRUŽANJU ATS USLUGA
ATS COMMUNICATION FACILITIES

Service designation	*Call sign*	*FREQ (MHZ) CH*	*SATVOICE number*	*Logon address*	*Hours of operation*	*Remarks*
1	*2*	*3*	*4*	*5*	*6*	*7*
APP	BEOGRAD RADAR	133.100 119.100 124.425 123.975/ALTN 121.500/EMERG	NIL	NIL	H24	
APP	BEOGRAD APPROACH / BEOGRAD PRILAZNA	133.100 119.100 124.425 123.975/ALTN 121.500/EMERG	NIL	NIL	H24	
TWR	BEOGRAD TORANJ / BEOGRAD TOWER	118.100 118.750/ALTN	NIL	NIL	H24	
TWR	BEOGRAD GROUND	118.300	NIL	NIL	H24	
TWR	BEOGRAD DELIVERY	121.975	NIL	NIL	H24	
VOLMET	BEOGRAD VOLMET	126.400	NIL	NIL	H24	
ATIS	BEOGRAD INFORMATION	125.025	NIL	NIL	H24	

LYBE AD 2.19 RADIO-NAVIGACIONI UREĐAJI I UREĐAJI ZA SLETANJE
RADIO NAVIGATION AND LANDING AIDS

Type of aid (MAG VAR) ILS CAT	*ID*	*FREQ CH*	*Hours of operation*	*COORD of the transmitting antenna*	*ELEV of the DME transmitting antenna*	*Remarks*
1	*2*	*3*	*4*	*5*	*6*	*7*
VOR/DME 6°E (2025)	BGD	112.05 MHZ CH 57Y	H24	444909.7N 0201840.2E	300 FT	DME COORD: 444910.0N 0201840.5E Coverage at 10000 FT ALT: Sector GEO 60 NM 112° – 155° 90 NM 155° – 112°
VOR/DME 5°E (2025)	SMI	117.00 MHZ CH 117X	H24	450034.1N 0192550.8E	300 FT	Coverage at 10000 FT ALT: Sector GEO 60 NM 020° – 060° 80 NM 060° – 020°
VOR/DME 5°E (2025)	TPL	116.80 MHZ CH 115X	H24	440836.6N 0204440.0E	1500 FT	Coverage at 10000 FT ALT: Sector GEO 25 NM 175° – 285° 80 NM 285° – 175°
VOR/DME 5°E (2025)	VAL	116.60 MHZ CH 113X	H24	441926.0N 0195228.9E	1100 FT	Coverage at 10000 FT ALT: Sector GEO 30 NM 125° – 245° 50 NM 245° – 326° 80 NM 326° – 125°
NDB 5°E (2025)	IA	485 KHZ	H24	450235.1N 0200423.2E		Range: 50 NM
NDB 5°E (2025)	OBR	355 KHZ	H24	443837.8N 0200818.4E		Range: 50 NM
NDB 6°E (2025)	PA	495 KHZ	H24	445330.2N 0203828.0E		Range: 50 NM
NDB 6°E (2025)	POZ	416 KHZ	H24	443714.7N 0210851.8E		Range: 50 NM

Type of aid (MAG VAR) ILS CAT	*ID*	*FREQ CH*	*Hours of operation*	*COORD of the transmitting antenna*	*ELEV of the DME transmitting antenna*	*Remarks*
1	*2*	*3*	*4*	*5*	*6*	*7*
NDB 5°E (2025)	VAL	390 KHZ	H24	441916.3N 0195230.2E		Range: 50 NM
DME	YUB	110.30 MHZ CH 40X	H24	444934.0N 0201741.2E	300 FT	DME collocated with GP 12L and frequency paired with LOC 12L. Coverage 25 NM within sector ±35° from LOC 12L course.
DME	YBG	109.50 MHZ CH 32X	H24	444915.3N 0201804.8E	300 FT	DME collocated with GP 12R and frequency paired with LOC 12R. Coverage 25 NM within sector ±35° from LOC 12R course.
L 6°E (2025)	JA	316 KHZ	H24	444434.5N 0202831.1E		Range: Data not AVBL
LOC 12L ILS CAT III (III.E.4) 6°E (2025)	YUB	110.30 MHZ	H24	444830.1N 0201954.9E		
GP 12L		335.00 MHZ	H24	444934.0N 0201741.2E		3.0°, RDH 53 FT
LOC 30R ILS CAT I 6°E (2025)	YBE	109.90 MHZ	H24	444941.5N 0201713.8E		
GP 30R		333.80 MHZ	H24	444852.5N 0201915.1E		3.0°, RDH 49 FT
MM 30R	Dots and Dashes	75 MHZ	H24	444824.8N 0202006.5E		Position: 296° MAG/0.60 NM to RWY 30R Intersect height: 241 FT
OM 30R	Dashes	75 MHZ	H24	444638.3N 0202409.8E		Position: 296° MAG/4.00 NM to RWY 30R Intersect height: 1324 FT
LOC 12R ILS CAT III (III.E.4) 6°E (2025)	YBG	109.50 MHZ	H24	444824.8N 0201950.5E		
GP 12R		332.60 MHZ	H24	444915.3N 0201804.9E		3.0°, RDH 56 FT

LYBE AD 2.20 LOKALNI PROPISI NA AERODROMU
LOCAL AERODROME REGULATIONS

1. Upotreba poletno-sletnih staza

1.1 Upotreba RWY 12L/30R

RWY 12L/30R se ne može koristiti istovremeno sa RWY 12R/30L zbog nedovoljnog razmaka između njih. RWY 12R/30L nije dostupna na zahtev pilota. U svakom trenutku može se koristiti samo jedna RWY za sletanje i poletanje:

a) Vazduhoplovi u dolasku moraju voziti iza pozicije za čekanje CAT III RWY 12L/30R i ne traže dozvolu za ulazak/prelazak preko RWY 12R/30L prilikom napuštanja RWY 12L/30R;

b) Vazduhoplovi u odlasku ne zahtevaju dozvolu za ulazak/prelazak preko RWY 12R/30L za poletanje sa RWY 12L/30R;

c) RWY 12R/30L se koristi kao ruta za voženje, kada je RWY 12L/30R u upotrebi za sletanje i poletanje.

Saobraćaj koji napušta RWY 12L preko TWY E treba da pređe preko RWY 12R/30L bez zaustavljanja, uđe na TWY D7 i zadrži poziciju, osim ako nije drugačije naređeno.

1. Use of runways

1.1 Use of RWY 12L/30R

RWY 12L/30R cannot be used simultaneously with RWY 12R/30L because of insufficient separation between the two. RWY 12R/30L is not available on request by pilots. At any moment, only one RWY can be used for take-off and landing:

a) Arriving aircraft must taxi beyond CAT III RWY 12L/30R holding position and do not require clearance to enter/cross RWY 12R/30L when vacating RWY 12L/30R;

b) Departing aircraft do not require clearance to enter/cross RWY 12R/30L for take-off from RWY 12L/30R;

c) RWY 12R/30L used as taxi route when RWY 12L/30R used for landing and take-off.

Traffic vacating RWY 12L via TWY E is to cross RWY 12R/30L without stopping, join TWY D7 and hold position unless otherwise instructed.

Saobraćaj koji napušta RWY 12L preko TWY R2 treba da pređe preko RWY 12R/30L bez zaustavljanja, uđe na TWY D6, zatim na TWY A i zadrži poziciju na međupoziciji za čekanje A3, osim ako nije drugačije naređeno.

Saobraćaj koji napušta RWY 12L preko TWY R1 treba da skrene desno na RWY 30L bez zaustavljanja i zadrži poziciju na RWY 12R/30L, ispred TWY D5, osim ako nije drugačije naređeno.

Saobraćaj koji napušta RWY 30R preko TWY R3 treba da skrene desno na RWY 30L bez zaustavljanja i zadrži poziciju na RWY 12R/30L, ispred TWY D5, osim ako nije drugačije naređeno.

Saobraćaj koji napušta RWY 30R preko TWY R4 treba da skrene desno na RWY 30L bez zaustavljanja i zadrži poziciju na RWY 12R/30L, ispred TWY D3, osim ako nije drugačije naređeno.

Saobraćaj koji napušta RWY 30R preko TWY C treba da pređe preko RWY 12R/30L i zadrži poziciju na RWY 12R/30L, ispred TWY D3, osim ukoliko nije drugačije naređeno.

Saobracaj koji napušta RWY 30R preko TWY B treba da pređe preko RWY 12R/30L bez zaustavljanja, ude na TWY D1 i zadrži poziciju, osim ako nije drugačije naređeno.

1.2 Upotreba RWY 12R/30L

RWY 12R/30L će se koristiti samo kada je RWY 12L/30R privremeno zatvorena zbog održavanja ili incidenta. Datum i vreme zatvorenosti radi izvođenja održavanja biće objavljeno putem NOTAM-a i obaveštenja aerodroma.

2. Upotreba rulnih staza za brzi izlazak vazduhoplova

TWY R1 i R3 se koriste za brzi izlazak vazduhoplova sa RWY 12L/30R, za vazduhoplove sa spoljašnjim razmakom točkova glavnog stajnog trapa do 9 M:

a) Sa TWY R1 dozvoljeno je levo i desno skretanje na RWY 12R/30L;
b) Sa TWY R3 dozvoljeno je samo desno skretanje na RWY 12R/30L.

TWY R2 se koristi za brzi izlazak vazduhoplova sa RWY 12L/30R, za vazduhoplove sa spoljašnjim razmakom točkova glavnog stajnog trapa do 15 M. Sa TWY R2 dozvoljeno je levo i desno skretanje na RWY 12R/30L.

TWY R4 se koristi za brzi izlazak vazduhoplova sa RWY 12L/30R, za vazduhoplove sa spoljašnjim razmakom točkova glavnog stajnog trapa do 15 M i sa rasponom krila do 61 M. Sa TWY R4 dozvoljeno je samo desno skretanje na RWY 12R/30L.

Rulne staze za brzi izlazak vazduhoplova R1, R2, R3 i R4 su opremljene znacima, oznakama i svetlima ZABRANJEN ULAZ sa RWY 12R/30L na RWY 12L/30R.

Udaljenost rulnih staza za brzi izlazak vazduhoplova od praga:

a) RWY 12L: izlaza R1 na 1200M,
izlaz R2 na 1850M.
b) RWY 30R: izlaz R3 na 1200M,
izlaz R4 na 1830M.

3. Koordinacija letenja

3.1 Poletanja i sletanja sa/na AD BEOGRAD/Nikola Tesla vanrednih letova, letova za sopstvene potrebe i ostalih letova opšte avijacije moraju biti koordinirana sa koordinatorom letenja AD BEOGRAD/Nikola Tesla.

Traffic vacating RWY 12L via TWY R2 is to cross RWY 12R/30L without stopping, join TWY D6, then TWY A and hold position at intermediate holding position A3 unless otherwise instructed.

Traffic vacating RWY 12L via TWY R1 is to turn right onto RWY 30L without stopping and hold position on RWY 12R/30L before TWY D5 unless otherwise instructed.

Traffic vacating RWY 30R via TWY R3 is to turn right onto RWY 30L without stopping and hold position on RWY 12R/30L before TWY D5 unless otherwise instructed.

Traffic vacating RWY 30R via TWY R4 is to turn right onto RWY 30L without stopping and hold position on RWY 12R/30L before TWY D3 unless otherwise instructed.

Traffic vacating RWY 30R via TWY C is to cross RWY 12R/30L and hold position on RWY 12R/30L before TWY D3, unless otherwise instructed.

Traffic vacating RWY 30R via TWY B is to cross RWY 12R/30L without stopping, join TWY D1 and hold position unless otherwise instructed.

1.2 Use of RWY 12R/30L

RWY 12R/30L will only be used when RWY 12L/30R is temporarily non-operational due to maintenance or incident. Dates and times of closure, to allow maintenance to take place, will be published by NOTAM and airport notices.

2. Use of rapid exit taxiways

TWY R1 and R3 are used for rapid vacating from RWY 12L/30R, for aircraft with outer main gear wheel span up to 9 M:

a) From TWY R1 left and right turns are allowed on RWY 12R/30L;
b) From TWY R3 only right turn is allowed on RWY 12R/30L.

TWY R2 is used for rapid vacating from RWY 12L/30R, for aircraft with outer main gear wheel span up to 15 M. From TWY R2 left and right turns are allowed on RWY 12R/30L.

TWY R4 is used for rapid vacating from RWY 12L/30R, for aircraft with outer main gear wheel span up to 15 M and with wingspan up to 61 M. From TWY R4 only right turn is allowed on RWY 12R/30L.

Rapid exit TWY R1, R2, R3 and R4 are equipped with NO ENTRY markings, signs and lights from RWY 12R/30L to RWY 12L/30R.

Rapid exit TWY distances from THR:

a) RWY 12L: exit R1 at 1200M,
exit R2 at 1850M.
b) RWY 30R: exit R3 at 1200M,
exit R4 at 1830M.

3. Flight coordination

3.1 Take-offs and landings from/to BEOGRAD/Nikola Tesla AD of non-scheduled, private and other general aviation flights shall be coordinated with flight coordinator of BEOGRAD/Nikola Tesla AD.

3.2 Trideset šest časova pre planiranog sletanja/poletanja ili za hitne slučajeve na sam dan izvršenja leta, izvršilac leta mora podneti koordinatoru letenja sledeće podatke:

a) naziv izvršioca leta;
b) tip vazduhoplova i MTOM;
c) pozivni znak vazduhoplova ili oznaku registracije vazduhoplova;
d) datum i vreme (UTC) sletanja/poletanja; i
e) SITA ili TEL ili e-mail osobe za kontakt.

3.3 Koordinator letenja

3.3.1 Radno vreme: 0600–1800;
u letnjem periodu 0500–1700
TEL: + 381 11 209 7345,
+ 381 64 848 5026
e-mail: flight.coordinator@beg.aero
SITA: BEGAPXH

3.3.2 U hitnim slučajevima
Radno vreme: 1800–0600;
u letnjem periodu 1700–0500
TEL: + 381 64 848 5470 Operativni centar
+ 381 64 848 5442 Šef smene

4. Ograničenja kapaciteta platforme

Zbog ograničenja u kapacitetu platforme, maksimalno vreme parkiranja za sve vanredne kargo letove je ograničeno na 6 sati, dok je maksimalno vreme parkiranja za helikoptere ograničeno na 4 sata. Za dodatne informacije u vezi sa ograničenjima, potrebno je izvršiti koordinaciju sa koordinatorom letenja u skladu sa tačkom 3.

5. Postupak odleđivanja i zaštite od zaleđivanja

5.1 Zahtev za izvođenje postupka odleđivanja i zaštite od zaleđivanja

Vođa vazduhoplova upućuje zahtev AKL BEOGRAD (BEOGRAD ATSU) za vršenje postupka odleđivanja i zaštite od zaleđivanja na frekvenciji 118.300 MHZ (pozivni znak BEOGRAD GROUND). Ovo se vrši prilikom potvrđivanja prethodno zahtevanih podataka za poletanje – Take-off Data.

Nakon toga, vođa vazduhoplova upućuje zahtev DAIC za vršenje postupka odleđivanja i zaštite od zaleđivanja najmanje 15 MIN pre startovanja vazduhoplova. Zahtev se upućuje preko frekvencije 121.550 MHZ koristeći pozivni znak BELGRADE DEICING 1 ili frekvencije 121.750 MHZ koristeći pozivni znak BELGRADE DEICING 2, u zavisnosti od pružaoca usluge odleđivanja i zaštite od zaleđivanja. Vođa vazduhoplova se identifikuje preko registracije vazduhoplova.

Zahtev mora da sadrži:

– da li se radi jednostepeni ili dvostepeni postupak;
– delove vazduhoplova koji će biti tretirani;
– procenat mešavine kojom se radi postupak.

3.2 Thirty six hours prior to the planned landing/take-off or in case of urgency on the same day when a flight is to be carried out, an operator shall submit to the flight coordinator, the following data:

a) name of operator;
b) aircraft type and MTOM;
c) aircraft identification or aircraft registration mark;
d) date and time (UTC) of landing/take-off; and
e) SITA or TEL or e-mail of the contact person.

3.3 Flight coordinator

3.3.1 Operational HR: 0600–1800;
during Summer time 0500–1700
TEL: + 381 11 209 7345,
+ 381 64 848 5026
e-mail: flight.coordinator@beg.aero
SITA: BEGAPXH

3.3.2 In urgent cases
Operational HR: 1800–0600;
during Summer time 1700–0500
TEL: + 381 64 848 5470 Operational center
+ 381 64 848 5442 Duty manager

4. Apron capacity constraints

Due to apron capacity constraints, maximum parking/ turnaround time for all ad-hoc (non-scheduled) cargo flights is limited to 6 hours, while maximum parking time for helicopters is limited to 4 hours. For additional information regarding constraints, it is necessary to coordinate with the flight coordinator in accordance with item 3.

5. De/anti-icing procedure

5.1 Request for de/anti-icing procedure

Request for de/anti-icing procedure shall be submitted to BEOGRAD ATSU by the pilot-in-command over 118.300 MHZ frequency (call sign BEOGRAD GROUND). This shall be done after confirmation of the requested Take-off Data.

After that, request for de/anti-icing procedure shall be submitted to the DAIC by pilot-in-command, at latest 15 MIN before starting the aircraft. The request shall be submitted over 121.550 MHZ frequency using the call sign BELGRADE DEICING 1 or 121.750 MHZ frequency using the call sign BELGRADE DEICING 2, depending on the de/anti-icing service provider. Pilot-in-command shall identify himself by aircraft registration.

The request must include:

– one step or two step process;
– parts of aircraft to be treated;
– fluid/water mixture, expressed as a percentage by volume.

5.2 Mesto obavljanja postupka odleđivanja i zaštite od zaleđivanja

Postupak odleđivanja i zaštite od zaleđivanja se obavlja nakon postavljanja vazduhoplova:

– na pozicije za odleđivanje i zaštitu od zaleđivanja N1 i N2 na platformi N za vazduhoplove raspona krila do 36 M;
– na poziciju za odleđivanje i zaštitu od zaleđivanja N1A na platformi N za vazduhoplove raspona krila od 36,01 M do 65,00 M;
– na poziciju za odleđivanje i zaštitu od zaleđivanja W1 na platformi W za vazduhoplove raspona krila do 36,00 M;
– na poziciju za odleđivanje i zaštitu od zaleđivanja W1A na platformi W za vazduhoplove raspona krila od 36,01 M do 60,30 M;
– na poziciju za odleđivanje i zaštitu od zaleđivanja W2 na TWY T za vazduhoplove raspona krila do 36,00 M.

Kada su platforme N i/ili W zauzete, postupak se može obavljati van pozicije za odleđivanje i zaštitu od zaleđivanja vazduhoplova:

– na pozicijama za parkiranje vazduhoplova generalne avijacije od A11 do A14;
– na prostoru TWY G za vazduhoplove koji su izgurani ili izvučeni sa parking pozicija A1 do A10 i E1 do E4. Prostor obuhvata poziciju sa koje je vazduhoplov izguran ili izvučen i susednu poziciju u pravcu guranja;
– na prostoru TWY H za vazduhoplove koji su izgurani ili izvučeni sa parking pozicija B1 do B10. Prostor obuhvata poziciju sa koje je vazduhoplov izguran ili izvučen i susednu poziciju u pravcu guranja;
– na prostoru TWY F za vazduhoplove sa rasponom krila do 36 M koji su izgurani ili izvučeni sa parking pozicija C1 do C14. Prostor obuhvata poziciju sa koje je vazduhoplov izguran ili izvučen i susednu poziciju u pravcu guranja;
– na određenim tačkama na TWY F: DEICING HOLD 1 i DEICING HOLD 2 – za vazduhoplove raspona krila od 36,01 M do 65,00 M. DEICING HOLD 1 i DEICING HOLD 2 ne mogu biti korišćene istovremeno.

Napomena: Izuzetno, postupak odleđivanja i zaštite od zaleđivanja može da se vrši na pozicijama za parkiranje vazduhoplova A1 do A10, B1 do B10, C1 do C14 i E1 do E4, samo po odobrenju Dežurnog menadžera aerodroma uz naplatu dodatnih troškova čišćenja pozicije od ostataka fluida za odleđivanje i zaštitu od zaleđivanja.

DAIC će odrediti na kojoj od pozicija će se vršiti postupak odleđivanja i zaštite od zaleđivanja.

AKL BEOGRAD (BEOGRAD ATSU) će dati instrukcije za taksiranje do određenih pozicija za odleđivanje i zaštitu od zaleđivanja. Vazduhoplov će biti zaustavljen na prečki za zaustavljanje F4 odakle će biti upućen na zadatu poziciju od strane AKL BEOGRAD (BEOGRAD ATSU).

Vazduhoplovi će biti vođeni do pozicije za odleđivanje i zaštitu od zaleđivanja pomoću svetala centralne linije. Zaustavljanje vazduhoplova na pozicijama za odleđivanje i zaštitu od zaleđivanja N1, N1A, N2, W1, W1A i W2 vrši se pomoću parker signaliste.

Ukoliko je vazduhoplov na poziciji za odleđivanje i zaštitu od zaleđivanja N1A, pozicije N1 i N2 se ne mogu koristiti.

Postupak odleđivanja i zaštite od zaleđivanja se može vršiti istovremeno na pozicijama N1 i N2.

Ukoliko je vazduhoplov na poziciji za odleđivanje i zaštitu od zaleđivanja W1A, pozicija W1 se ne može koristiti.

5.2 De/anti-icing position

De/anti-icing procedure is executed, after positioning of aircraft, on:

– de/anti-icing stands N1 and N2 on apron N for aircraft with a wingspan up to 36 M;
– de/anti-icing stand N1A on apron N for aircraft with a wingspan from 36.01 M to 65.00 M;
– de/anti-icing stand W1 on apron W for aircraft with a wingspan up to 36.00 M;
– de/anti-icing stand W1A on apron W for aircraft with a wingspan from 36.01 M to 60.30 M;
– de/anti-icing stand W2 at TWY T for aircraft with a wingspan up to 36.00 M.

When aprons N and/or W are occupied, the procedure can be performed outside the designated de/anti-icing stands, on:

– general aviation parking stands A11 to A14;
– TWY G for aircraft which are pushed or pulled from A1 to A10 and E1 to E4 parking stands. Position includes parking stand from which aircraft is pushed or pulled and the next aircraft parking stand in the direction of aircraft movement;
– TWY H for aircraft which are pushed or pulled from B1 to B10 parking stands. Position includes parking stand from which aircraft is pushed or pulled and the next aircraft parking stand in the direction of aircraft movement;
– TWY F for aircraft, wingspan up to 36 M, which are pushed or pulled from C1 to C14 parking stands. Position includes parking stand from which aircraft is pushed or pulled and the next aircraft parking stand in the direction of aircraft movement;
– TWY F: on DEICING HOLD 1 and DEICING HOLD 2 for aircraft with wingspan from 36.01 M up to 65.00 M. DEICING HOLD 1 and DEICING HOLD 2 cannot be used simultaneously.

Note: Exceptionally de/anti-icing could be executed on aircraft stands A1 to A10, B1 to B10, C1 to C14 and E1 to E4 only if aerodrome duty manager authorize it. In this case the aircraft stand cleaning from the rest of de/anti-icing fluid is additionally charged.

DAIC will assign stand for de/anti-icing procedure.

Instructions for taxiing to the de/anti-icing stands will be issued by BEOGRAD ATSU. The aircraft will be stopped at F4 stop bar from where it will be guided to the assigned stand by BEOGRAD ATSU.

Aircraft will be guided to the de/anti-icing stands with the aid of centerline lighting. Stopping guidance on de/anti-icing stands N1, N1A, N2, W1, W1A and W2 shall be given by marshaller.

If the aircraft is on the de/anti-icing stand N1A, stands N1 and N2 cannot be used.

De/anti-icing procedure can be performed simultaneously at stands N1 and N2.

If the aircraft is on the de/anti-icing stand W1A, stand W1 cannot be used.

Postupak odleđivanja i zaštite od zaleđivanja se može vršiti istovremeno na pozicijama W1 i W2 ili W1A i W2.

5.3 Provera nakon završenog postupka odleđivanja i zaštite od zaleđivanja

Ova provera se obavlja odmah nakon završetka postupka odleđivanja i zaštite od zaleđivanja na određenoj površini vazduhoplova. Vrši se vizuelno ili neposrednim dodirivanjem tretirane površine. Lice koje vrši proveru je u kontaktu sa vođom vazduhoplova putem interkomske veze.

5.4 Komunikacija

Pozicije za odleđivanje i zaštitu od zaleđivanja se nalaze u nadležnosti AKL BEOGRAD (BEOGRAD ATSU), izuzev tokom vršenja postupka odleđivanja i zaštite od zaleđivanja kada je nadležnost privremeno predata operateru aerodroma – DAIC.

Vođa vazduhoplova koji je u redu za postupak odleđivanja i zaštite od zaleđivanja mora pratiti komunikaciju sa DAIC na frekvenciji 121.550 MHZ.

Tokom vršenja postupka odleđivanja i zaštite od zaleđivanja vođa vazduhoplova je u vezi sa DAIC putem frekvencije 121.550 MHZ.

Nakon završetka postupka odleđivanja i zaštite od zaleđivanja, DAIC saopštava vođi vazduhoplova kôd zaštite od zaleđivanja vazduhoplova i obaveštava vođu vazduhoplova da je dužan da kontaktira AKL BEOGRAD (BEOGRAD ATSU) radi nastavka voženja do praga RWY.

6. Pokretanje motora na parking poziciji

Linijsko održavanje – LRU (line-replaceable unit) je jedino održavanje koje je dozvoljeno da se izvodi na parking pozicijama.

Strogo je zabranjeno testiranje motora na platformi i manevarskim površinama.

Pokretanje motora na parking poziciji dozvoljeno je samo u režimu IDLE.

7. Kritične tačke (Hot spots)

Kritična tačka 1 (Hot spot 1): Raskrsnica sa velikim obimom odlazećeg i dolazećeg saobraćaja sa RWY 12L/30R i RWY 12R/30L. Vozila koriste ovu raskrsnicu. Moguća greška prilikom kretanja - vazduhoplov koji napušta RWY 12L/30R preko TWY R4 mora biti svestan potencijalne zabune izmedu TWY D3 i TWY D4.

Kritična tačka 2 (Hot spot 2): Raskrsnica sa velikim obimom odlazećeg i dolazećeg saobraćaja sa RWY 12L/30R i RWY 12R/30L. Vozila koriste ovu raskrsnicu.

Kritična tačka 3 (Hot spot 3): Raskrsnica sa velikim obimom saobraćaja za vazduhoplove koji taksiraju. Servisni put preseca TWY L. Hot spot zona mogućih incidenata između aerodromske opreme i vazduhoplova u prevlačenju ili vazduhoplova koji izlazi sa parking pozicije B10. Posade moraju biti na oprezu.

Kritična tačka 4 (Hot spot 4): Raskrsnica rulnih staza sa kompleksnom geometrijom. Posade moraju biti na oprezu.

Za grafički prikaz kritičnih tačaka (hot spots), videti karte AD 2 LYBE 01.1–1/2 i AD 2 LYBE 02.1–1/2.

De/anti-icing procedure can be performed simultaneously at stands W1 and W2 or W1A and W2.

5.3 De/anti-icing check

The check of determined ACFT surface is conducted immediately after the end of de/anti-icing procedure. The method of check is visual or direct contact of the treated aircraft surfaces. Person who executes this check communicates with pilot-in-command by intercom.

5.4 Communication

De/anti-icing stands are located within the area of responsibility of BEOGRAD ATSU. Responsibility is temporarily transferred to aerodrome operator – DAIC during de/anti-icing procedure.

Pilot-in-command of the aircraft scheduled for de/anti-icing procedure must maintain air-ground voice communication watch with DAIC on 121.550 MHZ frequency.

During the de/anti-icing procedure aircraft maintains communication with DAIC on 121.550 MHZ frequency.

After the completion of de/anti-icing procedure, DAIC will communicate pilot-in-command de/anti-icing code and inform pilot-in-command that he is obliged to contact BEOGRAD ATSU in order to continue taxiing to the RWY.

6. Engine start on parking position

Line maintenance – LRU (line-replaceable unit) is the only maintenance that is allowed to perform on parking positions.

Engine testing is strictly forbidden on apron and maneuvering areas.

Engine start in parking position is allowed only in IDLE mode.

7. Hot spots

Hot spot 1: This is a high volume intersection for all traffic taxiing from departure and arrival RWY 12L/30R and RWY 12R/30L. Vehicles also crossing in this area. Possible routing error - aircraft vacating RWY 12L/30R at TWY R4 to be aware of potential confusion between TWY D3 and TWY D4.

Hot spot 2: This is a high volume intersection for all traffic taxiing from departure and arrival RWY 12L/30R and RWY 12R/30L. Vehicles also crossing in this area.

Hot spot 3: This is a high volume intersection for taxiing aircraft. A service road crossing TWY L. Hot spot area with potential of incidents between ground service equipment and towed aircraft or aircraft exiting parking stand B10. Pilots are to exercise caution.

Hot spot 4: This is a complex geometry TWY intersection. Pilots are to exercise caution.

For graphical interpretation of hot spots, see charts AD 2 LYBE 01.1–1/2 and AD 2 LYBE 02.1–1/2.

LYBE AD 2.21 POSTUPCI ZA SMANJENJE BUKE
NOISE ABATEMENT PROCEDURES

Poletanja sa RWY 12L i RWY 12R mlaznih vazduhoplova

Od poletanja do 800 FT (240 M) iznad AD ELEV:

– snaga/potisak pri poletanju
– najmanji odgovarajući položaj zakrilaca/pretkrilaca pri poletanju
– penjati pri brzini V_2+10 KT

Na 800 FT (240 M) iznad AD ELEV:

– smanjiti potisak na maksimalni potisak pri penjanju

Od 800 FT (240 M) do 3000 FT (900 M):

– nastaviti penjanje pri brzini V_2+10 KT do 20 KT
– održavati smanjenu snagu/potisak
– održavati najmanji odgovarajući položaj zakrilaca/ pretkrilaca pri poletanju

Na 3000 FT (900 M):

– održavati pozitivnu brzinu penjanja
– ubrzati postepeno do brzine penjanja na ruti/vazdušnom putu
– uvući zakrilca/pretkrilca prema planu

U skladu sa bezbednosnom naredbom Direktorata civilnog vazduhoplovstva Republike Srbije, poletanja sa RWY 12L, kao i sa RWY 12R kada je u upotrebi, su zabranjena za vazduhoplove tipa ILYUSHIN IL-76 i vazduhoplove koji poseduju potvrdu o buci ispod nivoa 3.

Bezbednosna naredba je objavljena na internet stranici:
http://cad.gov.rs

Za poletanje po SID TISAK 4Z, obavezno je korišćenje cele dužine RWY 12L, kao i cele dužine RWY 12R, kada je u upotrebi:

– tokom letnjeg računanja vremena:
0400 – 0500 (MON – FRI),
0400 – 0600 (SAT – SUN)
– tokom zimskog računanja vremena:
0500 – 0600 (MON – FRI),
0500 – 0700 (SAT – SUN)

RWY 12L and RWY 12R departures of turbojet aeroplanes

Take-off to 800 FT (240 M) above AD ELEV:

– take-off power/thrust
– lowest appropriate take-off flaps/slats
– climb at V_2+10 KT

At 800 FT (240 M) above AD ELEV:

– cut back to maximum climb thrust

From 800 FT (240 M) to 3000 FT (900 M):

– continue climb at V_2+10 KT to 20 KT
– maintain reduced power/thrust
– maintain lowest appropriate take-off flaps/slats

At 3000 FT (900 M):

– maintain positive rate of climb
– accelerate smoothly to en-route climb speed
– retract flaps/slats on schedule

In accordance with Safety order issued by the Civil Aviation Directorate of the Republic of Serbia, taking-off from RWY 12L, as well as RWY 12R when in use, is prohibited for ILYUSHIN IL-76 and aircraft with Noise Certificate below Stage 3.

Safety order is published on the website:
http://cad.gov.rs/en

For departures via SID TISAK 4Z, use of RWY 12L full length, as well as full length of RWY 12R when in use, is mandatory:

– during summer time:
0400 – 0500 (MON – FRI),
0400 – 0600 (SAT–SUN)
– during winter time:
0500 – 0600 (MON – FRI),
0500 – 0700 (SAT – SUN)

LYBE AD 2.22 POSTUPCI ZA LETENJE
FLIGHT PROCEDURES

1. Operacije pri smanjenoj vidljivosti

1.1 Opšte

Na AD BEOGRAD/Nikola Tesla se mogu vršiti operacije pri smanjenoj vidljivosti, uključujući operacije prilaženja i sletanja CAT II/III.

1.2 Operacije prilaženja i sletanja CAT II/III

Operacije prilaženja i sletanja CAT II/III su odobrene za RWY 12L i RWY 12R. Operacije zavise od upotrebljivosti uređaja/sistema i postupaka koji su dati dalje u tekstu.

1. Low visibility operations

1.1 General

Low visibility operations including CAT II/III approach and landing operations are available at BEOGRAD/Nikola Tesla AD.

1.2 CAT II/III approach and landing operations

CAT II/III approach and landing operations are authorised on RWY 12L and RWY 12R. The operations are subject to the serviceability of the facilities/systems and procedures listed below.

1.3 Uređaji/sistemi

Sledeći uređaji CAT II/III su raspoloživi za RWY 12L i RWY 12R:

- ILS LOC (III.E.4), GP, DME;
- neprekidno napajanje;
- svetlosno obeležavanje:
  - svetlosni sistem za precizno prilaženje CAT II/III;
  - *svetla THR i kraja RWY;
  - *svetla ose RWY (razmak 15 M) i svetla ivice RWY (razmak 60 M);
  - svetla TDZ;
  - *žuto-zelena svetla ose na TWY B, E i D1-D7;
- dnevne oznake na manevarskim površinama;
- *rezervno napajanje (vreme uključivanja 1 SEC);
- *sistem za procenu RVR na pozicijama ALPHA (TDZ RWY 12L), BRAVO (sredina RWY 12L), CHARLIE (kraj RWY 12L), DELTA (TDZ RWY 12R), ECHO (sredina RWY 12R) i FOX (kraj RWY 12R).

Napomena: *Uređaji koji su potrebni za nevođena poletanja pri smanjenoj vidljivosti (videti tačku 1.5.10.1).

1.4 Kriterijumi za pokretanje i prestanak postupaka pri smanjenoj vidljivosti (LVP)

Pokretanje LVP se sprovodi u dve faze:

- pripremna faza
- operativna faza.

Pripreme za LVP počinju kada:

- RVR na TDZ ili na sredini RWY opadne na 1000 M; i/ili
- se baza oblaka/vertikalna vidljivost spusti na 90 M (300 FT) sa tendencijom daljeg smanjenja.

LVP stupaju na snagu kada:

- RVR na TDZ ili na sredini RWY opadne ispod 550 M; i/ili
- se baza oblaka/vertikalna vidljivost spusti ispod 60 M (200 FT).

Piloti će biti obavešteni, prilikom prvog kontakta, preko RTF sledećom standardnom porukom: „LOW VISIBILITY PROCEDURES IN FORCE“.

LVP prestaju kada je RVR 550 M ili iznad i baza oblaka/ vertikalna vidljivost 60 M ili iznad uz očekivanje da će se ovi uslovi poboljšavati.

Piloti će biti obavešteni preko RTF sledećom frazom: „LOW VISIBILITY PROCEDURES CANCELLED AT TIME ____“.

1.5 ATC postupci

1.5.1 Informacije koje se daju pilotima

APP ili TWR će prosleđivati sledeće informacije pilotu vazduhoplova u dolasku:

a) pravac i brzinu prizemnog vetra uz odobrenje za prilaženje;

b) RVR uz odobrenje za prilaženje i prilikom preleta 4 NM od TDZ;

c) za vreme prilaženja, odmah po nastupanju pojave: kvar ili otkaz radio-navigacionih uređaja, dela sistema svetlosnog obeležavanja, transmisiometra, anemometra, rezervnog napajanja itd;

d) bitne promene vrednosti RVR (50 M ili više).

1.3 Facilities/systems

The following CAT II/III facilities are available for RWY 12L and RWY 12R:

- ILS LOC (III.E.4), GP, DME;
- No-break power supply;
- Lighting:
  - Precision approach CAT II/III lighting system;
  - *THR and RWY end lights;
  - *RWY centre line (15 M intervals) and RWY edge light (60 M intervals);
  - TDZ lights;
  - *colour coded yellow-green TWY centre line lights on TWY B, E and D1-D7;
- Markings on maneuvering area;
- *Secondary power supply (switch-over time 1 SEC);
- *RVR assessment system at position ALPHA (RWY 12L TDZ), BRAVO (RWY 12L mid-point), CHARLIE (RWY 12L stop end), DELTA (RWY 12R TDZ), ECHO (RWY 12R mid-point) and FOX (RWY 12R stop end).

Note: *Facilities required for non-guided low visibility take-off (see item 1.5.10.1).

1.4 Criteria for the initiation and termination of low visibility procedures (LVP)

The initiation of LVP will be implemented in two phases:

- Preparation phase
- Operations phase.

Preparations for LVP commence when:

- RVR at TDZ or RWY mid-point reaches 1000 M downward; and/or
- cloud base/vertical visibility reaches 90 M (300 FT) downward with further downward tendency.

LVP become effective when:

- RVR at TDZ or at RWY mid-point reaches values less than 550 M, and/or
- cloud base/vertical visibility reaches values less than 60 M (200 FT).

Pilots will be informed by RTF on first contact by the following standard message: “LOW VISIBILITY PROCEDURES IN FORCE”.

LVP will be terminated when the RVR is 550 M or greater and the ceiling of cloud base/vertical visibility is 60 M or above and a continuing improvement of these conditions is expected.

Pilots will be informed by RTF using the phraseology: “LOW VISIBILITY PROCEDURES CANCELLED AT TIME_____”.

1.5 ATC Procedures

1.5.1 Information given to pilots

APP or TWR will transmit following information to a pilot of arriving aircraft:

a) direction and velocity of the surface wind together with approach clearance;

b) RVR together with approach clearance and additionally when passing 4 NM from TDZ;

c) during approach, immediately after occurrence: failure or malfunction of radio navigation aids, part of the lighting system, transmissometer, anemometer, secondary power supply etc.;

d) significant variations of RVR values (50 M or more).

Nakon preleta FAF-a vođa vazduhoplova donosi odluku da li nastavlja prilaženje CAT II/III ili ne.

1.5.2 Radarsko vektorisanje

Vazduhoplovi u dolasku se vektorišu tako da preseku snop lokalajzera na visini od 3000 FT AMSL na tački LABUD za RWY 12L, odnosno na tački LAMBA za RWY 12R.

1.5.3 Razdvajanje

1.5.3.1 Opšte

Vazduhoplov koji prilazi po CAT II/III ne sme da preleti FAF (WEGGE za RWY 12L, odnosno ROZGI za RWY 12R) pre nego što je prethodni vazduhoplov sleteo.

Razdvajanje između vazduhoplova koji prilazi po CAT II/III i vazduhoplova koji ubrzava za poletanje, mora da osigura da vazduhoplov u odlasku preleti antenu lokalajzera, pre nego što se vazduhoplov u dolasku nađe na 2 NM od TDZ. Kako bi se ovo postiglo, vazduhoplov u odlasku mora da započne poletanje pre nego što vazduhoplov u dolasku preleti WEGGE za RWY 12L, odnosno ROZGI za RWY 12R.

Vazduhoplovu koji prilazi po CAT II/III na RWY 12R, neće se izdati odobrenje za sletanje, sve dok se na TWY A nalazi vazduhoplov raspona krila od 36,01 M do 65,00 M. Kako bi se ovo postiglo, vremenski interval na sletanju, između vazduhoplova raspona krila od 36,01 M do 65,00 M i sustižućeg vazduhoplova ne sme biti manji od 12 MIN.

Vazduhoplovu, raspona krila od 36,01 M do 65,00 M, koji prilazi po CAT II/III na RWY 12R, neće se izdati odobrenje za sletanje, sve dok se na TWY A nalazi drugi vazduhoplov. Kako bi se ovo postiglo, vremenski interval na sletanju, između vazduhoplova raspona krila od 36,01 M do 65,00 M i prethodnog vazduhoplova ne sme biti manji od 12 MIN.

Piloti vazduhoplova u dolasku će biti obavešteni preko RTF ili ATIS o primeni ATC postupaka za operacije pri smanjenoj vidljivosti: „LOW VISIBILITY PROCEDURES IN FORCE“.

Primenjuju se sledeća vremenska rastojanja između dva uzastopna vazduhoplova u prilazu za RWY 12L i RWY 12R u odnosu na uslove vidljivosti:

– **Uslovi vidljivosti 1** – RVR manji od 550 M:
  5 MIN između dva uzastopna vazduhoplova u dolasku;
– **Uslovi vidljivosti 2** – RVR manji od 800 M, a jednak ili veći od 550 M:
  3 MIN između dva uzastopna vazduhoplova u dolasku.

1.5.3.2 Površine za kretanje

Razdvajanje vazduhoplova na površinama za kretanje vrši se u skladu sa ICAO Doc 9476-AN/927 – Priručnik o sistemima za vođenje i kontrolu kretanja, tačka 4.5.

U slučaju kada je RVR 400 M i više, vazduhoplovi se mogu razdvajati bez upotrebe prečki za zaustavljanje.

1.5.4 Odobrenje za prilaženje

ATC izdaje odobrenja za prilaženje po ILS-u bez obzira na kategoriju prilaženja.

1.5.5 Odobrenje za sletanje

Odobrenje za sletanje će biti, po pravilu, izdato pre nego što se vazduhoplov (u dolasku) nađe na rastojanju ne manjem od 2 NM od THR. U posebnim slučajevima izdavanje odobrenja može da kasni do rastojanja od 1 NM od THR i u tom slučaju će piloti biti na odgovarajući način informisani.

After passing FAF, it is the decision of the pilot-in-command whether or not a CAT II/III approach will be continued.

1.5.2 Radar vectoring

Arriving aircraft are vectored so as to ensure a localizer intercept at 3000 FT AMSL on LABUD point for RWY 12L, or on LAMBA point for RWY 12R.

1.5.3 Separation

1.5.3.1 General

An aircraft carrying out a CAT II/III approach shall not pass the FAF (WEGGE for RWY 12L, or ROZGI for RWY 12R) before the preceding aircraft has landed.

Separation between an aircraft carrying out a CAT II/III approach and an aircraft rolling for take-off, shall ensure that the departing aircraft will pass over the ILS localizer antenna before the arriving aircraft reaches a point 2 NM from TDZ. To achieve this, the departing aircraft must commence its take-off run before the arriving aircraft overfly WEGGE for RWY 12L, or ROZGI for RWY 12R.

A landing clearance shall not be issued to an aircraft carrying out a CAT II/III approach on RWY 12R as long as there is an aircraft with a wingspan from 36.01 M up to 65.00 M on TWY A. In order to achieve this, the time interval on landing between an aircraft with a wingspan from 36.01 M up to 65.00 M and an approaching aircraft shall not be less than 12 MIN.

A landing clearance shall not be issued to an aircraft with a wingspan from 36.01 M up to 65.00 M carrying out a CAT II/III approach on RWY 12R as long as there is another aircraft on TWY A. In order to achieve this, the time interval on landing between an aircraft with a wingspan from 36.01 M up to 65.00 M and previous aircraft shall not be less than 12 MIN.

Pilots of arriving aircraft will be informed about application of ATC procedures for low visibility operations via RTF or ATIS: “LOW VISIBILITY PROCEDURES IN FORCE”.

The following time base spacing between two successive arriving aircraft on RWY 12L and RWY 12R regarding visibility conditions are applied:

– **Visibility condition 1** – RVR less than 550 M:
  5 MIN between two successive arriving aircraft;
– **Visibility condition 2** – RVR less than 800 M and equal or greater than 550 M:
  3 MIN between two successive arriving aircraft.

1.5.3.2 Movement Area

Separation of aircraft on the movement area is achieved according to ICAO Doc 9476-AN/927 – Manual of surface movement guidance and control systems, item 4.5.

In case that RVR is 400 M or greater, aircraft can be separated without usage of stop bars.

1.5.4 Clearance for approach

ATC issues a clearance for ILS approach regardless of the category flown.

1.5.5 Landing clearance

Landing clearance shall be delivered normally prior an (arriving) aircraft reaches a distance of more than 2 NM from THR. In exceptional cases transmission may be delayed until a distance of 1 NM from THR, in which case pilots must be informed accordingly.

1.5.6 Postupci pilota

Kad god se izvršava prilaženje pri smanjenoj vidljivosti, pilot mora da napusti RWY 12L preko TWY E, odnosno RWY 12R preko TWY D7. Pilot mora da javi da je sleteo i, dodatno, da je napustio RWY kada prođe kraj žuto-zelenih svetala ose TWY.

Vazduhoplov u odlasku mora da koristi TWY B ili TWY C kada je RWY 12L u upotrebi za poletanje, odnosno TWY D1, TWY D2, TWY D3, TWY D4 ili TWY T kada je RWY 12R u upotrebi za poletanje.

Vazduhoplov u odlasku mora da koristi TWY E kada je RWY 30R u upotrebi za poletanje, odnosno TWY D5, TWY D6 ili TWY D7 kada je RWY 30L u upotrebi za poletanje.

Pilot mora da održava radio-kontakt sa ATC sve vreme kada je van parking pozicije.

Pilot mora da izvesti kada je stigao na parking poziciju pre nego što isključi motore.

1.5.7 Započinjanje i nastavljanje prilaženja po ILS-u uzimajući u obzir dobijene podatke o RVR

Pilot može da započne prilaz, bez obzira da li dobijeni podaci o RVR na TDZ zadovoljavaju zahtevane minimume avio-prevozioca za RVR na TDZ. Prilaženje ne sme biti nastavljeno nakon 4 NM od TDZ ukoliko dobijeni RVR na TDZ nije bar jednak minimalnom zahtevanom RVR. Kada preleti 4 NM od TDZ, pilot može nastaviti prilaženje bez obzira na dobijene promene RVR-a, snižavajući do DH. Od DH prilaženje može biti nastavljeno do sletanja ako je uspostavljena zahtevana vizuelna referenca i ako se ona može održavati.

Napomena: Vrednosti OCA(H) se daju na odgovarajućim kartama instrumentalnog prilaženja.

1.5.8 Informacije o neispravnosti uređaja i degradiranje postupka prilaženja

Izmena operativnog statusa radio-navigacionih uređaja i sistema svetlosnog obeležavanja biće objavljena NOTAM-om, ako je prouzrokovana otkazom za koji se očekuje da traje duže od jednog sata.

U toku prilaženja, odmah po nastupanju otkaza, ATC će inicirati degradiranje LVP operacija prilaženja u skladu sa narednom tabelom.

Za otkaze koji će trajati kraće od jednog sata, ATC će (putem RTF) obavestiti pilote o razlozima degradacije LVP prilaženja.

1.5.6 Pilots procedures

Whenever low visibility approaches are carried out, the pilots shall vacate RWY 12L via TWY E, or RWY 12R via TWY D7. Pilots shall report when landed and additionally RWY vacated when passing the end of the colour coded yellow-green TWY centre line lights.

Departing aircraft shall use TWY B or TWY C when departing RWY 12L is in use, or TWY D1, TWY D2, TWY D3, TWY D4 or TWY T when departing RWY 12R is in use.

Departing aircraft shall use TWY E when departing RWY 30R is in use, or TWY D5, TWY D6 or TWY D7 when departing RWY 30L is in use.

Pilots shall maintain radio-contact with ATC at all times when outside of parking positions.

Pilots shall report when on parking position before engine shut-down.

1.5.7 Initiation and continuation of an ILS approach taking into account the reported RVR

A pilot may initiate an approach, regardless on whether the reported touch-down zone RVR does or does not meet the aircraft operator's required minimum RVR value for TDZ. An approach, however, must not be continued beyond 4 NM from TDZ unless the reported TDZ RVR is at least equal to the minimum required RVR. When the pilot has passed 4 NM from TDZ, he may continue approach regardless of any RVR changes reported, descending to the DH. From DH the approach may be continued to the landing provided that the required visual reference can be established and maintained.

Note: The OCA(H) values are promulgated on the respective instrument approach charts.

1.5.8 Information regarding malfunction and downgrading of the approach procedure

A change of operational status of a radio navigation aid or aerodrome lighting system, caused by a failure which is expected to last more than one hour, will be promulgated by NOTAM.

During approach, immediately after failure occurrence, ATC will initiate downgrading of LVP according to the following table.

In case of shorter failures (less than one hour), pilots will be notified of causes for downgrading approach LVP by ATC (through RTF).

Razmatrani sistemi / Systems considered	***Otkaz koji prijavljuje ATC / Failure to be reported by ATC***	***Očekivana posledica na prilaz po ILS i operacije sletanja / Expected effect on ILS approach and landing operations***
1	***2***	***3***
ILS	ILS neupotrebljiv ILS unserviceable	Ograničeno na neprecizno prilaženje Restricted to non-precision approach
	ILS degradiran na CAT II ILS downgraded to CAT II	Letenje ograničeno na CAT II Flight operations limited to CAT II
	ILS degradiran na CAT I ILS downgraded to CAT I	Letenje ograničeno na CAT I Flight operations limited to CAT I
	Osetljiva oblast LOC nije napuštena LOC sensitive area not vacated	Letenje ograničeno na CAT I Flight operations limited to CAT I
	DME neupotrebljiv DME unserviceable	CAT I

Razmatrani sistemi / Systems considered	***Otkaz koji prijavljuje ATC / Failure to be reported by ATC***	***Očekivana posledica na prilaz po ILS i operacije sletanja / Expected effect on ILS approach and landing operations***
1	***2***	***3***
Sistem svetlosnog obeležavanja Lighting system	Sistem svetlosnog obeležavanja RWY neupotrebljiv RWY lighting system unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
	Prilazna svetla neupotrebljiva Approach lighting unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
	Svetla ivice RWY neupotrebljiva RWY edge lighting unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
	Svetla ose RWY neupotrebljiva RWY centerline lighting unserviceable	Letenje ograničeno na CAT I Flight operations limited to CAT I
	Svetla zone dodira neupotrebljiva Touch Down Zone lighting unserviceable	Letenje ograničeno na CAT I Flight operations limited to CAT I
	Sistem svetlosnog obeležavanja TWY neupotrebljiv Taxiway lighting system unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
	Prečka za zaustavljanje A neupotrebljiva Stop bar A unserviceable	Operacije ograničene na jedan vazduhoplov na manevarskim površinama Operations limited to one aircraft on maneuvering areas
	Prečka za zaustavljanje B CAT III neupotrebljiva Stop bar B CAT III unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY B zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY B is closed
	Jedna od prečki za zaustavljanje D1-D7 neupotrebljiva One of stop bars D1-D7 unserviceable	Nema posledica na RWY 12R ako je RWY 12R zaštićena na drugi način Nema posledica na RWY 12L No effect on RWY 12R if RWY 12R protection is ensured by other means No effect on RWY 12L
	Više od jedne prečke za zaustavljanje D1-D7 neupotrebljivo More than one of stop bars D1-D7 unserviceable	Operacije ograničene na jedan vazduhoplov na manevarskim površinama ukoliko je RWY 12R u upotrebi Nema posledica na RWY 12L Operations limited to one aircraft on maneuvering areas if RWY 12R in use No effect on RWY 12L
	Prečka za zaustavljanje C CAT III neupotrebljiva Stop bar C CAT III unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY C zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY C is closed
	Prečka za zaustavljanje E CAT III neupotrebljiva Stop bar E CAT III unserviceable	Letenje ograničeno na CAT I za RWY 12L Nema posledice za RWY 12R, ako je TWY E zatvorena Flight operations limited to CAT I for RWY 12L No effect on RWY 12R, if TWY E is closed
	Prečka za zaustavljanje Y neupotrebljiva Stop bar Y unserviceable	Nema posledice No effect
	Prečka za zaustavljanje M neupotrebljiva Stop bar M unserviceable	Nema posledice No effect
	Prečka za zaustavljanje N neupotrebljiva Stop bar N unserviceable	Nema posledica na RWY 12R ako je RWY 12R zaštićena na drugi način Nema posledica na RWY 12L No effect on RWY 12R if RWY 12R protection is ensured by other means No effect on RWY 12L
	Prečka za zaustavljanje T neupotrebljiva Stop bar T unserviceable	Nema posledica na RWY 12R ako je RWY 12R zaštićena na drugi način Nema posledica na RWY 12L No effect on RWY 12R if RWY 12R protection is ensured by other means No effect on RWY 12L
	Prečka za zaustavljanje T1 neupotrebljiva Stop bar T1 unserviceable	Nema posledice No effect
	Prečka za zaustavljanje F neupotrebljiva Stop bar F unserviceable	Nema posledice No effect
	Prečka za zaustavljanje F1 neupotrebljiva Stop bar F1 unserviceable	Nema posledice No effect

Razmatrani sistemi / Systems considered	*Otkaz koji prijavljuje ATC / Failure to be reported by ATC*	*Očekivana posledica na prilaz po ILS i operacije sletanja / Expected effect on ILS approach and landing operations*
1	*2*	*3*
	Prečka za zaustavljanje F3 neupotrebljiva Stop bar F3 unserviceable	Nema posledice No effect
	Prečka za zaustavljanje F4 neupotrebljiva Stop bar F4 unserviceable	Nema posledice No effect
	Prečka za zaustavljanje G neupotrebljiva Stop bar G unserviceable	Nema posledice No effect
	Prečka za zaustavljanje H neupotrebljiva Stop bar H unserviceable	Nema posledice No effect
	Svetla zabrane ulaza R1 neupotrebljiva No entry bar R1 unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY R1 zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY R1 is closed
	Svetla zabrane ulaza R2 neupotrebljiva No entry bar R2 unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY R2 zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY R2 is closed
	Svetla zabrane ulaza R3 neupotrebljiva No entry bar R3 unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY R3 zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY R3 is closed
	Svetla zabrane ulaza R4 neupotrebljiva No entry bar R4 unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY R4 zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY R4 is closed
	Prečka za zaustavljanje ZORAN neupotrebljiva Stop bar ZORAN unserviceable	Primenjuje se vremensko rastojanje od 8 MIN između dva uzastopna vazduhoplova u prilazu za RWY 12L i RWY 12R, kada je RVR manji od 550 M 8 MIN time base spacing applied between two successive arriving aircraft on RWY 12L and RWY 12R for RVR less than 550 M
	Rezervno napajanje neupotrebljivo Standby power supply unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
RVR	RVR na TDZ neupotrebljiv Touchdown RVR unserviceable	Nema ograničenja ako je raspoloživ RVR na sredini RWY No limitation if mid-point RVR available
	TDZ + MID RVR neupotrebljivi TDZ + MID RVR unserviceable	Letenje ograničeno na CAT I Flight operations limited to CAT I
	RVR pokazivač neupotrebljiv RVR display unserviceable	Letenje ograničeno na CAT I Flight operations limited to CAT I
Pomoćni sistem Ancillary	Anemometar neupotrebljiv Anemometer unserviceable	Nema posledice ako su raspoloživi drugi sistemi No effect if other sources available
	Silometar neupotrebljiv Ceilometer unserviceable	Nema posledice No effect

1.5.9 Ograničenje

Kada je vrednost RVR ispod 350 M, rulanje vazduhoplova na sopstveni pogon biće dozvoljeno samo na delovima manevarskih površina opremljenih sistemom svetlosnog obeležavanja.

Taksiranje vazduhoplova sa parking pozicija A11 do A14, kada su LVP na snazi, dozvoljeno je samo uz instrukcije parker signaliste. Vođenje vazduhoplova vrši se od parking pozicije vazduhoplova do svetala centralne linije TWY G.

1.5.10 Poletanje pri smanjenoj vidljivosti

1.5.10.1 Opšte

RWY 12L i RWY 12R su pogodne za vođeno poletanje pri smanjenoj vidljivosti.

1.5.9 Restrictions

When RVR value is below 350 M, taxiing of aircraft under it's own power shall be allowed only on the parts of the maneuvering areas equipped with the lighting system.

Taxiing for departing of ACFT from ACFT stands A11 to A14, when LVP is in force, is allowed only with marshaller's instruction. Marshalling is provided from ACFT stand to the TWY G centre line lights.

1.5.10 Low visibility take-off

1.5.10.1 General

RWY 12L and RWY 12R are suitable for guided low visibility take-off.

RWY 30R je pogodna za vođeno poletanje pri smanjenoj vidljivosti.

RWY 30L nije pogodna za vođeno poletanje pri smanjenoj vidljivosti.

Zahtevani uređaji za nevođeno poletanje pri smanjenoj vidljivosti su označeni sa zvezdicom (*) pod tačkom 1.3.

Za poletanje pri smanjenoj vidljivosti, minimalna vidljivost duž poletno-sletne staze (RVR) za AD BEOGRAD/Nikola Tesla je 125 M.

1.5.10.2 Kriterijum za primenu LVP tokom poletanja pri smanjenoj vidljivosti

Po pravilu LVP se primenjuju za dolazeći i odlazeći saobraćaj. Ako se samo poletanje pri smanjenoj vidljivosti obavlja kada je RVR ispod 400 M, avio-prevozilac će zatražiti primenu postupaka pri smanjenoj vidljivosti.

Kada se vrše samo operacije poletanja pri smanjenoj vidljivosti, poruka treba da glasi: „LOW VISIBILITY TAKE OFF PROCEDURES IN FORCE“.

1.5.10.3 Izlazak na RWY

Izlazak na RWY 12L je dozvoljen samo preko TWY B ili TWY C.

Izlazak na RWY 12R je dozvoljen samo preko TWY T, TWY D1, TWY D2, TWY D3 ili TWY D4.

Izlazak na RWY 30R je dozvoljen samo preko TWY E.

Izlazak na RWY 30L je dozvoljen samo preko TWY D5, TWY D6 ili TWY D7.

1.5.10.4 Detalji o korišćenju pozicija za čekanje

Pozicija za čekanje za izlazak na RWY 12L je pozicija za čekanje na TWY B ili TWY C.

Pozicija za čekanje za izlazak na RWY 12R je pozicija za čekanje na TWY T, TWY D1, TWY D2, TWY D3 ili TWY D4.

Pozicija za čekanje za izlazak na RWY 30R je pozicija za čekanje na TWY E.

Pozicija za čekanje za izlazak na RWY 30L je pozicija za čekanje na TWY D5, TWY D6 ili TWY D7.

1.5.10.5 Nepredviđene situacije

U sledećim nepredviđenim situacijama očekivati asistenciju FOLLOW ME vozila:

– kada vazduhoplov prijavi da nije siguran u svoju poziciju na manevarskim površinama;
– kvar vazduhoplova na manevarskim površinama kada vazduhoplov nije u mogućnosti da samostalno napusti manevarske površine;
– gubitak dvostrane radio-veze sa vazduhoplovom na manevarskim površinama.

1.5.10.6 Degradiranje poletanja pri smanjenoj vidljivosti

Degradiranje operacija poletanja pri smanjenoj vidljivosti će inicirati ATC prema sledećem:

RWY 30R is suitable for guided low visibility take-off.

RWY 30L is not suitable for guided low visibility take-off.

Facilities required for non guided low visibility take-off are marked with an asterisk (*) in item 1.3.

The fixed minimum RVR value for low visibility take-off at BEOGRAD/Nikola Tesla AD is 125 M.

1.5.10.2 Criteria for the implementation of LVP during low visibility take-off

Normally LVP are applied for arriving and departing traffic. If low visibility take-off only is conducted when RVR is below 400 M, the aircraft operator shall request LVP procedures to be provided.

When low visibility take-off only is in operation, the message should read: “LOW VISIBILITY TAKE OFF PROCEDURES IN FORCE”.

1.5.10.3 Details of RWY entries

Entry to RWY 12L is only permitted via TWY B or TWY C.

Entry to RWY 12R is only permitted via TWY T, TWY D1, TWY D2, TWY D3 or TWY D4.

Entry to RWY 30R is only permitted via TWY E.

Entry to RWY 30L is only permitted via TWY D5, TWY D6 or TWY D7.

1.5.10.4 Details of holding points to be used

The holding position to be used for RWY 12L is holding position on TWY B or TWY C.

The holding position to be used for RWY 12R is holding position on TWY T, TWY D1, TWY D2, TWY D3 or TWY D4.

The holding position to be used for RWY 30R is holding position on TWY E.

The holding position to be used for RWY 30L is holding position on TWY D5, TWY D6 or TWY D7.

1.5.10.5 Contingency

For contingency, expect the assistance of the FOLLOW ME vehicle:

– when an aircraft reports that it is not sure of its position on the maneuvering areas;
– failure of an aircraft on maneuvering areas when the aircraft is not able to leave the maneuvering areas on its own;
– two-way radio communication failure – aircraft on the maneuvering areas.

1.5.10.6 Downgrading of low visibility take-off

Downgrading of low visibility take-off operations will be initiated by ATC according to the following:

Razmatrani sistemi / Systems considered	*Otkaz koji prijavljuje ATC / Failure to be reported by ATC*	*Očekivana posledica na letenje / Expected effect on flying*
1	*2*	*3*
ILS	ILS neupotrebljiv ILS unserviceable	Nije dozvoljeno vođeno poletanje pri smanjenoj vidljivosti Guided low visibility take-off not permitted
	ILS degradiran na CAT II ili CAT I ILS downgraded to CAT II or CAT I	Nije dozvoljeno vođeno poletanje pri smanjenoj vidljivosti Guided low visibility take-off not permitted

Razmatrani sistemi / Systems considered	***Otkaz koji prijavljuje ATC / Failure to be reported by ATC***	***Očekivana posledica na letenje / Expected effect on flying***
1	***2***	***3***
Sistem svetlosnog obeležavanja Lighting system	Sistem svetlosnog obeležavanja RWY neupotrebljiv RWY lighting system unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
	Svetla ivice RWY neupotrebljiva RWY edge lighting unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
	Svetla ose RWY neupotrebljiva RWY centerline lighting unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
	Sistem svetlosnog obeležavanja TWY neupotrebljiv TWY lighting system unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
	Prečka za zaustavljanje A neupotrebljiva Stop bar A unserviceable	Operacije ograničene na jedan vazduhoplov na manevarskim površinama Operations limited to one aircraft on maneuvering areas
	Prečka za zaustavljanje B CAT III neupotrebljiva Stop bar B CAT III unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY B zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY B is closed
	Prečka za zaustavljanje C CAT III neupotrebljiva Stop bar C CAT III unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY C zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY C is closed
	Prečka za zaustavljanje E CAT III neupotrebljiva Stop bar E CAT III unserviceable	Letenje ograničeno na CAT I ukoliko je RWY 30R u upotrebi Nema posledica na RWY 30L, ako je TWY E zatvorena Flight operations limited to CAT I if RWY 30R in use No effect on RWY 30L, if TWY E is closed
	Jedna od prečki za zaustavljanje D1-D7 neupotrebljiva One of stop bars D1-D7 unservicable	Nema posledica na RWY 12R/30L ako je RWY 12R/30L zaštićena na drugi način Nema posledica na RWY 12L/30R No effect on RWY 12R/30L if RWY 12R/30L protection is ensured by other means No effect on RWY 12L/30R
	Više od jedne prečke za zaustavljanje D1-D7 neupotrebljivo More than one of stop bars D1-D7 unservicable	Operacije ograničene na jedan vazduhoplov na manevarskim površinama Operations limited to one aircraft on maneuvering areas
	Prečka za zaustavljanje Y neupotrebljiva Stop bar Y unserviceable	Nema posledice No effect
	Prečka za zaustavljanje M neupotrebljiva Stop bar M unserviceable	Nema posledice No effect
	Prečka za zaustavljanje N neupotrebljiva Stop bar N unserviceable	Nema posledica na RWY 12R/30L ako je RWY 12R/30L zaštićena na drugi način Nema posledica na RWY 12L/30R No effect on RWY 12R/30L if RWY 12R/30L protection is ensured by other means No effect on RWY 12L/30R
	Prečka za zaustavljanje T neupotrebljiva Stop bar T unserviceable	Nema posledica na RWY 12R/30L ako je RWY 12R/30L zaštićena na drugi način Nema posledica na RWY 12L/30R No effect on RWY 12R/30L if RWY 12R/30L protection is ensured by other means No effect on RWY 12L/30R
	Prečka za zaustavljanje T1 neupotrebljiva Stop bar T1 unserviceable	Nema posledice No effect
	Prečka za zaustavljanje F neupotrebljiva Stop bar F unserviceable	Nema posledice No effect
	Prečka za zaustavljanje F1 neupotrebljiva Stop bar F1 unserviceable	Nema posledice No effect
	Prečka za zaustavljanje F3 neupotrebljiva Stop bar F3 unserviceable	Nema posledice No effect
	Prečka za zaustavljanje F4 neupotrebljiva Stop bar F4 unserviceable	Nema posledice No effect
	Prečka za zaustavljanje G neupotrebljiva Stop bar G unserviceable	Nema posledice No effect
	Prečka za zaustavljanje H neupotrebljiva Stop bar H unserviceable	Nema posledice No effect

Razmatrani sistemi / Systems considered	*Otkaz koji prijavljuje ATC / Failure to be reported by ATC*	*Očekivana posledica na letenje / Expected effect on flying*
1	*2*	*3*
	Prečka za zaustavljanje ZORAN neupotrebljiva Stop bar ZORAN unserviceable	Nema posledice No effect
	Svetla zabrane ulaza R1 neupotrebljiva No entry bar R1 unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY R1 zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY R1 is closed
	Svetla zabrane ulaza R2 neupotrebljiva No entry bar R2 unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY R2 zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY R2 is closed
	Svetla zabrane ulaza R3 neupotrebljiva No entry bar R3 unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY R3 zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY R3 is closed
	Svetla zabrane ulaza R4 neupotrebljiva No entry bar R4 unserviceable	Nema posledica na RWY 12L ako je RWY 12L zaštićena na drugi način Nema posledica na RWY 12R, ako je TWY R4 zatvorena No effect on RWY 12L if RWY 12L protection is ensured by other means No effect on RWY 12R, if TWY R4 is closed
	Rezervno napajanje neupotrebljivo Standby power supply unserviceable	Letenje ograničeno na CAT I – operacije u vidnom delu dana Flight operations limited to CAT I – Daylight operations
RVR	RVR na prve 2/3 RWY neupotrebljiv Rollout RVR unserviceable	Nema posledica ako pilot može da proceni vidljivost No effect if visibility can be assessed by the pilot
	RVR na ostalim mernim tačkama neupotrebljiv Other RVR measuring points unserviceable	Ograničenje zavisi od pravila letenja Restriction depending on flight operation rules
	RVR pokazivač neupotrebljiv RVR display unserviceable	CAT I
Pomoćni sistem Ancillary	Anemometar neupotrebljiv Anemometer unserviceable	Nema posledica ako su raspoloživi drugi sistemi No effect if other sources available
	Silometar neupotrebljiv Ceilometer unserviceable	Nema posledica No effect

2. RNAV postupci za dolazak

2.1 Opšte

Postupci RNAV STAR vode vazduhoplov do putanje završnog prilaza koja je u sklopu objavljenih procedura instrumentalnog prilaženja za RWY 12L, RWY 12R, RWY 30R i RWY 30L.

Zaokret završnog prilaženja se obično izvodi radarskim vektorisanjem radi ekspeditivnosti vođenja saobraćaja i razdvajanja vazduhoplova.

Primena procedura zahteva odobrenje ATC.

Procedure će biti praćene na radaru.

Pilot vazduhoplova koji nije opremljen sa odgovarajućim sistemima mora o tome da obavesti ATC, po prijemu odobrenja za STAR ili njegove delove, koristeći frazu „UNABLE RNAV STAR“. ATC će tada radarski vektorisati vazduhoplov ili izdati konvencionalni STAR do putanje završnog prilaza relevantne procedure instrumentalnog prilaženja.

2. Procedures for RNAV arrivals

2.1 General

RNAV STARs guide the aircraft to the final approach track of the published instrument approach procedures for the RWY 12L, RWY 12R, RWY 30R and RWY 30L.

The turn to final approach is usually performed by radar vectors to expedite traffic handling and for separation reasons.

The utilization of the procedures requires a clearance by ATC.

The procedures will be radar monitored.

Pilots of aircraft which are not equipped with appropriate systems shall advise ATC, after reception of a clearance for a STAR or parts of it, about this fact, by using the phrase “UNABLE RNAV STAR”. ATC will then issue radar vectors or conventional STAR to the final approach track of the relevant instrument approach procedure.

2.2 Fraze/Odobrenja

Sledeće Fraze/Odobrenja koje se mogu koristiti:

a) „CLEARED (oznaka STAR-a) ARRIVAL“ za dozvolu za letenje po STAR u horizontalnoj ravni. Dodelu visina vrši ATC. Nadvišavanje terena je osigurano projektovanjem STAR-a;

b) „CLEARED DIRECT (oznaka tačke)“ je dozvola za letenje sa trenutne pozicije direktno do navedene tačke, a zatim za nastavak po odgovarajućem STAR-u za RWY u upotrebi. Dodelu visina vrši ATC. Nadvišavanje terena osigurava ATC.

Napomena: Oznaka tačke, za koju je moguće koristiti odobrenje navedeno pod b), se sastoji od poslednja dva slova četvoroslovne ICAO oznake lokacijskog indikatora aerodroma (BE) i tri cifre što se prenosi kao „BRAVO ECHO xxx“ (na primer CLEARED DIRECT BRAVO ECHO 103).

2.3 Ušteda pređenog rastojanja unutar TMA BEOGRAD

ATCC BEOGRAD izdaje odobrenja posadama vazduhoplova za letenje po RNAV STAR do putanje završnog prilaza odgovarajuće RWY u upotrebi.

Tokom saobraćajnog špica (koji je prethodno objavljen NOTAM-om) operateri vazduhoplova moraju da planiraju da lete po kompletnim postupcima RNAV STAR koji su objavljeni u AIP-u.

Izvan saobraćajnog špica, koji nije objavljen NOTAM-om, operateri vazduhoplova mogu da planiraju i da očekuju odobrenje da preseku putanju završnog prilaza između 10 NM do 15 NM od praga, čime se skraćuje pređeno rastojanje za približno 30 NM.

3. Prekid radio-veze

3.1 Vazduhoplovi u odlasku

Nastaviti let u skladu sa ICAO procedurom.

3.1.1 Vazduhoplovi koji odluče da se vrate na LYBE

- Postaviti squawk 7600;
- Zadržati poslednju odobrenu visinu ili penjati na minimalnu bezbednu visinu;
- 7 MIN nakon postavljanja squawk 7600 ili na granici FIR-a, šta je ranije, vratiti se na poslednju tačku SID procedure iz FPL-a;
- Za prilaz odabrati pravac RWY iz koga je izvršeno poletanje;
- Nakon poslednje tačke SID procedure iz FPL leteti na:
  - Za RWY 12L na LABUD;
  - Za RWY 12R na LAMBA;
  - Za RWY 30L na TUPKO;
  - Za RWY 30R na TUPKO; i potom
- Ukoliko je odobrena visina veća od 10000 FT snižavati do 10000 FT;
- Za RWY 12L uključiti se u postupak za čekanje na LABUD (videti IAC ILS or LOC RWY 12L);
- Za RWY 12R uključiti se u postupak za čekanje na LAMBA (videti IAC ILS or LOC RWY 12R);
- Za RWY 30L uključiti se u postupak za čekanje na TUPKO (videti IAC VOR B RWY 30L);
- Za RWY 30R uključiti se u postupak za čekanje na TUPKO (videti IAC ILS or LOC RWY 30R);
- U postupku za čekanje snižavati na MHA;
- Po dostizanju MHA napustiti postupak za čekanje i izvršiti IAP i sletanje.

2.2 Phraseology/Clearances

The following Phraseology/Clearances may be used:

a) “CLEARED (STAR designator) ARRIVAL” for authorization to fly the lateral STAR. Altitude assignments will be issued by ATC. The terrain clearance is assured by STAR design;

b) “CLEARED DIRECT (waypoint designator)” is the authorization to fly from the present position direct to a waypoint and to continue thereafter on the appropriate STAR to the RWY in use. Altitude assignments will be issued by ATC. The terrain clearance will be assured by ATC.

Note: Waypoint designator, that may be used for clearance under b), is based on the last two letters of the four-letter ICAO Location Indicator for aerodrome (BE) plus additionally three digits and shall be transmitted as “BRAVO ECHO xxx” (e.g. CLEARED DIRECT BRAVO ECHO 103).

2.3 Calculation of track miles within BEOGRAD TMA

BEOGRAD ATCC issues clearances to air crews to fly RNAV STARs to the final approach track of the relevant RWY in use.

During rush hours (previously published by NOTAM) aircraft operators have to plan the complete RNAV STARs published in AIP.

Outside NOTAM published rush hours, aircraft operators may plan and expect to be cleared to intercept final track between 10 NM and 15 NM from THR, reducing distance flown by approximately 30 NM.

3. Radiocommunication failure

3.1 Departing traffic

Continue the flight in accordance with ICAO procedure.

3.1.1 Aircraft that decide to return to LYBE

- Squawk 7600;
- Maintain last assigned level or climb to minimum safe altitude;
- 7 MIN after setting squawk 7600 or at the FIR boundary, whichever is earlier, return to last waypoint from FPL SID procedure;
- For the approach select departure RWY;
- After last waypoint from FPL SID procedure, fly to:
  - LABUD for RWY 12L;
  - LAMBA for RWY 12R;
  - TUPKO for RWY 30L;
  - TUPKO for RWY 30R; and then
- If cleared level is higher than 10000 FT descend to 10000 FT;
- For RWY 12L join published holding over LABUD (see IAC ILS or LOC RWY 12L);
- For RWY 12R join published holding over LAMBA (see IAC ILS or LOC RWY 12R);
- For RWY 30L join published holding over TUPKO (see IAC VOR B RWY 30L);
- For RWY 30R join published holding over TUPKO (see IAC ILS or LOC RWY 30R);
- Descend to MHA;
- After reaching MHA leave holding and execute IAP and landing.

3.2 Vazduhoplovi u dolasku

3.2.1 Vazduhoplovi koji nemaju informaciju o RWY u upotrebi i STAR

- Postaviti squawk 7600;
- Nastaviti let do početne tačke STAR procedure iz FPL-a;
- Zadržati poslednju odobrenu visinu 7 MIN od postavljanja squawk 7600 ili do ulaska u postupak za čekanje, šta god je kasnije;
- Uključiti se u publikovani postupak za čekanje na početnoj tački STAR procedure iz FPL-a;
- U postupku za čekanje snižavati do 10000 FT;
- Odabrati odgovarajuću RWY u upotrebi na osnovu ATIS emisije. Ukoliko nema ATIS, RWY odabrati na osnovu izveštaja o pravcu i brzini prizemnog vetra iz zadnjeg poznatog meteorološkog izveštaja i ukoliko je vetar odgovarajući, za sletanje odabrati bližu RWY;
- Nakon dostizanja 10000 FT u postupku za čekanje leteti:
  - Za RWY 12L na LABUD;
  - Za RWY 12R na LAMBA;
  - Za RWY 30L na TUPKO;
  - Za RWY 30R na TUPKO; i
- Za RWY 12L uključiti se u postupak za čekanje na LABUD (videti IAC ILS or LOC RWY 12L);
- Za RWY 12R uključiti se u postupak za čekanje na LAMBA (videti IAC ILS or LOC RWY 12R);
- Za RWY 30L uključiti se u postupak za čekanje na TUPKO (videti IAC VOR B RWY 30L);
- Za RWY 30R uključiti se u postupak za čekanje na TUPKO (videti IAC ILS or LOC RWY 30R);
- U postupku za čekanje snižavati na MHA;
- Po dostizanju MHA napustiti postupak za čekanje i izvršiti IAP i sletanje.

3.2.2 Vazduhoplovi kojima je dodeljen STAR

a) Pre STAR

- Postaviti squawk 7600;
- Zadržati poslednju odobrenu visinu 7 MIN od postavljanja squawk 7600 ili do ulaska u postupak za čekanje, šta god je kasnije;
- Uključiti se u publikovani postupak za čekanje na početnoj tački STAR procedure iz FPL-a;
- U postupku za čekanje započeti snižavanje do MHA;
- Nakon dostizanja MHA uključiti se u STAR proceduru i pratiti horizontalni i vertikalni profil cele procedure;
- Izvršiti IAP i sletanje.

b) Vazduhopovi koji prate STAR ili lete direktno na tačku u okviru STAR ili u prilazu ili su vektorisani

- Postaviti squawk 7600;
- Zadržati poslednju odobrenu visinu;
- Pratiti horizontalni profil celokupne STAR procedure ili pratiti granicu važenja odobrenja pa potom:
  - Za RWY 12L uključiti se u postupak za čekanje na LABUD (videti IAC ILS or LOC RWY 12L);
  - Za RWY 12R uključiti se u postupak za čekanje na LAMBA (videti IAC ILS or LOC RWY 12R);
  - Za RWY 30L uključiti se u postupak za čekanje na TUPKO (videti IAC VOR B RWY 30L);
  - Za RWY 30R uključiti se u postupak za čekanje na TUPKO (videti IAC ILS or LOC RWY 30R);

3.2 Arriving traffic

3.2.1 Aircraft without an assigned RWY and STAR

- Squawk 7600;
- Proceed to first waypoint of a STAR according to FPL;
- Maintain last assigned level for 7 MIN after setting squawk 7600 or until joining holding, whichever is later;
- Join published holding over first waypoint of a STAR according to FPL;
- In holding commence descent to 10000 FT;
- Select appropriate RWY in use according to ATIS broadcast. If ATIS is not available, select RWY according to surface wind direction and velocity from last known MET REPORT and if wind is suitable, select closer RWY;
- After reaching 10000 FT in holding, fly to:
  - LABUD for RWY 12L;
  - LAMBA for RWY 12R;
  - TUPKO for RWY 30L;
  - TUPKO for RWY 30R; and
- For RWY 12L join published holding over LABUD (see IAC ILS or LOC RWY 12L);
- For RWY 12R join published holding over LAMBA (see IAC ILS or LOC RWY 12R);
- For RWY 30L join published holding over TUPKO (see IAC VOR B RWY 30L);
- For RWY 30R join published holding over TUPKO (see IAC ILS or LOC RWY 30R);
- Descend to MHA;
- After reaching MHA leave holding and execute IAP and landing.

3.2.2 Aircraft that are assigned a STAR

a) Before STAR

- Squawk 7600;
- Maintain last assigned level for 7 MIN after setting squawk 7600 or until joining holding, whichever is later;
- Join published holding over first waypoint of a STAR according to FPL;
- In holding commence descent to MHA;
- After reaching MHA join STAR and follow horizontal and vertical profile of entire procedure;
- Execute IAP and landing.

b) Aircraft already following STAR or flying direct on a STAR or approach point or being vectored

- Squawk 7600;
- Maintain last assigned level;
- Follow horizontal profile of entire STAR or proceed as cleared and then:
  - For RWY 12L join published holding over LABUD (see IAC ILS or LOC RWY 12L);
  - For RWY 12R join published holding over LAMBA (see IAC ILS or LOC RWY 12R);
  - For RWY 30L join published holding over TUPKO (see IAC VOR B RWY 30L);
  - For RWY 30R join published holding over TUPKO (see IAC ILS or LOC RWY 30R);

– U postupku za čekanje snižavati do MHA;
– Po dostizanju MHA napustiti postupak za čekanje i izvršiti IAP i sletanje.

c) Vazduhoplovi u postupku za čekanje
– Postaviti squawk 7600;
– Zadržati poslednju odobrenu visinu 7 MIN od postavljanja squawk 7600;
– U postupku za čekanje snižavati do MHA;
– Po dostizanju MHA napustiti postupak za čekanje i pratiti STAR u skladu sa izdatim EAT ili ETA iz FPL-a, šta je kasnije;
– Izvršiti IAP i sletanje.

3.2.3 Vazduhoplovi koji prate proceduru neuspelog prilaženja

– Postaviti squawk 7600;
– Pratiti MISSED APPROACH proceduru sa odobrenom visinom;
– Nakon OBR čim je moguće leteti:
  – Za RWY 12L/12R na LOGAR;
  – Za RWY 30L/30R na RIPAN, pa se potom
– Uključiti u IAP za prethodno dodeljenu RWY ili suprotnu RWY u slučaju da je razlog MISSED APPROACH nepovoljni vetar;
– Penjati/Snižavati na visinu za započinjanje IAP;
– Izvršiti IAP i sletanje.

4. VFR postupci za dolazak i odlazak

Videti kartu AD 2 LYBE 15.1–1/2.

4.1 Dolasci

4.1.1 VFR letovi u sletanju na AD BEOGRAD/Nikola Tesla moraju da koriste VFR rute od NDB OBR i NDB PA do tačaka za čekanje SAZIV i PELZO. Dalje instrukcije i odobrenje za sletanje se dobijaju od AKL BEOGRAD (BEOGRAD ATSU) na frekvenciji 118.100 MHZ.

4.1.2 U slučaju gubitka radio-veze pilot treba da uključi SSR kod A7600, ukoliko je vazduhoplov opremljen transponderom, da se vrati VFR rutom i sleti na najbliži nekontrolisani aerodrom. Ukoliko to nije moguće vazduhoplov će čekati na tački SAZIV ili PELZO na svetlosni signal sa AKL BEOGRAD (BEOGRAD ATSU) za sletanje.

4.2 Odlasci

4.2.1 Planiranje VFR letova treba da bude u skladu sa VFR rutama.

4.2.2 VFR letovi treba da slede uputstva i odobrenja od AKL BEOGRAD (BEOGRAD ATSU) na frekvenciji 118.100 MHZ.

4.3 Tranzitni letovi

VFR letovi kroz CTR BEOGRAD biće odobreni samo ukoliko to saobraćajna situacija dozvoljava.

– In holding commence descent to MHA;
– After reaching MHA leave holding and execute IAP and landing.

c) Aircraft HOLDING in flight
– Squawk 7600;
– Maintain last assigned level for 7 MIN after setting squawk 7600;
– In holding commence descent to MHA;
– After reaching MHA leave holding and follow STAR according to issued EAT or FPL ETA, whichever is later;
– Execute IAP and landing.

3.2.3 Aircraft following MISSED APPROACH procedure

– Squawk 7600;
– Follow MISSED APPROACH procedure climbing to cleared altitude;
– After OBR when ready fly to:
  – LOGAR for RWY 12L/12R;
  – RIPAN for RWY 30L/30R, and then
– Join IAP on previously assigned RWY or opposite RWY if MISSED APPROACH was caused by unsuitable wind;
– Climb/Descend to altitude for initiating IAP;
– Execute IAP and landing.

4. VFR flight procedures for arrival and departure

See chart AD 2 LYBE 15.1–1/2.

4.1 Arrivals

4.1.1 VFR flights landing at BEOGRAD/Nikola Tesla AD shall be conducted on VFR routes from OBR NDB and PA NDB to SAZIV and PELZO holding points. Further instructions and landing clearance will be given by BEOGRAD ATSU on frequency 118.100 MHZ.

4.1.2 In the case of communication failure, if aircraft is equipped with transponder, pilot shall squawk SSR code A7600, return on VFR route and land at the nearest uncontrolled aerodrome. If unable to comply aircraft will hold at SAZIV or PELZO awaiting light signals from BEOGRAD ATSU.

4.2 Departures

4.2.1 VFR flights should be planned according to VFR routes.

4.2.2 VFR flights shall comply with instructions and clearances given by BEOGRAD ATSU on frequency 118.100 MHZ.

4.3 Transit flights

VFR transit flights through BEOGRAD CTR will be cleared only if traffic situation permits.

LYBE AD 2.23 DODATNE INFORMACIJE ADDITIONAL INFORMATION

1. Upotreba dela CAT II sistema svetala u CAT I uslovima

Avio-prevozioci vrše najave u pisanom obliku, najmanje 24 HR pre planiranog sletanja, na elektro@beg.aero.

Dodatni kontakt detalji:

TEL: + 381 11 209 7111, + 381 64 848 5312

1. Use of part of CAT II lighting system in CAT I conditions

Aircraft operators shall submit requests in writing, minimum 24 HR before planned landing, to elektro@beg.aero.

Additional contacts:

TEL: + 381 11 209 7111, + 381 64 848 5312

2. Ptice

Periodična pojava ptica na i u blizini RWY.

2. Birds

Periodical bird concentration on and in the vicinity of RWY.

LYBE AD 2.24 VAZDUHOPLOVNE KARTE KOJE SE ODNOSE NA AERODROM
AERONAUTICAL CHARTS RELATED TO AN AERODROME

| Aerodrome Chart – ICAO ..... AD 2 LYBE 01.1–1/2
| Aircraft Parking/Docking Chart – ICAO ..... AD 2 LYBE 02.1–1/2
| Aerodrome Obstacle Chart – ICAO Type A (RWY 12L) ..... AD 2 LYBE 04.1–1/2
| Aerodrome Obstacle Chart – ICAO Type A (RWY 12R) ..... AD 2 LYBE 04.1–3/4
| Aerodrome Obstacle Chart – ICAO Type A (RWY 30L) ..... AD 2 LYBE 04.1–5/6
| Aerodrome Obstacle Chart – ICAO Type A (RWY 30R) ..... AD 2 LYBE 04.1–7/8
| Precision Approach Terrain Chart – ICAO (RWY 12L) ..... AD 2 LYBE 06.1–1/2
| Precision Approach Terrain Chart – ICAO (RWY 12R) ..... AD 2 LYBE 06.1–3/4
| Standard Departure Chart – Instrument – ICAO (RWY 12L/12R) ..... AD 2 LYBE 08.1–1/2
| Standard Departure Chart – Instrument – ICAO (RWY 12L/12R – TISAK 4Z) ..... AD 2 LYBE 08.1–3/4
| Standard Departure Chart – Instrument – ICAO (RWY 30L/30R) ..... AD 2 LYBE 08.1–5/6
| Standard Departure Chart – Instrument – ICAO (RNAV RWY 12L/12R) ..... AD 2 LYBE 08.2–1/2
| Standard Departure Chart – Instrument – ICAO (RNAV RWY 30L/30R) ..... AD 2 LYBE 08.2–3/4
| Standard Arrival Chart – Instrument – ICAO (RWY 12L/12R) ..... AD 2 LYBE 10.1–1/2
| Standard Arrival Chart – Instrument – ICAO (RWY 30L/30R) ..... AD 2 LYBE 10.1–3/4
| Standard Arrival Chart – Instrument – ICAO (RNAV RWY 12L/12R) ..... AD 2 LYBE 10.2–1/4
| Standard Arrival Chart – Instrument – ICAO (RNAV RWY 30L/30R) ..... AD 2 LYBE 10.2–5/8
| Instrument Approach Chart – ICAO (ILS or LOC RWY 12L) ..... AD 2 LYBE 12.1–1/2
| Instrument Approach Chart – ICAO (ILS or LOC RWY 12R) ..... AD 2 LYBE 12.1–3/4
| Instrument Approach Chart – ICAO (ILS or LOC RWY 30R) ..... AD 2 LYBE 12.1–5/6
| Instrument Approach Chart – ICAO (VOR RWY 12L) ..... AD 2 LYBE 12.2–1/2
| Instrument Approach Chart – ICAO (VOR A RWY 12R) ..... AD 2 LYBE 12.2–3/4
| Instrument Approach Chart – ICAO (VOR B RWY 30L) ..... AD 2 LYBE 12.2–5/6
| Instrument Approach Chart – ICAO (VOR RWY 30R) ..... AD 2 LYBE 12.2–7/8
| Instrument Approach Chart – ICAO (RNP RWY 12L) ..... AD 2 LYBE 12.4–1/2
| Instrument Approach Chart – ICAO (RNP RWY 12R) ..... AD 2 LYBE 12.4–3/4
| Instrument Approach Chart – ICAO (RNP RWY 30L) ..... AD 2 LYBE 12.4–5/6
| Instrument Approach Chart – ICAO (RNP RWY 30R) ..... AD 2 LYBE 12.4–7/8
| Bird concentrations in the vicinity of the aerodrome ..... AD 2 LYBE 14.1–1/2
| VFR flight procedures for arrival and departure ..... AD 2 LYBE 15.1–1/2

LYBE AD 2.25 PRODOR POVRŠI VIZUELNOG SEGMENTA (VSS)
VISUAL SEGMENT SURFACE (VSS) PENETRATION

Neprimenljivo
Not applicable