

₊A8

PEOAO PC0D0 PC1D1 PC2D2 PC3D3 PC4D4 PC5D5 PC6D6 PC7D7 PB8D8 PB9D9 PB10D10 PB11D11 PE1A1 PETAT PE2A2 PE3 (Key1)A3 PE4 (Key0)A4 PE5A5 PE6A6 PE7A7 PE8A8 PE9A9 PE10A10 PE10D10
PE12A12 PB11D11
PE13A13 PB12D12
PE14A14 PB13D13
PE15A15 PB14D14
PA0 (Key UP)A16 PB15D15
PA1A17
PA2A10 PE11A11 PD8WE# PD9Reset# PD10WP# PA2A18 PA3A19 PA4A20 PD11RY/BY# PA5A21 PA6 (LED1)A22 PA7 (LED2)A23 PA8A24 PD12Byte# PD130E PD14CE

,A15

₊A22

₊A22