



# The Unio Smart Case Raspberry Pi 4

## **Hardware Setup:**





## **Shutdown Button Setup:**

In this tutorial we show you how to configure the proper shutdown button script at startup.

sudo wget https://github.com/Unio-IoT/smart/archive/master.zip

This will download the zip file named master.zip and you need to unzip the same by using the following command and rename the directory.

```
sudo unzip master.zip
sudo mv /home/pi/smart-master /home/pi/smart
```

After unzip you will get a directory named smart-case-master, please open the directory by using the following command.

cd smart

Make the script executable.

sudo chmod +x UNQ4B.py

The best method to run a program on your Raspberry Pi at startup is to use the file **rc.local**. In order to have a command or program run when the Pi boots, you can add commands to the **rc.local** file. This is especially useful if you want to power up your Pi in headless mode (that is without a connected monitor), and have it run a program without configuration or a manual start.

#### **Editing rc.local**

On your Pi, edit the file /etc/rc.local using the editor of your choice. You must edit it with root permissions:

sudo nano /etc/rc.local

Add commands to execute the python program, preferably using absolute referencing of the file location (complete file path are preferred). Be sure to leave the line **exit 0** at the end, then save the file and exit. In nano, to exit, type Ctrl-x, and then Y.

python /home/pi/smart/UNQ4B.pyc &

python /home/pi/smart/UNQ4B.pyc & exit 0

If your program runs continuously (runs an infinite loop) or is likely not to exit, you must be sure to fork the process by adding an ampersand ("&") to the end of the command, like:

The Pi will run this program at bootup, and before other services are started. If you don't include the ampersand and if your program runs continuously, the Pi will not complete its boot process. The ampersand allows the command to run in a separate process and continue booting with the main process running.

Now reboot the Pi to test it:

sudo reboot

#### Note:

Also, be sure to reference absolute file names rather than relative to your home folder. For example use `/home/pi/myscript.py` instead of `myscript.py`.

If you add a script into /etc/rc.local, it is added to the boot sequence. If your code gets stuck then the boot sequence cannot proceed.

Unio and Unio Smart Case logo and designs are trademarks or registered trademarks of Unio IoT Pvt. Ltd. and/or its affiliates in the India and/or other countries, and may not be used without written permission.

Python is a registered trademark of the PSF (Python Software Foundation).

Raspberry Pi and the Raspberry Pi Logo are a registered trademark of the Raspberry Pi Foundation, which is a UK registered charity.