

SIM7672X & SIM7652X Series_Sleep Mode_ Application Note

LTE Module

SIMCom Wireless Solutions Limited

SIMCom Headquarters Building, Building 3, No. 289 Linhong
Road, Changning District, Shanghai P.R. China
Tel: 86-21-31575100
support@simcom.com
www.simcom.com



Document Title:	SIM7672X & SIM7652X Series_Sleep Mode_Application Note
Version:	1.00
Date:	2023.05.22
Status:	Released

GENERAL NOTES

SIMCOM OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS, TO SUPPORT APPLICATION AND ENGINEERING EFFORTS THAT USE THE PRODUCTS DESIGNED BY SIMCOM. THE INFORMATION PROVIDED IS BASED UPON REQUIREMENTS SPECIFICALLY PROVIDED TO SIMCOM BY THE CUSTOMERS. SIMCOM HAS NOT UNDERTAKEN ANY INDEPENDENT SEARCH FOR ADDITIONAL RELEVANT INFORMATION, INCLUDING ANY INFORMATION THAT MAY BE IN THE CUSTOMER'S POSSESSION. FURTHERMORE, SYSTEM VALIDATION OF THIS PRODUCT DESIGNED BY SIMCOM WITHIN A LARGER ELECTRONIC SYSTEM REMAINS THE RESPONSIBILITY OF THE CUSTOMER OR THE CUSTOMER'S SYSTEM INTEGRATOR. ALL SPECIFICATIONS SUPPLIED HEREIN ARE SUBJECT TO CHANGE.

COPYRIGHT

THIS DOCUMENT CONTAINS PROPRIETARY TECHNICAL INFORMATION WHICH IS THE PROPERTY OF SIMCOM WIRELESS SOLUTIONS LIMITED COPYING, TO OTHERS AND USING THIS DOCUMENT, ARE FORBIDDEN WITHOUT EXPRESS AUTHORITY BY SIMCOM. OFFENDERS ARE LIABLE TO THE PAYMENT OF INDEMNIFICATIONS. ALL RIGHTS RESERVED BY SIMCOM IN THE PROPRIETARY TECHNICAL INFORMATION, INCLUDING BUT NOT LIMITED TO REGISTRATION GRANTING OF A PATENT, A UTILITY MODEL OR DESIGN. ALL SPECIFICATION SUPPLIED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.

SIMCom Wireless Solutions Limited

SIMCom Headquarters Building, Building 3, No. 289 Linhong Road, Changning District, Shanghai P.R. China

Tel: +86 21 31575100

Email: simcom@simcom.com

For more information, please visit:

https://www.simcom.com/technical_files.html

For technical support, or to report documentation errors, please visit:

https://www.simcom.com/online_questions.html or email to: support@simcom.com

Copyright © 2023 SIMCom Wireless Solutions Limited All Rights Reserved.

www.simcom.com 1 / 11



About Document

Version History

Version	Date	Owner	Description
V1.00	2023.5.22		New version

www.simcom.com 2 / 11



Scope

Based on module AT command manual, this document will introduce Sleep mode application process. Developers could understand and develop application quickly and efficiently based on this document. This document applies to SIM7672X Series, SIM7652X Series.



www.simcom.com 3 / 11



Contents

About Document	
About Document	
Scope	
Contents	
1 Introduction	
1.1 Purpose of the document	
1.2 Related documents	
2 Sleep depth	6
3 Sleep	
3.1 Sleep conditions	
3.2 Sleep steps	
3.3 Sleep status	8
4 Wake Up	
4.1 Wake Up Source	
4.2 Wake up method	
5 AT Commands for Sleep	
5.1 AT+CSCLK Control Sleep	



1 Introduction

1.1 Purpose of the document

This document describes what conditions are required to make the module enter the sleep mode and how to wake up the module.

1.2 Related documents

[1] SIM7672X & SIM7652X Series_AT Command Manual.

www.simcom.com 5 / 11



2 Sleep depth

ACTIVE state: The PMU Module is off, even if there is nothing to do, the MCU is still waiting in while loop. The power consumption is the largest.

IDLE state: At this state MCU will turn off the core clock when there is no task, all system interrupt can wake up the system and restart the core clock.

SLEEP1 state: All peripherals are powered down on the basis of IDLE state, and peripheral interrupts cannot wake up the system.

OFF state: Power off the chip, can wake-up only by PWRKEY.

NOTE

The sleep depth we set is SLEEP1 state about AT+CSCLK=1 or AT+CSCLK=2. All
tasks equally determine sleep. The sleep state is influenced by various factors, and
they will undergo a voting mechanism and eventually enter sleep mode.

www.simcom.com 6 / 11



3 Sleep

3.1 Sleep conditions

Minimum functionality mode ceases a majority function of the module, to enable the module enter the minimum power consumption mode, the following hardware and software conditions must be followed:

- (1) Module is in normal mode.
- (2) Send AT command "AT+CFUN=0".
- (3) Send AT command "AT+CSCLK=1" or "AT+CSCLK=2".
- (4) DTR pin pulled to high level and USB_ VBUS pulled to low level.

This mode is set by the AT command which provides a choice of the functionality levels.

AT+CFUN=0: Minimum functionality
AT+CFUN=1: Full functionality (Default)

AT+CFUN=4: Flight mode

If module has been set to minimum functionality mode, the RF function and SIM card function will be closed. In this case, the serial port and USB are still accessible, but RF function and SIM card will be unavailable. If module has been set to flight mode, the RF function will be closed. In this case, the serial port and USB are still accessible, but RF function will be unavailable.

3.2 Sleep steps

- 1.Send the AT command "AT+CSCLK=1" or "AT+CSCLK=2".
- 2.Send the AT command "AT+CFUN=0".(optional)
- 3.Unplug USB.
- 4. Pull up DTR.

NOTE

 If 'AT+CFUN=0' is not sent, the module may not be able to sleep or will not sleep for a long time.

www.simcom.com 7 / 11



3.3 Sleep status

- 1.The network light is off.
- 2. Sending instructions through serial port is not possible.
- 3.We can see the sign 'enter sleep' in the log.
- 4.measure power consumption below 1mA.



www.simcom.com 8 / 11



4 Wake Up

4.1 Wake Up Source

The chip has six wake-up sources:wakeup0,wakeup1,wakeup2,wakeup3,wakeup4,wakeup5. This wake-up method is mainly determined by the hardware.For example, DTR, serial port RX, VBUS, these three commonly used wake-up methods on our end.

4.2 Wake up method

(1)AT+CSCLK=1

When we use **AT+CSCLK=1**, then unplug the USB and raise the DTR to sleep, we can wake up the module by plugging in the USB or lowering the DTR, The main phenomenon observed is that commands can be sent, followed by the network light being on.

(2)AT+CSCLK=2

When we use AT+CSCLK=2 to hibernate the module, we can use the main serial port to send data for module wake-up when unplugging the USB, similar to AT+CSCLK=1.

www.simcom.com 9 / 11



5 AT Commands for Sleep

5.1 AT+CSCLK Control Sleep

This command is used to enable UART Sleep or always work. If set to 0, UART always work. If set to 1, ensure that DTR is pulled high and the module can go to DTR sleep. If set to 2, the module will enter RX sleep. RX wake-up directly sends data through the serial port (for example: AT) to wake-up.

AT+CSCLK Control UART Sleep		
Test Command AT+CSCLK=?	Response +CSCLK: (range of supported <status>s) OK</status>	
Read Command AT+CSCLK?	Response +CSCLK: <status></status>	
Write Command AT+CSCLK= <status></status>	Response 1) OK 2) ERROR	
Execution Command AT+CSCLK	Response Set <status>=0: OK</status>	
Parameter Saving Mode	NO_SAVE	
Max Response Time	9000ms	
Reference	-	

Defined Values

<status></status>	<u>0</u>	off
	1	DTR sleep
	2	RX sleep

Examples

AT+CSCLK? +CSCLK: 0

10 / 11 www.simcom.com



OK

AT+CSCLK=?

+CSCLK: (0-2)

OK

AT+CSCLK=1

OK

AT+CSCLK=2

OK

AT+CSCLK

OK



www.simcom.com