

## Configuration de l'Access Switch :

### Paramètres généraux :

#### # Spanning-tree

```
spanning-tree mode rapid-pvst
spanning-tree portfast default
spanning-tree bpduguard default
```

#### # SSH

```
hostname FLO-SW-ACC-01
ip domain-name lab.local
crypto key generate rsa modulus 2048
```

```
username admin secret cisco
```

```
line vty 0 4
login local
transport input ssh
```

```
no ip domain-lookup #éviter blocage si erreur de commande
service password-encryption #chiffrer les mdp
```

#### # Création des vlans

```
vlan 10
name users
vlan 20
name wifi
vlan 30
name servers
vlan 40
name mngmt
```

#### # Uplink vers Coreswitch

```
int range g2/0/47-48
switchport mode trunk
switchport trunk allowed vlan 10,20,30,40
spanning-tree portfast trunk
no sh
```

#### # Ports vlan 10

```
int range g2/0/1-12
switchport mode access
switchport access vlan 10
spanning-tree portfast
no sh
```

#### # Ports vlan 20

```
int range g2/0/21-24
switchport mode access
switchport access vlan 20
spanning-tree portfast
no sh
```

```
# Ports vlan 30
int range g2/0/25-26
switchport mode access
switchport access vlan 30
spanning-tree portfast
no sh
```

```
# Ports vlan 40
int range g2/0/37-38
switchport mode access
switchport access vlan 40
no sh
int vlan 40
ip addr 172.17.4.2 255.255.255.248
no sh
```

```
ip default-gateway 172.17.5.2
```

```
# Sécurité
int range g0/25-48
sh
```

```
int range g0/2-20
switchport port-security
switchport port-security maximum 2
switchport port-security violation restrict
```

```
# Pour wipe switch
write erase
delete flash:vlan.dat
reload
no
```