

Voter2-MTR2K Quick Start Guide

20 July 2026, Dave Maciorowski, WA1JHK, www.jhk-labs.com

Here are the steps to perform to setup your Voter2-MTR2K for the first time from factory defaults. You will need the Voter2 Users Guide for reference. For more info, see the Basic Setup on page 11.

1. Install the board and power up
 - The board can be installed in Option Slot 1 or 2, either the middle or the bottom slot.
 - The Wireline card can be installed or not installed. It is not used.
 - Plug in the line cord of the MTR2000.
2. Setup the USB Console and connect your terminal program.
 - Plug a USB-C cable into the console connector of the Voter2-MTR2K.
 - Run a terminal emulator program, e.g. Tera Term or Putty.
 - Set the serial port baudrate to 115200, 8, N, 1.
3. Plug in the RSS cable, run RSS and edit the board configuration.
 - Plug in the RSS cable. Connect it to your computer running RSS.
 - Click File | Read Station.
 - On the Station Configuration dialog, click Edit Config.
 - Click on Option Board Type and select Aux I/O.
 - Click Ok. Click File | Write Station.
4. Login to the Voter2 with the root login.
 - Press enter until the prompt says `Username`.
 - Enter a `Username` of `root`.
 - Enter a `Password` of `guru`.
5. Setup the radio interface.
 - `help show` – view the list of configuration options.
 - The `show` command is also used to view individual configuration options.
 - `set gpsdev liv4f` – set up GPS operation for the ST Teseo-LIV4F module that is preinstalled on your board.
 - The `set` command is used to set individual configuration options.
 - `set rssimode analog` – this should already be set to `analog` but worth checking. This option uses the MTR2000 station-generated RSSI output for voting.
 - `set rxmode cor` – rely on the MTR2000 COR logic output for now.
 - Notice that there is an asterisk displayed at your prompt, like this: `root*>`
This informs you that you have made changes that are not yet permanently saved. Use the command `settings save` to save your changes to nonvolatile memory.

6. Plug in your GPS 3.3V Active Antenna.

- Your GPS receiver is searching for satellites.
- `help status` – see the list of status display options.
 - There are a number of summary status screens available to you.
- `status gps --` shows you the gps connection information and satellites received.

7. Setup your local mode operation.

- `set local mode repeater` – you will use local mode to set the transmit audio level.

8. Setup your Audio Level Calibration.

Follow the instructions in Appendix D of the Users Guide, page 36.

- Make sure that you are NOT generating CTCSS.

9. Setup your RSSI Calibration.

Follow the instructions in Appendix E of the Users Guide, page 39.

10. Setup your Squelch Calibration.

Follow the instructions in Appendix F of the Users Guide, page 43.

11. Plug in your network connection.

- Plug your network cable into the shielded connector. This is the network connector.

12. Setup your network connection.

If you are using DHCP, the Factory Defaults will work fine.

- `status ethernet` will show you the connection information.

If you are setting up your own IP address, set the following options:

- `set myipmode static` – set this option to `static`.
- `set mystaticip <ip address>` – set your IP Address, e.g. 192.168.20.220
- `set mystaticsn <subnet>` – set your Subnet Mask, e.g. 255.255.255.0
- `set mystaticgw <gateway ip address>` – set your Gateway Address, e.g. 192.168.20.1
- `set mystaticdns <dns ip address>` – set your DNS Address, e.g. 192.168.20.1
- `status ethernet` will show you the connection information.

13. Setup your AllstarLink (DIAL) connection.

Configure these options.

- `set dial ipmode static` – set this to `static` or `dns`.
- `set dial port 1667` – set to 667 for pre-ASL3; set to 1667 for ASL3.
- `set dial staticip <ASL ip address>` -- set the ip address of the voter server.
- `set dial fqdn <fully qualified domain name>` – used when `ipmode` is set to `dns`.
- `set dial voterpwd <password>` – set the voter-unique password defined as the secret in the voter client definition of `voter.conf`.
- `set dial hostpwd <password>` – set the host password defined in the general stanza of `voter.conf`.
- `set dial voterchal <challenge>` – set the voter challenge string, if required.
- `status dial --` shows the connection status.