




GNUSim8085 - 8085 Microprocessor Simulator

File Reset Assembler Debug Help

Registers

Register	Value	Flag
A	05	S 0
BC	05 00	Z 1
DE	00 04	AC 0
HL	00 14	P 1
PSW	00 00	C 0
PC	42 16	
SP	FF FF	
Int-Flag	00	

Decimal - Hex Conversion

Decimal: 0 Hex: 0

To Hex To Dec

I/O Ports

0 - + 00

Update Port Value

Memory

0 - + 00

Update Memory

Load me at:

- 1 MOV A, 2200
- 2 MOV B, A
- 3 MVI D, 0
- 4 LIA 2201
- 5 MOV C, A
- 6 LXL H, 0000
- 7 DAD D
- 8 DCR C
- 9 JNC BACT
- 10 SHLD 2202
- 11 BACT

Start: 2200 OK

Address (Hex)	Address	Data
0808	2200	4
0809	2201	5
080A	2202	20
080B	2203	0
080C	2204	0
080D	2205	0
080E	2206	0
080F	2207	0
08A0	2208	0
08A1	2209	0
08A2	2210	0
08A3	2211	0
08A4	2212	0
08A5	2213	0

Line No. Assembler Message

0 Program assembled successfully

Simulator: Idle

