

1:07

Vo 11.5 5G+
NR KB/s



GNUSimBOBS - 8085 Microprocessor Simulator

File Reset Assembler Debug Help

Registers

Register	Value	Flag
A	00	S 0
BC	00 00	Z 1
DE	00 00	AC 0
HL	00 00	P 1
PSW	00 00	C 0
PC	42 22	
SP	00 0A	
Int-Reg	00	

Decimal - Hex Conversion

Decimal: 0 Hex: 0

To Hex To Dec

I/O Ports

0 - + 00

Update Port Value

Memory

0 - + 00

Update Memory

Load me at

```
1. LDD 2050
2. SPHL
3. LDD 2050
4. JC 2050
5. LXT R4, 0000H
6. LXT R5, 0000H
7. RALD: LMD SP
8. JNC START
9. INC B
10. RALD: DCK B
11. MOV A, B
12. ORA D
13. JNC AGAIN
14. RALD: 2050
15. MOV I, C
16. MOV R, B
17. RALD: 2050
18. RLT
19.
20.
21.
```

Start: 2050 OK

Address (Hex)	Address	Data
0802	2050	10
0803	2051	0
0804	2052	5
0805	2053	0
0806	2054	50
0807	2055	5
0808	2056	0
0809	2057	0
080A	2058	0
080B	2059	0
080C	2060	0
080D	2061	0
080E	2062	0
080F	2063	0

Line No. Assembler Message

0 Program assembled successfully

Simulator: Idle