

Terminal Chat CLI

Below are the commands you can enter into the Terminal Chat clients:

`set freq {frequency}`

Set the LoRa frequency. Example: `set freq 915.8`

`set tx {tx-power-dbm}`

Sets LoRa transmit power in dBm.

`set name {name}`

Sets your advertisement name.

`set lat {latitude}`

Sets your advertisement map latitude. (decimal degrees)

`set lon {longitude}`

Sets your advertisement map longitude. (decimal degrees)

`set dutycycle {percent}`

Sets the transmit duty cycle limit (1-100%). Example: `set dutycycle 10` for 10%.

`set af {air-time-factor}`

Sets the transmit air-time-factor. Deprecated — use `set dutycycle` instead.

`time {epoch-secs}`

Set the device clock using UNIX epoch seconds. Example: `time 1738242833`

`advert`

Sends an advertisement packet

`clock`

Displays current time per device's clock.

`ver`

Shows the device version and firmware build date.

`card`

Displays *your* 'business card', for others to manually *import*

`import {card}`

Imports the given card to your contacts.

`list {n}`

List all contacts by most recent. (optional {n}, is the last n by advertisement date)

`to`

Shows the name of current recipient contact. (for subsequent 'send' commands)

`to {name-prefix}`

Sets the recipient to the *first* matching contact (in 'list') by the name prefix. (ie. you don't have to type whole name)

`send {text}`

Sends the text message (as DM) to current recipient.

`reset path`

Resets the path to current recipient, for new path discovery.

`public {text}`

Sends the text message to the built-in 'public' group channel